


DIGITAL CAMERA

COOLPIX S5300 User's Manual



For advanced use of the camera, read the Reference Manual (in pdf format) which is available in many languages including Hindi, Bengali, Tamil, Marathi and Telugu. See the reverse side for information to download the file.





i


Introduction

Read This First

Thank you for purchasing the Nikon COOLPIX S5300 digital camera. Before using the camera, please read the information in "For Your Safety" (
will-x) and familiarize yourself with the information provided in this manual. After reading, please keep this manual handy and refer to it to enhance your enjoyment of your new camera.

Confirming the Package Contents

In the event that any items are missing, please contact the store where you purchased the camera.



- User's Manual (this manual)
- Warranty
- * A plug adapter is included if the camera was purchased in a country or region that requires a plug adapter. The shape of the plug adapter varies with the country or region of purchase (
 12).

NOTE: A memory card is not included with the camera.

About This Manual

If you want to start using the camera right away, see "The Basics of Shooting and Playback" (@10).

To learn about the parts of the camera and information that is displayed in the monitor, see "Parts of the Camera" (\square 1).

Downloading the "Reference Manual"

Refer to the *Reference Manual* (PDF format) for more detailed information. The *Reference Manual* can be downloaded from the Nikon website.

http://nikonimglib.com/manual/

The *Reference Manual* can be viewed using Adobe Reader, available for free download from the Adobe website.

Other Information

• Symbols and Conventions

Symbol	Description
	This icon marks cautions and information that should be read before using the camera.
Ø	This icon marks notes and information that should be read before using the camera.
∏/ ∞ /ö	These icons indicate other pages containing relevant information;

*Refer to the *Reference Manual* for pages indicated with 🟍.

- SD, SDHC, and SDXC memory cards are referred to as "memory cards" in this manual.
- The setting at the time of purchase is referred to as the "default setting."
- The names of menu items displayed in the camera monitor, and the names of buttons or messages displayed on a computer monitor appear in bold.
- In this manual, images are sometimes omitted from monitor display samples so that monitor indicators can be more clearly shown.
- Illustrations and monitor content shown in this manual may differ from the actual product.

Information and Precautions

Life-Long Learning

As part of Nikon's "Life-Long Learning" commitment to ongoing product support and education, continually updated information is available online at the following sites:

- For users in the U.S.A.: http://www.nikonusa.com/
- For users in Europe and Africa: http://www.europe-nikon.com/support/
- For users in Asia, Oceania, and the Middle East: http://www.nikon-asia.com/

Visit these sites to keep up-to-date with the latest product information, tips, answers to frequently asked questions (FAQs), and general advice on digital imaging and photography. Additional information may be available from the Nikon representative in your area. Visit the site below for contact information.

http://imaging.nikon.com/

Use Only Nikon Brand Electronic Accessories

Nikon COOLPIX cameras are designed to the highest standards and include complex electronic circuitry. Only Nikon brand electronic accessories (including battery chargers, batteries, Charging AC Adapters, AC adapters and, USB cables) certified by Nikon specifically for use with this Nikon digital camera are engineered and proven to operate within the operational and safety requirements of this electronic circuitry.

The use of non-Nikon electronic accessories could damage the camera and may void your Nikon warranty.

The use of third-party rechargeable Li-ion batteries not bearing the Nikon holographic seal could interfere with normal operation of the camera or result in the batteries overheating, igniting, rupturing, or leaking.

For more information about Nikon brand accessories, contact a local authorized Nikon dealer.

Holographic seal: Identifies this device as an authentic Nikon product.

kon Nikon Nik kon Nikon Nik byj<u>N</u> uoyjN uoj kon Nikon Nik

Before Taking Important Images

Before taking images on important occasions (such as at weddings or before taking the camera on a trip), take a test shot to ensure that the camera is functioning normally. Nikon will not be held liable for damages or lost profits that may result from product malfunction.

About the Manuals

- No part of the manuals included with this product may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form, by any means, without Nikon's prior written permission.
- Nikon reserves the right to change the specifications of the hardware and software described in these manuals at any time and without prior notice.
- Nikon will not be held liable for any damages resulting from the use of this product.
- While every effort was made to ensure that the information in these manuals is accurate and complete, we would appreciate it were you to bring any errors or omissions to the attention of the Nikon representative in your area (address provided separately).

Notice Concerning Prohibition of Copying or Reproduction

Note that simply being in possession of material that was digitally copied or reproduced by means of a scanner, digital camera or other device may be punishable by law.

Items prohibited by law from being copied or reproduced

Do not copy or reproduce paper money, coins, securities, government bonds or local government bonds, even if such copies or reproductions are stamped "Sample." The copying or reproduction of paper money, coins, or securities which are circulated in a foreign country is prohibited. Unless the prior permission of the government was obtained, the copying or reproduction of unused postage stamps or post cards issued by the government is prohibited.

The copying or reproduction of stamps issued by the government and of certified documents stipulated by law is prohibited.

Cautions on certain copies and reproductions

The government has issued cautions on copies or reproductions of securities issued by private companies (shares, bills, checks, gift certificates, etc.), commuter passes, or coupon tickets, except when a minimum of necessary copies are to be provided for business use by a company. Also, do not copy or reproduce passports issued by the government, licenses issued by public agencies and private groups, ID cards and tickets, such as passes and meal coupons.

• Comply with copyright notices

The copying or reproduction of copyrighted creative works such as books, music, paintings, woodcut prints, maps, drawings, movies, and photographs is governed by national and international copyright laws. Do not use this product for the purpose of making illegal copies or to infringe copyright laws.

Disposing of Data Storage Devices

Please note that deleting images or formatting data storage devices such as memory cards or built-in camera memory does not completely erase the original image data. Deleted files can sometimes be recovered from discarded storage devices using commercially available software, potentially resulting in the malicious use of personal image data. Ensuring the privacy of such data is the user's responsibility.

Before discarding a data storage device or transferring ownership to another person, erase all data using commercial deletion software, or format the device and then completely refill it with images containing no private information (for example, images of empty sky). Be sure to also replace any images selected for the **Select an image** option in the **Welcome screen** setting (\square 77). Care should be taken to avoid injury or damage to property when physically destroying data storage devices.

To delete the Wi-Fi settings, select **Restore default settings** in the Wi-Fi options menu (*b*71).

For Your Safety

To prevent damage to your Nikon product or injury to yourself or to others, read the following safety precautions in their entirety before using this equipment. Keep these safety instructions where all those who use the product will read them.

The consequences that could result from failure to observe the precautions listed in this section are indicated by the following symbol:



This icon marks warnings, information that should be read before using this Nikon product, to prevent possible injury.

WARNINGS

Turn off in the event of malfunction

Should you notice smoke or an unusual smell coming from the camera or Charging AC Adapter, unplug the Charging AC Adapter and remove the battery immediately, taking care to avoid burns. Continued operation could result in injury. After removing or disconnecting the power source, take the equipment to a Nikonauthorized service representative for inspection.

\Lambda Do not disassemble

Touching the internal parts of the camera or Charging AC Adapter could result in injury. Repairs should be performed only by qualified technicians. Should the camera or Charging AC Adapter break open as the result of a fall or other accident, take the product to a Nikon-authorized service representative for inspection, after unplugging the product and/or removing the battery.

Do not use the camera or Charging AC Adapter in the presence of flammable gas

Do not use electronic equipment in the presence of flammable gas, as this could result in explosion or fire.

\Lambda Handle the camera strap with care

Never place the strap around the neck of an infant or child.

🔺 Keep out of reach of children

Particular care should be taken to prevent infants from putting the battery or other small parts into their mouths.

Do not remain in contact with the camera, Charging AC Adapter, or AC adapter for extended periods while the devices are on or in use

Parts of the devices become hot. Leaving the devices in direct contact with the skin for extended periods may result in lowtemperature burns.

Do not leave the product where it will be exposed to extremely high temperatures, such as in an enclosed automobile or in direct sunlight

Failure to observe this precaution could cause damage or fire.

Observe caution when handling the battery

The battery may leak, overheat, or explode if improperly handled. Observe the following precautions when handling the battery for use in this product:

- Before replacing the battery, turn the product off. If you are using the Charging AC Adapter/AC adapter, be sure it is unplugged.
- Use only a Rechargeable Li-ion Battery EN-EL19 (included). Charge the battery by using a camera that supports battery charging. To perform this operation, use the Charging AC Adapter EH-71P (included) and USB cable UC-E21 (included). The Battery Charger MH-66 (available separately) is also available to charge the battery without using a camera.

- When inserting the battery, do not attempt to insert it upside down or backwards.
- Do not short or disassemble the battery or attempt to remove or break the battery insulation or casing.
- Do not expose the battery to flame or to excessive heat.
- Do not immerse in or expose to water.
- Put the battery in a plastic bag, etc. in order to insulate it before transporting. Do not transport or store with metal objects such as necklaces or hairpins.
- The battery is prone to leakage when fully discharged. To avoid damage to the product, be sure to remove the battery when no charge remains.
- Discontinue use immediately should you notice any change in the battery, such as discoloration or deformation.
- If liquid from the damaged battery comes in contact with clothing or skin, rinse immediately with plenty of water.

▲ Observe the following precautions when handling the Charging AC Adapter

- Keep dry. Failure to observe this precaution could result in fire or electric shock.
- Dust on or near the metal parts of the plug should be removed with a dry cloth. Continued use could result in fire.
- Do not handle the plug or go near the Charging AC Adapter during lightning storms. Failure to observe this precaution could result in electric shock.

- Do not damage, modify, forcibly tug or bend the USB cable, place it under heavy objects, or expose it to heat or flames. Should the insulation be damaged and the wires become exposed, take it to a Nikon-authorized service representative for inspection. Failure to observe these precautions could result in fire or electric shock.
- Do not handle the plug or Charging AC Adapter with wet hands. Failure to observe this precaution could result in electric shock.
- Do not use with travel converters or adapters designed to convert from one voltage to another or with DC-to-AC inverters. Failure to observe this precaution could damage the product or cause overheating or fire.

Use the appropriate power supply (battery, Charging AC adapter, AC adapter, USB cable)

Using a power supply other than those provided or sold by Nikon could result in damage or malfunction.

\Lambda Use appropriate cables

When connecting cables to the input and output jacks, use only the cables provided or sold by Nikon for the purpose, to maintain compliance with product regulations.

A Handle moving parts with care

Be careful that your fingers or other objects are not pinched by the lens cover or other moving parts.

$\mathbf{\Lambda}$

Using the flash close to your subject's eyes could cause temporary visual impairment

The flash should be no less than 1 meter (3 ft 4 in.) from the subject.

Particular care should be observed when photographing infants.

Do not operate the flash with the flash window touching a person or object

Failure to observe this precaution could result in burns or fire.

🔺 Avoid contact with liquid crystal

Should the monitor break, care should be taken to avoid injury caused by broken glass and to prevent liquid crystal from the monitor touching the skin or entering the eyes or mouth.

Turn the power off when using inside an airplane or the hospital

Turn the power off while inside the airplane during take off or landing. Do not use wireless network functions while in the air. Follow the instructions of the hospital when using while in a hospital. The electromagnetic waves emitted by this camera may disrupt the electronic systems of the airplane or the instruments of the hospital. If you are using an Eye-Fi card, remove it from the camera before boarding an aircraft or entering a hospital.

Notices

Notices for Customers in the U.S.A.

IMPORTANT SAFETY INSTRUCTIONS -

SAVE THESE INSTRUCTIONS.

DANGER - TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS

For connection to a supply not in the U.S.A., use an attachment plug adapter of the proper configuration for the power outlet if needed.

The power supply unit is intended to be correctly orientated in a vertical or floor mount position.

Federal Communications Commission (FCC) Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.



CAUTIONS

Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Nikon Corporation may void the user's authority to operate the equipment.

Interface Cables

Use the interface cables sold or provided by Nikon for your equipment. Using other interface cables may exceed the limits of Class B Part 15 of the FCC rules.

Notice for Customers in the State of California WARNING

Handling the cord on this product will expose you to lead, a chemical known to the State of California to cause birth defects or other reproductive harm.

Wash hands after handling.

Nikon Inc.,

1300 Walt Whitman Road Melville, New York 11747-3064 USA Tel: 631-547-4200

Notice for Customers in Canada

CAN ICES-3 B / NMB-3 B

Notices for Customers in Europe

CAUTIONS

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

This symbol indicates that electrical and electronic equipment is to be collected separately.



The following apply only to users in European countries:

- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- Separate collection and recycling helps conserve natural resources and prevent negative consequences for human health and the environment that might result from incorrect disposal.
- For more information, contact the retailer or the local authorities in charge of waste management.

This symbol on the battery indicates that the battery is to be collected separately.



The following apply only to users in European countries:

- All batteries, whether marked with this symbol or not, are designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- For more information, contact the retailer or the local authorities in charge of waste management.

Wi-Fi (Wireless LAN Network)

This product is controlled by the United States Export Administration Regulations, and you are required to obtain permission from the United States government if you export or reexport this product to any country to which the United States embargoes goods. The following countries were subject to embargo: Cuba, Iran, North Korea, Sudan, and Syria. Since the target countries are subject to change, please contact the United States Department of Commerce for the latest information.

Restrictions on Wireless Devices

The wireless transceiver included in this product conforms to wireless regulations in the country of sale and is not for use in other countries (products purchased in the EU or EFTA can be used anywhere within the EU and EFTA). Nikon does not accept liability for use in other countries. Users who are unsure as to the original country of sale should consult with their local Nikon service center or Nikon-authorized service representative. This restriction applies to wireless operation only and not to any other use of the product.

Notice for Customers in the U.S.A. and Canada

Federal Communications Commission (FCC) and Industry of Canada (IC)

Declaration of Conformity

This device complies with Part 15 of FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device.

FCC/IC RF Exposure Statement

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

The available scientific evidence does not show that any health problems are associated with using low power wireless devices. There is no proof, however, that these low power wireless devices are absolutely safe. Low power wireless devices emit low levels of radio frequency energy (RF) in the microwave range while being used. Whereas high levels of RF can produce health effects (by heating tissue), exposure of low-level RF that does not produce heating effects causes no known adverse health effects. Many studies of low-level RF exposures have not found any biological effects. Some studies have suggested that some biological effects might occur, but such findings have not been confirmed by additional research.

COOLPIX 55300, which is equipped with a WSDB-686GN (FCC ID:2AAD3AA1G0J0 / IC ID:4634A-2150EC) Wireless LAN Module, has been tested and found to comply with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65 and RSS-102 of the IC radio frequency (RF) Exposure rules. Please refer to the SAR test report that was uploaded to FCC website.

Declaration of Conformity (Europe)

Hereby, Nikon Corporation, declares that COOLPIX S5300 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of conformity may be consulted at http://imaging.nikon.com/support/pdf/DoC_S5300.pdf.

Precautions when Using Radio Transmissions

• Always keep in mind that radio transmission or reception of data is subject to interception by third parties. Note that Nikon is not responsible for data or information leaks that may occur during data transfer.

Personal Information Management and Disclaimer

- User information registered and configured on the product, including wireless LAN
 connection settings and other personal information, is susceptible to alteration and loss
 resulting from operational error, static electricity, accident, malfunction, repair or other
 handling. Always keep separate copies of important information. Nikon is not responsible
 for any direct or indirect damages or lost profits resulting from alteration or loss of content
 that is not attributable to Nikon.
- Before discarding this product or transferring it to another owner, perform **Reset all** in the setup menu (\$\overline\$77) to delete all user information registered and configured with the product, including wireless LAN connection settings and other personal information.

Table of Contents

Introduction	ii
Read This First	ii
Confirming the Package Contents	i
About This Manual	ii
Information and Precautions	v
For Your Safety	viii
WARNINGS	
Notices	xi
Wi-Fi (Wireless LAN Network)	xiii

Parts of the Camera	1
The Camera Body	. 1
Attaching the Camera Strap	. 3
Using Menus (the MENU Button)	4
The Monitor	. 6
Shooting Mode	. 6
Playback Mode	. 8

The Basics of Shooting and Playback

••••		10
	Preparation 1 Insert the Battery	10
	Preparation 2 Charge the Battery	12
	Preparation 3 Insert a Memory Card	14
	Internal Memory and Memory Cards	15
	Preparation 4 Setting the Display Language	ge,
	Date, and Time	16
	Step 1 Turn the Camera On	20
	Step 2 Select a Shooting Mode	22

10

Available Shooting Modes	. 23
Step 3 Frame a Picture	24
Using the Zoom	
Step 4 Focus and Shoot	26
The Shutter-release Button	. 27
Step 5 Play Back Images	28
Step 6 Delete Images	30
Shooting Features	32
🕮 (Scene Auto Selector) Mode	32
Scene Mode (Shooting Suited to Scenes)	
-	34
Tips and Notes	. 35
Special Effects Mode (Applying Effects	
When Shooting)	40
Smart Portrait Mode (Capturing Images o	of
Smiling Faces)	42
🗖 (Auto) Mode	44
Using Quick Effects	. 45
Functions That Can Be Set Using the Mul	ti
Selector	46
Using the Flash	. 47
Using the Self-timer	. 49
Using Macro Mode	. 51
Adjusting Brightness (Exposure	
Compensation)	. 52
Default Settings	. 53
Functions That Can Be Set with the MENU	
Button (Shooting Menu)	55

Refer to the *Reference Manual* for pages indicated with 🏍.

Introduction

Options Available in the Shooting Menu

FG

Functions That Cannot Be Used	
Simultaneously	58
Focusing	61
Using Face Detection	61
Using Skin Softening	62
Using Target Finding AF	63
Subjects Not Suitable for Autofocus	64
Focus Lock	65

Playback Zoom	66
Thumbnail Playback/Calendar Display	67
Functions That Can Be Set with the MENU	
Button (Playback Menu)	68

Recording and Playing Back Movies.... 70

Recording Movies	70
Functions That Can Be Set with the MENU	
Button (Movie Menu)	74
Playing Back Movies	75

Jsing the Wi-Fi (Wireless LAN) Function
Functions That Can Be Performed Using Wi
Fi 70

Take Photos View Photos Installing the Software on the Smart Devi Connecting the Smart Device to the Cam	79 ce 80 era
Connecting the Camera to a TV,	
Computer, or Printer	83
Connection Methods	83
Using ViewNX 2	
Installing ViewNX 2	
Transferring Images to the Computer	
Viewing Images	89
Reference Section	01
Using Easy Panorama (Shooting and	
Playback) 🕭	
Shooting with Easy Panorama 🕭	02
Viewing Images Captured with Easy	
Panorama ð	
Favorite Pictures Mode 🕭	
Adding Images to Albums ð	
Playing Back Images in Albums ð	
Removing Images from Albums	
Changing the Favorites Album Icon ð	
Auto Sort Mode	
List by Date Mode	511
Viewing and Deleting Images Captured	
Continuously (Sequence)	
Viewing Images in a Sequence	
Deleting Images in a Sequence 🗲	013

Fqi	ting Images (Still Images)	5014
E	Before Editing Images	5-0 14
	Quick Effects: Changing Hue or Mood	
	Quick Retouch: Enhancing Contrast a	
	Saturation	
	D-Lighting: Enhancing Brightness and	
	Contrast	
	Red-eye Correction: Correcting Red-ey	
	When Shooting with the Flash	
C	Jiamour Relouch: Enhancing Human	
	Small Picture: Reducing the Size of an	5-010
	mage	~~ 20
	Crop: Creating a Cropped Copy	
	nnecting the Camera to a TV (Playba	
	a TV)	
		J=022
	nnecting the Camera to a Printer (Di	
Cor		irect
Cor Prir	nnecting the Camera to a Printer (D nt) Connecting the Camera to a Printer	irect 50 24
Cor Prir	nnecting the Camera to a Printer (D nt) Connecting the Camera to a Printer	irect 5-024
Cor Prir (nnecting the Camera to a Printer (D nt)	irect 5-024 5-025 5-027
Cor Prir C F	nnecting the Camera to a Printer (D nt)	irect 5-024 5-025 5-027 5-029
Cor Prin C F F Edi	nnecting the Camera to a Printer (D nt)	irect -024 -025 -027 -027 -029 -032
Cor Prir C F Edi The	nnecting the Camera to a Printer (D nt)	irect -024 -025 -027 -027 -029 -032 de)
Cor Prir (F Edi The	nnecting the Camera to a Printer (D nt)	irect 24 20 25 27 20 27 20 27 20 27 20 27 20 27 20 27 20 27 20 27 20 27 27 27 27 27 27 27 27 27 27
Cor Prir (F Edi The	nnecting the Camera to a Printer (D nt)	irect -024 -025 -027 -029 -029 -032 de) -034
Cor Prir C F Edi The 	nnecting the Camera to a Printer (D) to me the Camera to a Printer (D) Connecting the Camera to a Printer Printing Images One at a Time	irect -024 -025 -027 -029 -032 de) -034 -034
Cor Prin F F Edi The In	nnecting the Camera to a Printer (D) connecting the Camera to a Printer Printing Images One at a Time Printing Multiple Images ting Movies e Shooting Menu (for (Auto) Mo mage Mode (Image Size and Quality)	irect
Cor Prir F F Edi The 	nnecting the Camera to a Printer (D) nt)	irect -024 -025 -027 -029 -032 de) -034 -034 -036 -036 -039
Cor Prir F F Edi The 	nnecting the Camera to a Printer (D) nt)	irect -025 -027 -029 -032 de) -034 -0 -034 -0 -034

Autofocus Mode	0-048
Quick Effects	
The Smart Portrait Menu	🍽 49
Skin Softening	🏍 49
Smile Timer	🏍 50
Blink Proof	6-6 51
The Playback Menu	
Print Order (Creating a DPOF Print C	
Slide Show	
Protect	
Rotate Image	
Voice Memo	
Copy (Copy Between Internal Mem	-
Memory Card)	
Sequence Display Options	
Choose Key Picture	
The Movie Menu	
Movie Options	
Open with HS Footage	
Autofocus Mode	🍋 68
Movie VR	
Wind Noise Reduction	
Frame Rate	
The Wi-Fi Options Menu	
The Setup Menu	
Welcome Screen	
Time Zone and Date	
Monitor Settings	6-6 76
Print Date (Imprinting Date and Tim	,
Photo VR	
Motion Detection	🍋 80


Refer to the *Reference Manual* for pages indicated with 🍋.


xviii

	AF Assist	6-6 81
	Digital Zoom	6-6 81
	Sound Settings	6-6 82
	Auto Off	6-0 82
	Format Memory/Format Card	6-6 83
	Language	6-6 84
	TV Settings	6-6 84
	Charge by Computer	6-6 85
	Blink Warning	6-6 86
	Eye-Fi Upload	6-6 87
	Reset All	6-6 88
	Firmware Version	66 88
Err	or Messages	ð - ð89
	e Names	
Op	otional Accessories	ð - ð95
Op	otional Accessories	∂− 095
	otional Accessories nnical Notes and Index	
Tech		. Ø 1
Tech Ca	nical Notes and Index	
Tech Ca	nical Notes and Index ring for the Product The Camera	. Ø-1 Ø-2 Ø-2
Tech Ca	nical Notes and Index ring for the Product	
Tech Ca	nical Notes and Index ring for the Product The Camera The Battery	. Ö-1 Ö-2 Ö-2 Ö-3 Ö-4
Tech Ca	rincal Notes and Index ring for the Product The Camera The Battery Charging AC Adapter	, Ö-1 , Ö-2 , Ö-2 , Ö-3 , Ö-4 , Ö-5
Tech Ca Cle	rincal Notes and Index ring for the Product The Camera The Battery Charging AC Adapter Memory Cards	
Tech Ca Cle	rincal Notes and Index ring for the Product The Camera The Battery Charging AC Adapter Memory Cards eaning and Storage	,
Tech Ca Cle	rincal Notes and Index ring for the Product The Camera The Battery Charging AC Adapter Memory Cards Paning and Storage Cleaning	. $\dot{\mathcal{O}}$ 1 $\dot{\mathcal{O}}$ 2 $\dot{\mathcal{O}}$ 2 $\dot{\mathcal{O}}$ 3 $\dot{\mathcal{O}}$ 4 $\dot{\mathcal{O}}$ 5 $\dot{\mathcal{O}}$ 6 $\dot{\mathcal{O}}$ 6 $\dot{\mathcal{O}}$ 6
Tech Ca Cle	rincal Notes and Index ring for the Product The Camera. The Battery Charging AC Adapter Memory Cards aning and Storage Cleaning Storage	. $\dot{\mathcal{O}}$ 1 $\dot{\mathcal{O}}$ 2 $\dot{\mathcal{O}}$ 2 $\dot{\mathcal{O}}$ 3 $\dot{\mathcal{O}}$ 4 $\dot{\mathcal{O}}$ 5 $\dot{\mathcal{O}}$ 6 $\dot{\mathcal{O}}$ 6 $\dot{\mathcal{O}}$ 6 $\dot{\mathcal{O}}$ 7
Tech Ca Cle Tro Sp	rincal Notes and Index ring for the Product The Camera The Battery Charging AC Adapter Memory Cards saning and Storage Cleaning Storage bubleshooting	, 21 , 22 , 22 , 23 , 23 , 24 , 25 , 25

Parts of the Camera

The Camera Body







2

Attaching the Camera Strap







Using Menus (the MENU Button)

Use the multi selector and the 🞯 button to navigate the menus.

- 1 Press the MENU button.
 - The menu is displayed.



2 Press the multi selector ◀.

• The current menu icon is displayed in yellow.



	Shooting menu
D	Image mode
	White balance
*	Continuous
((_T))	ISO sensitivity
	Color options
4	AF area mode
╘───	Autofocus mode

Menu icons

- **3** Select the desired menu icon.
 - The menu is changed.



- 4 Press the 🛞 button.
 - The menu options become selectable.



5 Select a menu option.



7 Select a setting.

6 Press the 🛞 button.

• The settings for the option you selected are displayed.



8 Press the 🛞 button.

- The setting you selected is applied.
- When you are finished using the menu, press the **MENU** button.





Setting Menu Options


- Certain menu options cannot be set depending on the current shooting mode or the state of the camera. Unavailable options are displayed in gray and cannot be selected.

The Monitor

The information that is displayed in the monitor during shooting and playback changes depending on the camera's settings and state of use.


By default, information is displayed when the camera is turned on and when you operate the camera, and turns off after a few seconds (when **Photo info** is set to **Auto info** in **Monitor settings** (\square 77)).

Shooting Mode



1	Shooting mode22, 34, 40, 42, 44
2	Flash mode47
3	Macro mode51
4	Zoom indicator
5	Focus indicator
6	Movie options (normal speed movies)
7	Movie options (HS movies)
8	Image mode
。 9	5
	Easy panorama
10	Photo VR icon
11	Movie VR icon
12	Motion detection icon
13	Wind noise reduction
14	Exposure compensation value 52
15	Movie recording time remaining
16	Number of exposures remaining
10	(still images)
17	Internal memory indicator
18	Aperture value
19	Focus area (target finding AF)63, 🖚46
20	Focus area (for manual or center)
	,
21	Focus area (face detection, pet detection)

22	Focus area (subject tracking)
	0-0 45, 0-0 47
23	Shutter speed27
24	ISO sensitivity
25	(a) Battery level indicator20(b) Charging AC Adapter connection indicator
26	Print date
27	"Date not set" indicator16
28	Wi-Fi communication indicator
29	Eye-Fi communication indicator
30	Travel destination icon
31	White balance mode
32	Skin softening
33	Color options
34	Quick effects icon 45, 56, 🖚 48
35	Continuous shooting mode 56, 🏍 39
36	Blink proof icon
37	Hand-held/tripod35, 36
38	Backlighting (HDR)
39	Self-timer indicator49
40	Smile timer
41	Pet portrait auto release
42	Still image capture (during movie recording)




1	Album icon in favorite pictures mode	
2	Category icon in auto sort mode 🖚 10	
3	List by date icon 🖚 11	
4	Protect icon	
5	Sequence display (when Individual pictures is selected)	
6	Print order icon68, 🟍52	
7	Voice memo indicator	
8	Glamour retouch icon	
9	Quick effects icon29, 🖚14	
10	D-Lighting icon	
11	Quick retouch icon	
12	Red-eye correction icon	
13	Internal memory indicator	
14	(a) Current image number/ total number of images(b) Movie length	

15	Image mode	
16	Easy panorama	
17	Movie options	
18	Small picture icon	
19	Crop icon	
20	Volume indicator75, 🖚60	
21	Quick effects guide	
22	Easy panorama playback guide Sequence playback guide Movie playback guide	
23	Time of recording	
24	Date of recording	
25	(a) Battery level indicator20(b) Charging AC Adapter connection indicator	
26	File number and type	
27	Eye-Fi communication indicator	

The Basics of Shooting and Playback


Preparation 1 Insert the Battery

1 Open the battery-chamber/memory card slot cover.



2 Insert the battery.

- Push the orange battery latch in the direction indicated by the arrow (①), and fully insert the battery (②).
- The battery locks into place when inserted correctly.



Be Careful to Insert the Battery in Correct Direction

Inserting the battery upside down or backwards could damage the camera.



3 Close the battery-chamber/memory card slot cover.


Removing the Battery


Turn the camera off and make sure that the power-on lamp and monitor have turned off, and then open the battery-chamber/ memory card slot cover.

Move the battery latch in the direction indicated by the arrow $(\widehat{0})$ to eject the battery $(\widehat{2})$.

High Temperature Caution

The camera, battery, and memory card may be hot immediately after using the camera.





Preparation 2 Charge the Battery

1 Prepare the included Charging AC Adapter.



If a plug adapter* is included with your camera, attach the plug adapter to the plug on the Charging AC Adapter. Push the plug adapter firmly until it is securely held in place. Once the two are connected, attempting to forcibly remove the plug adapter could damage the product.


* The shape of the plug adapter varies according to the country or region in which the camera was purchased. This step can be omitted if the plug adapter comes permanently bonded to the Charging AC Adapter.

2 Make sure the battery is installed in the camera, and then connect the camera to the Charging AC Adapter in order of (1) to (3).

Make sure that the plugs are properly oriented. Do not insert or remove the plugs at an
angle when connecting or disconnecting them.

Note

Do not use a USB cable other than the UC-E21. Using a USB cable other than the UC-E21 could result in overheating, fire or electric shock.



Charge lamp	Description
Flashes slowly (green)	The battery is charging.
Off	When charging is complete, the charge lamp stops flashing green and turns off. About 1 hour and 50 minutes are required to charge a fully exhausted battery.
Flashes quickly (green)	 The ambient temperature is not suited to charging. Charge the battery indoors with an ambient temperature of 5°C to 35°C (41°F to 95°F). The USB cable or Charging AC Adapter is not properly connected, or there is a problem with the battery. Disconnect the USB cable or unplug the Charging AC Adapter and correctly connect it again, or change the battery.

3 Disconnect the Charging AC Adapter from the electrical outlet and then disconnect the USB cable.

Notes About Charging the Battery

- The camera can be operated while the battery is charging, but the charging time increases.
- If the battery level is extremely low, you may not be able to operate the camera while the battery is charging.
- Do not, under any circumstances, use another make or model of AC adapter other than Charging AC Adapter EH-71P, and do not use a commercially available USB-AC adapter or a battery charger for a mobile phone. Failure to observe this precaution could result in overheating or in damage to the camera.

Charging Using a Computer or Battery Charger

- You can also charge the battery by connecting the camera to a computer (🛄 83, 🏍 85).
- You can use the Battery Charger MH-66 (available separately; 🔊 95) to charge the battery without using the camera.

Preparation 3 Insert a Memory Card

1 Turn off the camera and open the batterychamber/memory card slot cover.


2 Insert the memory card.


• Slide the memory card in until it clicks into place.


Be Careful to Insert the Memory Card in Correct Direction

Inserting the memory card upside down or backwards could damage the camera and memory card.

3 Close the battery-chamber/memory card slot cover.







Memory card slot



The Basics of Shooting and Playback

Formatting a Memory Card

The first time you insert a memory card that has been used in another device into this camera, make sure to format it with this camera. Insert the memory card into the camera, press the **MENU** button, and select **Format card** in the setup menu.

Removing the Memory Card

Turn the camera off and make sure that the power-on lamp and monitor have turned off, and then open the battery-chamber/ memory card slot cover.


Gently push the memory card into the camera (1) to partially eject the card (2).

High Temperature Caution

The camera, battery, and memory card may be hot immediately after using the camera.

Internal Memory and Memory Cards


Camera data, including images and movies, can be saved either in the camera's internal memory or on a memory card. To use the camera's internal memory, first remove the memory card.



Preparation 4 Setting the Display Language, Date, and Time

When the camera is turned on for the first time, the language-selection screen and the date and time setting screen for the camera clock are displayed.

 If you exit without setting the date and time, will flash when the shooting screen is displayed.



3 Select Yes and press the 🛞 button.



4 Select your home time zone and press the 🛞 button.

- To enable davlight saving time, press A. When the daylight saving time function is enabled. Se is displayed above the map. To disable the daylight saving time function, press $\mathbf{\nabla}$.
- 5 Select the date format and press the ® button.

6 Set the date and time, and press the **®** button

- and minute).
- Edit the date and time: Press ▲▼.
- Confirm the settings: Select the minute field and press the (R) button.
- Select **Yes** and press the **(W**) button.
 - · When settings are finished, the lens extends and the camera switches to shooting mode.











Changing the Language or the Date and Time Setting

- You can change these settings using the **Language** and **Time zone and date** settings in the **Y** setup menu (C)77).
- You can enable or disable daylight saving time in the **Ŷ** setup menu by selecting **Time zone and date** followed by **Time zone**. Press the multi selector **▶** and then **▲** to enable daylight saving time and move the clock forward one hour, or **▼** to disable daylight saving time and move the clock back one hour.

Interview Clock Battery

- The camera's clock is powered by a built-in backup battery. The backup battery charges when the main battery is inserted into the camera or when the camera is connected to an optional AC adapter, and it can run the clock for several days after about ten hours of charging.
- If the camera's backup battery becomes exhausted, the date and time setting screen is displayed when the camera is turned on. Set the date and time again. See step 3 ([116]) of "Preparation 4 Setting the Display Language, Date, and Time" for more information.

Imprinting the Shooting Date on Printed Images


- You can permanently imprint the shooting date on images as they are captured by setting Print date in the setup menu (
 77).
- You can use the ViewNX 2 software (\$\overlime{10}\$85) to print the shooting date on images that were captured without using the **Print date** option.

e e

Step 1 Turn the Camera On

1 Press the power switch.

- The monitor turns on.
- To turn the camera off, press the power switch again.



2 Check the battery level indicator and the number of exposures remaining.

Battery Level Indicator

Number of exposures remaining

Display	Description		
	The battery level is high.	2	
	The battery level is low.		
① Battery exhausted.	The camera cannot capture images. Recharge the battery.		


Battery level indicator

Number of Exposures Remaining

The number of images that can be taken is displayed.

• In is displayed when no memory card is inserted in the camera, and images are saved in the internal memory.

I The Auto Off Function




- The time that elapses before the camera enters standby mode is about one minute. The time can be changed using the **Auto off** setting in the setup menu (\square 77).
- While the camera is in standby mode, the monitor turns back on if you perform any of the following operations:

Step 2 Select a Shooting Mode



2 Use the multi selector ▲▼ to select a shooting mode and press the 🛞 button.

- Section (scene auto selector) mode is used in this example.
- The shooting mode setting is saved even after the camera is turned off.



Available Shooting Modes


SCEN	Scene auto selector	CC 32
	The camera automatically selects the optimum scene mode when you frame an making it even easier to take images using settings that suit the scene.	image,
ĩ	Scene mode	11 34
	Camera settings are optimized according to the scene that you select.	
S0	Special effects	4 0
	Effects can be applied to images during shooting.	
3	Smart portrait	4 2
	When the camera detects a smiling face, you can take an image automatically wi pressing the shutter-release button (smile timer). You can also use the skin softer option to smooth the skin tones of human faces.	
Ō	Auto mode	4 4
	Used for general shooting. Settings can be adjusted to suit the shooting condition the type of shot you want to capture.	ons and

Step 3 Frame a Picture

1 Hold the camera steady.

Keep fingers and other objects away from the lens, flash, AF assist-illuminator, microphone, and speaker.

• When taking pictures in portrait ("tall") orientation, turn the camera so that the flash is above the lens.





2 Frame the picture.

• When the camera automatically determines the scene mode, the shooting mode icon changes (\$\box\$32).

Shooting mode icon



Notes About 🕮 (Scene Auto Selector) Mode

- Depending upon shooting conditions, the camera may not select the desired scene mode. In this case, select another shooting mode (CP34, 40, 42, 44).
- When the digital zoom is in effect, the scene mode changes to

🖉 When Using a Tripod

- We recommend using a tripod to stabilize the camera in the following situations:
 - When shooting in dim lighting
 - When shooting with the flash mode (QQ48) set to 🚯 (off)
 - When using the telephoto setting
- When using a tripod to stabilize the camera during shooting, set **Photo VR** to **Off** in the setup menu (\square 77) to prevent potential errors caused by this function.

Using the Zoom

When you move the zoom control, the zoom lens position changes.

- To zoom in closer to the subject: Move toward **T** (telephoto).
- To zoom out and view a larger area: Move toward W (wide-angle).


When you turn the camera on, the zoom moves to the maximum wide-angle position.

- A zoom indicator is displayed at the top of the monitor when the zoom control is moved.
- Digital zoom, which allows you to further magnify the subject up to approximately 4x the maximum optical zoom ratio, can be activated by moving and holding the zoom control toward **T** when the camera is zoomed in to the maximum optical zoom position.

🖉 Notes About Digital Zoom

The zoom indicator turns blue when the digital zoom is activated, and it turns yellow when the zoom magnification is increased further.

- Zoom indicator is blue: Image quality is not noticeably reduced by using the Dynamic Fine Zoom.
- Zoom indicator is yellow: Image quality is noticeably reduced.
- The indicator remains blue across a wider area when the image size is smaller.
- The zoom indicator may not turn blue when using certain continuous shooting settings.






Step 4 Focus and Shoot

1 Press the shutter-release button halfway.

- When the subject is in focus, the focus area glows green (multiple focus areas can glow green).
- When you are using digital zoom, the camera focuses in the center of the frame and the focus area is not displayed. When the camera has focused, the focus indicator (\$\$\overlime{17}\$) glows green.
- If the focus area or focus indicator flashes, the camera is unable to focus. Modify the composition and try pressing the shutter-release button halfway again.

2 Without lifting your finger, press the shutterrelease button the rest of the way down.









The Shutter-release Button

Press halfway	To set focus and exposure (shutter speed and aperture value), press the shutter-release button lightly until you feel a slight resistance. Focus and exposure remain locked while the shutter- release button is pressed halfway.
Press all the way	Press the shutter-release button all the way to release the shutter and take an image. Do not use force when pressing the shutter-release button, as this may result in camera shake and blurred images. Press the button gently.

Notes About Saving Images and Recording Movies

The indicator showing the number of exposures remaining or the indicator showing the maximum movie length flashes while images are being saved or while a movie is being recorded. **Do not open the battery-chamber/memory card slot cover or remove the battery or memory card** while an indicator is flashing. Doing this could result in loss of data, or in damage to the camera or the memory card.

Step 5 Play Back Images

1 Press the 🕨 (playback) button.

 If you press and hold down the
 (playback) button while the camera is turned off, the camera turns on in playback mode.



- **2** Use the multi selector to select an image to display.
 - Press and hold down ▲▼◀▶ to scroll through the images quickly.



Display the previous image

Display the next image



- images quickly.
 - To return to shooting mode, press the D button or shutter-release button.

The Quick Effects Function

- When OX: II is displayed in full-frame playback mode, you can press the 𝕺 button to apply an effect to the image.
- When the effect selection screen is displayed, use the multi selector ▲▼◀▶ to select an effect, press the ℗ button, and then select **Yes** in the confirmation dialog and press the ℗ button to save the image as a separate file.

See "Quick Effects: Changing Hue or Mood" (🖚14) for more information.




Step 6 Delete Images

1 Press the finibutton to delete the image currently displayed in the monitor.



- 2 Use the multi selector ▲▼ to select the desired deletion method and press the [®] button.
 - To exit without deleting, press the MENU button.



- Deleted images cannot be recovered.
- To cancel, select **No** and press the 🛞 button.





Operating the Erase Selected Images Screen

Use the multi selector ◀► to select an image to be deleted, and then use ▲ to display m.

- To undo the selection, press $oldsymbol{
 abla}$ to remove $oldsymbol{ ilde{m}}$.
- Move the zoom control (□1) toward T (Q) to switch to full-frame playback or W () to switch to thumbnail playback.



2 Add [™] to all images that you want to delete and then press the [™] button to confirm the selection.

A confirmation dialog is displayed. Follow the on-screen instructions to complete
operations.

V Deleting Images in a Sequence

- If you press the <u>m</u> button and delete a key picture while only key pictures are displayed for sequences of images (<u>D</u>69), all images in the sequence, including the key picture, are deleted.
- To delete individual images in a sequence, press the B button to display them one at a time and press the \fbox{D} button.

Deleting the Last Image Captured While in Shooting Mode

When using shooting mode, press the induction to delete the last image that was saved.

Shooting Features

🗺 (Scene Auto Selector) Mode

The camera automatically selects the optimum scene mode when you frame an image, making it even easier to take images using settings that suit the scene.

Enter shooting mode \rightarrow **D** (shooting mode) button \rightarrow **W** (scene auto selector) mode \rightarrow **W** button

When the camera selects a scene mode, the shooting mode icon displayed in the shooting screen changes to that for the scene mode currently enabled.

2*	Portrait (for taking close-up portraits of one or two people)
21	Portrait (for taking portraits of three or more people, or images in which a large background takes up the frame)
	Landscape
<u>e</u> t*	Night portrait (for taking close-up portraits of one or two people)
E ĩ	Night portrait (for taking portraits of three or more people, or images in which a large background takes up the frame)
*	Night landscape
	Close-up
2°91	Backlighting (for taking images of subjects other than people)
* 2)	Backlighting (for taking portrait images)
SEDE	Other scenes

Functions Available in 🚟 (Scene Auto Selector) Mode

- Flash mode (CC 47)
- Self-timer (1149)
- Exposure compensation (¹⁵²)

Scene Mode (Shooting Suited to Scenes)

When a scene is selected, camera settings are automatically optimized for the selected scene.

Enter shooting mode $\rightarrow \square$ (shooting mode) button $\rightarrow 2$ (second icon from the top*) $\rightarrow \triangleright \rightarrow \land \bigtriangledown \rightarrow$ select a scene $\rightarrow \textcircled{W}$ button

* The icon of the last scene selected is displayed.

Portrait (default setting)	Landscape ¹	💐 Sports ² (🎞 35)	Night portrait (CC 35)
Party/indoor ² (CC)35)	₽ Beach ²	₿ Snow ²	Sunset ^{2, 3}
當 Dusk/dawn ^{1, 3}	Night landscape ¹ (Щ36)	🗱 Close-up (🛄 36)	*1 Food (CC 36)
▲ Museum ² (□37)	Fireworks show ^{1, 3} (\$\Omega37\$)	Black and white copy ² (C37)	Backlighting ² (CC 37)
Easy panorama (C)38)	♥ Pet portrait (□□39)		

The camera focuses at infinity.

The camera focuses on the area in the center of the frame.

³ Use of a tripod is recommended, because the shutter speed is slow. Set **Photo VR** to **Off** in the setup menu (^{[[]}77)</sup> when using a tripod to stabilize the camera during shooting.

Displaying a Description of Each Scene Mode (Help Display)

Select a scene and move the zoom control (\square 1) toward **T** (**2**) to view a description of that scene. To return to the original screen, move the zoom control toward **T** (**2**) again.



Tips and Notes

💐 Sports

- While the shutter-release button is held all the way down, the camera shoots up to about 7 images continuously at a rate of about 2 fps (when image mode is set to **15**).
- The frame rate for continuous shooting may vary depending on the current image mode setting, the memory card used, or shooting conditions.
- Focus, exposure, and hue are fixed at the values determined with the first image in each series.

📓 Night portrait

- From the screen displayed after 📓 Night portrait is selected, select 🛱 Hand-held or 🗭 Tripod.
- 🛱 Hand-held (default setting):
 - When the elicon at the top left of the monitor glows green, press the shutter-release button all the way to capture a series of images which are combined into a single image and saved.
 - Once the shutter-release button is pressed all the way, hold the camera still until a still image is displayed. After taking an image, do not turn the camera off before the monitor switches to the shooting screen.
 - If the subject moves while the camera is shooting continuously, the image may be distorted, overlapped, or blurred.
- 🗭 Tripod:
 - One image is captured at a slow shutter speed when the shutter-release button is pressed all the way.
 - Vibration reduction is disabled even when **Photo VR** in the setup menu (277) is set to **On**.

X Party/indoor

• To avoid the effects of camera shake, hold the camera steady. Set **Photo VR** to **Off** in the setup menu (\square 77) when using a tripod to stabilize the camera during shooting.

🖬 Night landscape

- From the screen displayed after 📾 Night landscape is selected, select 🛱 Hand-held or 🗭 Tripod.
- 🛱 Hand-held (default setting):
 - When the explored icon at the top left of the monitor glows green, press the shutter-release button all the way to capture a series of images which are combined into a single image and saved.
 - Once the shutter-release button is pressed all the way, hold the camera still until a still image is displayed. After taking an image, do not turn the camera off before the monitor switches to the shooting screen.
 - The angle of view (i.e., the area visible in the frame) seen in the saved image is narrower than that seen in the monitor at the time of shooting.
- Tripod:
 - One image is captured at a slow shutter speed when the shutter-release button is pressed all the way.
 - Vibration reduction is disabled even when **Photo VR** in the setup menu (\square 77) is set to **On**.

🗱 Close-up

- Macro mode (¹₁51) is enabled and the camera automatically zooms to the closest position at which it can focus.
- You can move the focus area. Press the 𝕺 button, use the multi selector ▲▼◀► to move the focus area, and press the 𝚱 button to apply the setting.

#Food

- Macro mode (¹₁51) is enabled and the camera automatically zooms to the closest position at which it can focus.
- You can adjust hue by using the multi selector ▲▼. The hue setting is saved in the camera's memory even after the camera is turned off.



🏛 Museum

- The camera captures a series of up to ten images while the shutter-release button is held all the way down, and the sharpest image in the series is automatically selected and saved (BSS (Best Shot Selector)).
- The flash does not fire.

Fireworks show

- The shutter speed is fixed at four seconds.
- The zoom is restricted to four fixed positions.

Black and white copy

• Use together with macro mode (CD51) when shooting subjects that are close to the camera.

🖺 Backlighting

- From the screen displayed after Backlighting is selected, select ON or OFF to enable or disable the high dynamic range (HDR) function based on the type of image you want to take.
- OFF (default setting): The flash fires to prevent the subject from being hidden in shadow.
 - When the shutter-release button is pressed all the way down, one image is captured.
- ON: Use when taking images with very bright and dark areas in the same frame.
 - When the shutter-release button is pressed all the way, the camera shoots images continuously at high speed, and saves the following two images.
 - A non-HDR composite image
 - An HDR composite image in which the loss of details in highlights or shadows is minimized
 - If there is only enough memory to save one image, an image processed by D-Lighting (\$\overlime{1}68\$) at the time of shooting, in which dark areas of the image are corrected, is the only image saved.
 - Once the shutter-release button is pressed all the way, hold the camera still until a still image is displayed. After taking an image, do not turn the camera off before the monitor switches to the shooting screen.
 - The angle of view (i.e., the area visible in the frame) seen in the saved image is narrower than that seen in the monitor at the time of shooting.

🛱 Easy panorama

- From the screen displayed after ⊐ Easy panorama is selected, select the shooting range from S Normal (180°) or ⊐ Wide (360°).
- The zoom position is fixed at wide-angle.
- Press the shutter-release button all the way down, remove your finger from the button, and then slowly pan the camera horizontally. Shooting ends when the camera captures the specified shooting range.
- Focus and exposure are locked when shooting starts.
- If you press the
 Button when a captured image is displayed in full-frame playback mode, the
 image scrolls automatically.
- The images cannot be edited on this camera.

See "Using Easy Panorama (Shooting and Playback)" (🖚 2) for more information.

V Notes About Printing Panorama Images

The entire image may not be able to be printed depending on the printer's settings. Additionally, printing may not be possible depending on the printer.

🦋 Pet portrait


- When you point the camera at a dog or cat, the camera detects the pet's face and focuses on it. By default, the camera detects a dog or cat face and automatically releases the shutter (pet portrait auto release).
- On the screen displayed when 🦋 Pet portrait is selected, select 🔄 Single or 🖵 Continuous.
 - S Single: The camera captures one image when a dog or cat face is detected.
 - Continuous: The camera captures three images continuously when a dog or cat face is detected.

V Pet Portrait Auto Release

- Press the multi selector ◀ (ⓒ) to change the **Pet portrait auto release** setting.
 - 📓: The camera detects a dog or cat face and automatically releases the shutter.
 - **OFF**: The camera does not release the shutter automatically, even if a dog or cat face is detected. Press the shutter-release button. The camera also detects human faces when **OFF** is selected.
- Pet portrait auto release is set to OFF after five bursts have been taken.
- Shooting is also possible by pressing the shutter-release button, regardless of the Pet portrait auto release setting. When I Continuous is selected, you can take images continuously while holding down the shutter-release button all the way.

Focus Area

- When the camera detects a face, the face is displayed inside a yellow border. When the camera acquires focus on a face displayed inside a double border (focus area), the double border turns green. If no faces are detected, the camera focuses on the subject in the center of the frame.
- Under some shooting conditions, the pet face may not be detected and other subjects may be displayed inside a border.



Special Effects Mode (Applying Effects When Shooting)

Effects can be applied to images during shooting.

Enter shooting mode $\rightarrow \Box$ (shooting mode) button \rightarrow SO (third icon from the top*) $\rightarrow \rightarrow \Delta \nabla \rightarrow$ select an effect $\rightarrow @$ button

* The icon of the last effect selected is displayed.

Category	Description		
SO Soft* (default setting)	Softens the image by adding a slight blur to the entire image.		
SE Nostalgic sepia*	Adds a sepia tone and reduces the contrast to simulate the qualities of an old photograph.		
High-contrast monochrome	Changes the image to black and white and gives it sharp contrast.		
🔠 High key	Gives the entire image a bright tone.		
Low key	Gives the entire image a dark tone.		
Selective color	Creates a black and white image in which only the specified color remains.		
POP Pop	Increases the color saturation of the entire image to create a bright look.		
VI Super vivid	Increases the color saturation of the entire image and sharpens the contrast.		
🛱 Painting	Gives the image a painting-like appearance.		
1 Toy camera effect	Gives the entire image a yellowish hue and darkens the image periphery.		

Slider

Category	Description
10 Toy camera effect 2	Decreases the color saturation of the entire image and darkens the image periphery.
🕉 Cross process	Gives the image a mysterious appearance based on a specific color.
∮¤ Mirror*	Creates a bilaterally symmetric image whose right half is an inverted mirror image of the left half.

* Some effects are not available when using certain **Movie options** (¹⁷⁴) settings.

- The camera focuses on the area in the center of the frame.
- When Selective color or Cross process is selected, use the multi selector ▲▼ to select the desired color from the slider.

To change settings for any of the following functions, press the $\textcircled{\mathbf{W}}$ button to cancel color selection.

- Flash mode (CC 47)
- Self-timer (🛄 49)
- Macro mode (CC 51)
- Exposure compensation (CC 52)

To return to the color selection screen, press the $\textcircled{\ensuremath{\mathbb{O}}}$ button again.

1	[]	¢®
o	OK Save	

Smart Portrait Mode (Capturing Images of Smiling Faces)

When the camera detects a smiling face, you can take an image automatically without pressing the shutter-release button (smile timer (\square 57)). You can use the skin softening option to smooth the skin tones of human faces.

Enter shooting mode \rightarrow \square (shooting mode) button \rightarrow \boxdot Smart portrait \rightarrow M button

1 Frame the picture.

- Point the camera at a human face.
- **2** Without pressing the shutter-release button, wait for the subject to smile.
 - If the camera detects that the face framed by the double border is smiling, the shutter is automatically released.
 - Whenever the camera detects a smiling face, it automatically releases the shutter.

3 End automatic shooting.

- Perform one of the operations listed below to end shooting.
 - Set Smile timer to Off.
 - Press the 🖸 button and select a different shooting mode.

Notes About Smart Portrait Mode

Under some shooting conditions, the camera may be unable to detect faces or smiles (\square 61). The shutter-release button can also be used for shooting.

When the Self-timer Lamp Flashes

When using smile timer, the self-timer lamp flashes when the camera detects a face and flashes quickly immediately after the shutter is released.

Functions Available in Smart Portrait Mode

- Flash mode (CC 47)
- Self-timer (🛄 49)
- Exposure compensation (🛄 52)
- Smart portrait menu (CC 55)

🗖 (Auto) Mode

Used for general shooting. Settings can be adjusted to suit the shooting conditions and the type of shot you want to capture.

Enter shooting mode \rightarrow \square (shooting mode) button \rightarrow \square (auto) mode \rightarrow M button

You can change how the camera selects the area of the frame to focus on by changing the AF area mode setting (^{[[]})56).

The default setting is Target finding AF ($\square 63$).

Functions Available in 🖸 (Auto) Mode

- Flash mode (CC 47)
- Self-timer (🖽 49)
- Macro mode (CC 51)
- Exposure compensation (¹¹⁵²)
- Shooting menu (CC 55)

Using Quick Effects

When in (auto) mode, you can apply effects to images immediately after releasing the shutter.

- The edited image is saved as a separate file with a different name.
- 1 Press the 🛞 button when the image is displayed after it is taken in 🖸 (auto) mode.
 - When you press the **NENU** button or when no operations are performed for about five seconds, the monitor display returns to the shooting screen.
 - To not display the screen shown on the right, set **Quick** effects to Off in the shooting menu (CD55).




uper vivid

Ouick effects

2 Use the multi selector ▲▼◀▶ to select the desired effect and press the 🛞 button.

- Move the zoom control (□1) toward **T** (**Q**) to switch to full-frame playback or **W** (■) to switch to thumbnail playback.
- To exit without saving the edited image, press the MENU button. When a confirmation dialog is displayed, select Yes and press the OB button.



3 Select **Yes** and press the **®** button.

Notes About Quick Effects

The quick effects function is disabled when Wi-Fi is connected.

Functions That Can Be Set Using the Multi Selector

The functions that are available vary depending on the shooting mode, as shown below.



		يتي (scene auto selector)	Scene	Special effects	Smart portrait	🗖 (auto)
1	Flash mode (147)	~		~	✓*	~
2	👏 Self-timer (🖽 49)	~		~	✓*	~
3	Macro mode (CD51)	-	*	~	-	~
4	Exposure compensation (CD52)	~		~	~	~

* Availability depends on the setting.

Using the Flash

1


2

You can select a flash mode to match the shooting conditions.



The Flash Lamp

- The status of the flash can be confirmed by pressing the shutterrelease button halfway.
 - On: The flash fires when you press the shutter-release button all the way down.
 - Flashing: The flash is charging. The camera cannot shoot images.
 - Off: The flash does not fire when an image is taken.
- If the battery level is low, the monitor turns off while the flash is charging.



👌 (6400)

\$ AUTO

20

٤

\$ SLO

1080 50 16



Available Flash Modes

\$ AUTO	Auto
	The flash fires when necessary, such as in dim lighting.The flash mode icon on the shooting screen is displayed only immediately after the setting is made.
‡ ©	Auto with red-eye reduction
	Reduce "red-eye" in portraits caused by the flash.
٢	Off
	The flash does not fire.We recommend using a tripod to stabilize the camera when shooting in dark surroundings.
\$	Fill flash
	The flash fires whenever an image is taken. Use to "fill-in" (illuminate) shadows and backlit subjects.
\$ SLO₩	Slow sync
	Suited to evening and night portraits that include background scenery. The flash fires when necessary to illuminate the main subject; slow shutter speeds are used to capture

Interstand Mode Setting

• The setting may not be available with some shooting modes.

background at night or under dim lighting.

• The setting applied in 🖸 (auto) mode is saved in the camera's memory even after the camera is turned off.

🖉 Red-eye Reduction

If the camera detects red eye while saving an image, the affected area is processed to reduce red-eye before the image is saved.

Note the following when shooting:

- More time than usual is required to save images.
- Red-eye reduction may not produce the desired results in some situations.
- In some rare cases, red-eye reduction may be applied unnecessarily to other areas of the image. In these cases, select another flash mode and take the image again.

©10s

OFF

Using the Self-timer

1

The camera is equipped with a self-timer that releases the shutter about ten seconds or two seconds after you press the shutter-release button.

Set **Photo VR** to **Off** in the setup menu (277) when using a tripod to stabilize the camera during shooting.

2 Select 🖄 10s or 🕉 2s, and press the 🛞 button.

Press the multi selector \blacktriangleleft (\checkmark).

- (10s (ten seconds): Use on important occasions, such as weddinas.
- (32s (two seconds): Use to prevent camera shake.
- If a setting is not applied by pressing the 🛞 button within a few seconds, the selection will be canceled.
- When the shooting mode is **Pet portrait** scene mode, (pet portrait auto release) is displayed (239). The self-timer cannot be used.
- **3** Frame the picture and press the shutter-release button halfway.
 - · Focus and exposure are set.










4 Press the shutter-release button the rest of the way down.

- Countdown starts. The self-timer lamp flashes and then glows steadily about one second before the shutter is released.
- When the shutter is released, the self-timer is set to **OFF**.
- To stop the countdown, press the shutterrelease button again.





Using Macro Mode

1

Use macro mode when taking close-up images.

Press the multi selector $\mathbf{\nabla}$ ($\mathbf{\mathbf{X}}$). 2 Select ON and press the 🛞 button. • If the setting is not applied by pressing the 🕅 button within a few seconds, the selection will be canceled.

3 Move the zoom control to set the zoom ratio to a position where \bigotimes and the zoom indicator glow green.

 When the zoom ratio is set to a position where the zoom indicator glows green, the camera can focus on subjects as close as approximately 9 cm (3.6 in.) from the lens. When the zoom is at the position where \bigtriangleup is displayed, the camera can focus on subjects as close as approximately 2 cm (0.8 in.) from the lens.

Notes About Using the Flash

The flash may be unable to light the entire subject at distances of less than 50 cm (1 ft 8 in.).

I The Macro Mode Setting

- The setting may not be available with some shooting modes.
- The setting applied in 🗖 (auto) mode is saved in the camera's memory even after the camera is turned off.



0 N



Macro mode

Adjusting Brightness (Exposure Compensation)

You can adjust overall image brightness.

Press the multi selector ▶ (☑).



2 Select a compensation value and press the ® button.

- To brighten the image, set a positive (+) value.
- To darken the image, set a negative (-) value.
- The compensation value is applied, even without pressing the $\textcircled{\ensuremath{\mathbb{R}}}$ button.



Exposure Compensation Value

The setting applied in 🖸 (auto) mode is saved in the camera's memory even after the camera is turned off.

1

Default Settings

Default settings for each shooting mode are described below.

	Flash (🎞 47)	Self-timer (🎞49)	Macro (囗]51)	Exposure compensation (CD52)
🚾 (scene auto selector)	\$ AUTO ¹	Off	Off ²	0.0
Scene				
🔰 (portrait)	4 ®	Off	Off ³	0.0
🖬 (landscape)	\mathfrak{S}^3	Off	Off ³	0.0
💐 (sports)	\mathfrak{B}^3	Off ³	Off ³	0.0
🛋 (night portrait)	\$@ 4	Off	Off ³	0.0
💥 (party/indoor)	\$@ ⁵	Off	Off ³	0.0
😫 (beach)	\$ AUTO	Off	Off ³	0.0
৪ (snow)	\$ AUTO	Off	Off ³	0.0
🚔 (sunset)	\mathfrak{B}^3	Off	Off ³	0.0
🚔 (dusk/dawn)	(3) ³	Off	Off ³	0.0
🖬 (night landscape)	(3) ³	Off	Off ³	0.0
🗱 (close-up)	٤	Off	On ³	0.0
food)	\mathfrak{S}^3	Off	On ³	0.0
🏛 (museum)	() ³	Off	Off	0.0
(fireworks show)	(3) ³	Off ³	Off ³	0.0 ³
(black and white copy)	۲	Off	Off	0.0

	Flash (囗Ҵ47)	Self-timer (🎞49)	Macro (囗51)	Exposure compensation (
😰 (backlighting)	\$ ∕ € ⁶	Off	Off ³	0.0
🛱 (easy panorama)	$\textcircled{3}{2}$	Off ³	Off ³	0.0
🥩 (pet portrait)	\mathfrak{B}^3	5 7	Off	0.0
SO (special effects)	٢	Off	Off	0.0
速 (smart portrait)	\$ AUTO	Off	Off ³	0.0
🗖 (auto)	\$ AUTO	Off	Off	0.0

The camera automatically selects the flash mode appropriate for the scene it has selected. (3) (off) can be selected manually.

 2 Cannot be changed. The camera enters macro mode when ${\bf W}$ is selected.

³ The setting cannot be changed.

⁴ The setting cannot be changed. The flash mode setting is fixed at fill flash with red-eye reduction.

⁵ Slow sync with red-eye reduction flash mode may be used.

⁶ Flash is fixed at **‡** (fill flash) when **HDR** is set to **OFF**, and is fixed at **(**) (off) when **HDR** is set to **ON**.

 7 Self-timer cannot be used. Pet portrait auto release can be turned on or off ($\square 39$).

Functions That Can Be Set with the MENU Button (Shooting Menu)

The settings listed below can be changed by pressing the **MENU** button during shooting (CA).



The settings that can be changed vary depending on the shooting mode, as shown below.

	Scene auto selector	Scene ²	Special effects	Smart portrait	Auto mode
Image mode ¹	~	~	~	~	~
White balance	-	-	-	-	~
Continuous	-	-	-	-	~
ISO sensitivity	-	-	-	-	~
Color options	-	-	-	-	~
AF area mode	-	-	-	-	~
Autofocus mode	-	-	-	-	~
Quick effects	-	-	-	-	~
Skin softening	-	-	-	V	-
Smile timer	-	-	-	V	-
Blink proof	-	-	-	×	-

¹ The setting is also applied to other shooting modes.

² Additional settings are available for some scene modes. See "Tips and Notes" (¹³⁵) for more information.

Options Available in the Shooting Menu

Option	Description	
Image mode	 Allows you to set the combination of image size and image quality used when saving images. Default setting: 10 4608×3456 	6 34
White balance	Allows you to adjust white balance to suit the weather conditions or light source in order to make the colors in images match what you see with your eyes. • Default setting: Auto	æ 36
Continuous	Allows you to select single or continuous shooting. • Default setting: Single	6 39
ISO sensitivity	Allows you to control the camera's sensitivity to light. • Default setting: Auto When Auto is selected, SO is displayed in the monitor while shooting if ISO sensitivity increases.	6 42
Color options	Allows you to change the color tones of images. • Default setting: Standard color	60 43
AF area mode	Allows you to determine how the camera selects the focus area that is used for autofocus. • Default setting: Target finding AF (��63)	6-0 44
Autofocus mode	Allows you to select either Single AF , which focuses only when the shutter-release button is pressed halfway, or Full-time AF , which continues focusing even when the shutter-release button is not pressed halfway. • Default setting: Single AF	6-0 48
Quick effects	Allows you to enable or disable the quick effects function (CC45). • Default setting: On	6 48

Option	Description	
Skin softening	Allows you to select the skin softening level for human faces. Default setting: Normal 	6 49
Smile timer	Allows you to select whether or not the camera automatically releases the shutter when it detects a human smiling face. • Default setting: On (BSS)	~ 50
Blink proof	The camera automatically releases the shutter twice with every shot and saves one image in which the subject's eyes are open. • Default setting: Off	6 51

Functions That Cannot Be Used Simultaneously

Restricted function	Option	Description
	Continuous (🎞 56)	When a setting other than Single is selected, the flash cannot be used.
Flash mode	Blink proof (🎞 57)	When Blink proof is set to On , the flash cannot be used.
	Smile timer (🎞 57)	When On (continuous) or On (BSS) is selected, the flash cannot be used.
Self-timer	Smile timer (🎞 57)	When Smile timer is selected, the self-timer cannot be used.
	AF area mode (🎞 56)	When Subject tracking is selected, the self- timer cannot be used.
Macro mode	AF area mode (🎞 56)	When Subject tracking is selected, macro mode cannot be used.
lmage mode	Continuous (🎞 56)	 Image mode is set as follows depending on the continuous shooting setting: Continuous H: 120 fps: III (image size: 640 × 480 pixels) Continuous H: 60 fps: III (image size: 1280 × 960 pixels) Multi-shot 16: III (image size: 2560 × 1920 pixels)
White balance	Color options (🎞 56)	When Black-and-white , Sepia , or Cyanotype is selected, the White balance setting is fixed at Auto .

Restricted function	Option	Description
Continuous	Self-timer (🎞 49)	If the self-timer is used when Pre-shooting cache is selected, the setting is fixed at Single .
ISO sensitivity	Continuous (🎞 56)	When Pre-shooting cache, Continuous H: 120 fps, Continuous H: 60 fps, or Multi- shot 16 is selected, ISO sensitivity is fixed at Auto.
AF area mode	White balance (🎞 56)	When a setting other than Auto is selected for White balance in Target finding AF mode, the camera does not detect the main subject.
Quick effects	Continuous (🎞 56)	The quick effects function cannot be used for images with continuous shooting.
Smile timer	Blink proof (🎞 57)	When Blink proof is set to On, Smile timer is fixed at On (single) if On (continuous) or On (BSS) is set.
Blink proof	Smile timer (🎞 57)	When Smile timer is set to On (continuous) or On (BSS), Blink proof is fixed at Off.
Monitor settings	Quick effects (🛄 56)	When Quick effects is set to On while shooting still images, the captured image is displayed after shooting, regardless of the Image review setting.
Print date	Continuous (🎞 56)	When Pre-shooting cache, Continuous H: 120 fps , or Continuous H: 60 fps is selected, date and time cannot be imprinted on images.

Restricted function	Option	Description
Motion detection	Continuous (🎞 56)	When a setting other than Single is selected, Motion detection is disabled.
	ISO sensitivity (🎞 56)	When the ISO sensitivity is set to any setting other than Auto , Motion detection is disabled.
	AF area mode (🎞 56)	When Subject tracking is selected, Motion detection is disabled.
	Smile timer (🎞 57)	When On (continuous) or On (BSS) is selected, Motion detection is disabled.
Blink warning	Continuous (🎞 56)	When a setting other than Single is selected, Blink warning is disabled.
Digital zoom	Continuous (🎞 56)	When Multi-shot 16 is selected, digital zoom cannot be used.
Digital zoom	AF area mode (🎞 56)	When Subject tracking is selected, digital zoom cannot be used.
Shutter sound	Continuous (🎞 56)	When a setting other than Single is selected, the shutter sound is disabled.

Notes About Digital Zoom

- Depending on the shooting mode or the current settings, digital zoom may not be available (
- When digital zoom is in effect, the camera focuses in the center of the frame.


Focusing

The focus area varies depending on the shooting mode.

Using Face Detection

In the following shooting modes, the camera uses face detection to automatically focus on human faces.

- Z / Z Portrait, C / C Night portrait, or C Backlighting in C (scene auto selector) mode (32)
- Portrait or Night portrait scene mode (234)
- Smart portrait mode (QQ42)
- When **AF area mode** (156) in 1 (auto) mode (144) is set to **Face priority**.



If the camera detects more than one face, a double border is displayed around the face that the camera focuses on, and single borders are displayed around the other faces.

If the shutter button is pressed halfway when no faces are detected:

- In m (scene auto selector) mode, the focus area changes depending on the scene.
- In Portrait and Night portrait scene modes or in smart portrait mode, the camera
 focuses in the center of the frame.
- In a (auto) mode, the camera selects the focus area containing the subject closest to the camera.

Notes About Face Detection

- The camera's ability to detect faces depends on a variety of factors, including the direction in which the faces are looking.
- The camera may be unable to detect faces in the following situations:
 - When faces are partially hidden by sunglasses or otherwise obstructed
 - When faces take up too much or too little of the frame

Using Skin Softening

When the shutter is released while using one of the shooting modes listed below, the camera detects human faces and processes the image to soften facial skin tones (up to three faces).

- Smart portrait mode (¹/₄₂)
 - The skin softening level can be adjusted.
- Z Portrait, IN Night portrait, or Backlighting in (scene auto selector) mode (
 (
 32)
- Portrait or Night portrait scene mode (
 34)

Editing functions such as **Skin softening** can be applied to saved images by using **Glamour retouch** (\square 68) even after shooting.


Notes About Skin Softening

- It may take more time than usual to save images after shooting.
- Under some shooting conditions, the desired skin softening results may not be achieved, and skin softening may be applied to areas of the image where there are no faces.


Using Target Finding AF

When **AF area mode** (^(C)56) in **(**(auto) mode is set to **Target finding AF**, the camera focuses in the manner described below when you press the shutter-release button halfway.

• The camera detects the main subject and focuses on it. When the subject is in focus, the focus area glows green. If a human face is detected, the camera automatically sets focus priority on it.



Focus areas



If no main subject is detected, the camera automatically selects one or more of the nine focus areas containing the subject closest to the camera. When the subject is in focus, the focus areas that are in focus glow green.

Notes About Target Finding AF

- Depending on shooting conditions, the subject that the camera determines to be the main subject may vary.
- The main subject may not be detected when using certain White balance settings.
- The camera may not detect the main subject appropriately in the following situations:
 - When the subject is very dark or bright
 - When the main subject lacks clearly defined colors
 - When the shot is framed so that the main subject is at the edge of the monitor
 - When the main subject is composed of a repeating pattern

Subjects Not Suitable for Autofocus

The camera may not focus as expected in the following situations. In some rare cases, the subject may not be in focus despite the fact that the focus area or the focus indicator glows green:

- Subject is very dark
- Objects of sharply differing brightness are included in the scene (e.g. the sun behind the subject makes that subject appear very dark)
- No contrast between the subject and surroundings (e.g. a portrait subject wearing a white shirt is standing in front of a white wall)
- Several objects are at different distances from the camera (e.g. the subject is inside a cage)
- Subjects with repeating patterns (window blinds, buildings with multiple rows of similarly shaped windows, etc.)
- Subject is moving rapidly

In the situations noted above, try pressing the shutter-release button halfway to refocus several times, or focus on another subject positioned at the same distance from the camera as the actual desired subject, and use focus lock (\square 65).

Focus Lock

Focus lock shooting is recommended when the camera does not activate the focus area that contains the desired subject.

1 Set **AF area mode** to **Center** in **D** (auto) mode (D)55).

- **2** Position the subject in the center of the frame and press the shutterrelease button halfway.
 - The camera focuses on the subject and the focus area glows green.
 - Focus and exposure are locked.
- 3 Without lifting your finger, recompose the picture.
 - Make sure to maintain the same distance between the camera and the subject.
- **4** Press the shutter-release button the rest of the way down to take the picture.












Playback Features

Playback Zoom

Moving the zoom control toward $\mathbf{T}(\mathbf{Q})$ in full-frame playback mode ($\mathbf{\square}28$) zooms in on the image.



Displayed area guide

Image is zoomed in.

- You can change the zoom ratio by moving the zoom control toward \mathbf{W} (\mathbf{E}) or \mathbf{T} (\mathbf{Q}).
- To view a different area of the image, press the multi selector $\mathbf{A} \nabla \mathbf{A}$
- If you are viewing an image that was captured using face detection or pet detection, the camera zooms in on the face detected at the time of shooting (except when viewing an image captured in a series). To zoom in on an area of the image where there are no faces, adjust the magnification rate and then press $\mathbf{A} \mathbf{\nabla} \mathbf{\Phi}$.
- When a zoomed image is displayed, press the 🕅 button to return to full-frame playback mode.

Cropping Images

When a zoomed image is displayed, you can press the **MENU** button to crop the image to include only the visible portion and save it as a separate file (#21).

Thumbnail Playback/Calendar Display

Moving the zoom control toward **W** () in full-frame playback mode (28) displays images as thumbnails.



- You can change the number of thumbnails displayed by moving the zoom control toward W () or T (Q).
- While using calendar display mode, press A V + to select a date and then press the B button to display the images captured on that day.

Notes About Calendar Display

Images captured when the camera's date is not set are treated as images captured on January 1, 2014.

Functions That Can Be Set with the MENU Button (Playback Menu)

When viewing images in full-frame playback mode or thumbnail playback mode, you can configure the menu operations listed below by pressing the **MENU** button (\square 4).

Option	Description	
Quick retouch*	Allows you to create retouched copies in which contrast and saturation have been enhanced.	6 16
D-Lighting*	Allows you to create copies with enhanced brightness and contrast, brightening dark portions of an image.	6 16
Red-eye correction*	Corrects "red-eye" that may occur in images when shooting with a flash.	6 17
Glamour retouch*	Detects faces in images and retouches the detected faces glamorously.	6 18
Print order	Allows you to select which images are printed, and how many copies of each image are printed, prior to printing.	6 52
Slide show	Allows you to view images in an automatic slide show.	6 56
Protect	Protects selected images from accidental deletion.	66 57
Rotate image	Allows you to rotate the displayed image to portrait or landscape orientation.	6 59
Small picture*	Creates a small copy of images.	6 20
Voice memo	Allows you to use the camera's microphone to record voice memos and attach them to images.	6 0

Option	Description	
Сору	Allows you to copy images between the internal memory and a memory card.	6 61
Sequence display options	 Allows you to select whether to display only the key picture for a sequence of images captured continuously or to display the sequence as individual images. When only the key picture is displayed for a sequence, press the	€ 63
Choose key picture	Allows you to change the key picture for images captured in sequence.	6 63
Favorite pictures	Allows you to add images to an album. This option is not displayed in favorite pictures mode.	6 6
Remove from favorites	Allows you to remove images from an album. This option is displayed only in favorite pictures mode.	20 8

* Edited images are saved as separate files. Some images may not be edited.

Recording and Playing Back Movies

Recording Movies

1 Display the shooting screen.

- Check the remaining amount of movie recording time.
- If Photo info in the Monitor settings in the setup menu (
 (
 77) is set to Movie frame+auto info, the area that will be visible in the movie can be confirmed before movie recording starts.



Movie recording time remaining

2 Press the ● (* movie-record) button to start movie recording.

- The camera focuses in the center of the frame.
- A still image can be captured during movie recording (⁽¹⁷³⁾).

Press the \bigcirc (🐙 movie-record) button again to end recording.





70

3

Maximum Movie Length

Individual movie files cannot exceed 4 GB in size or 29 minutes in length, even when there is sufficient free space on the memory card for longer recording.

- The maximum movie length for a single movie is displayed on the shooting screen.
- Recording may end before either limit is reached if camera temperature becomes elevated.
- The actual movie length may vary depending on the movie content, subject movement, or type of memory card.

Notes About Saving Images and Recording Movies

The indicator showing the number of exposures remaining or the indicator showing the maximum movie length flashes while images are being saved or while a movie is being recorded. **Do not open the battery-chamber/memory card slot cover or remove the battery or memory card** while an indicator is flashing. Doing this could result in loss of data, or in damage to the camera or the memory card.

Notes About Movie Recording

- Memory cards with an SD Speed Class rating of 6 or faster are recommended when recording movies (22). Movie recording may stop unexpectedly when memory cards with a lower Speed Class rating are used.
- There may be some degradation in image quality when digital zoom is used.
- The sounds of zoom control operation, zoom, autofocus lens drive movement, movie vibration reduction, and aperture operation when brightness changes may be recorded.
- The following phenomena may be seen in the monitor while recording movies. These phenomena are saved in the recorded movies.
 - Banding may occur in images under fluorescent, mercury-vapor, or sodium-vapor lighting.
 - Subjects that move quickly from one side of the frame to the other, such as a moving train or car, may appear skewed.
 - The entire movie image may be skewed when the camera is panned.
 - Lighting or other bright areas may leave residual images when the camera is moved.
- Depending on the distance to the subject or the amount of zoom applied, subjects with repeating patterns (fabrics, lattice windows, etc.) may have colored stripes (interference patterns, moire, etc.) in them during movie recording and playback. This occurs when the pattern in the subject and the layout of the image sensor interfere with each other; it is not a malfunction.

V Notes About Vibration Reduction During Movie Recording

- When **Movie VR** in the movie menu (¹¹⁷⁴) is set to **On (hybrid)**, the angle of view (i.e., the area visible in the frame) becomes narrower during movie recording.
- In special effects mode, only lens shift VR is used to compensate for camera shake when Movie options is set to 100 in 1080/60i (100 in 1080/50i), even if Movie VR is set to On (hybrid).
- When using a tripod to stabilize the camera during shooting, set **Movie VR** to **Off** to prevent potential errors caused by this function.

Notes About Camera Temperature

- The camera may become hot when shooting movies for an extended period of time or when the camera is used in a hot area.
- If the inside of the camera becomes extremely hot when recording movies, the camera will
 automatically stop recording.

The amount of time remaining until the camera stops recording (@10s) is displayed. After the camera stops recording, it turns itself off.

Leave the camera off until the inside of the camera has cooled.

Notes About Autofocus for Movie Recording

Autofocus may not perform as expected (CC64). Should this occur, try the following:

- Set Autofocus mode in the movie menu to Single AF (default setting) before starting movie recording.
- 2. Frame another subject (positioned at the same distance from the camera as the intended subject) in the center of the frame, press the (* movie-record) button to start recording, and modify the composition.

Capturing Still Images While Recording Movies

If the shutter-release button is pressed all the way while recording a movie, one frame is saved as a still image. Movie recording continues while the still image is being saved.

- (a) is displayed at the top left of the monitor. When 🕲 is displayed, still images cannot be captured.
- The size of the captured image varies depending on the **Movie options** setting (74).




Notes About Capturing Still Images During Movie Recording

- Still images cannot be captured during a movie recording in the following situations:
 - When the remaining movie recording time is less than 30 seconds
 - When Movie options is set to 1000 in 1080/60i (1000 in 1080/50i) or HS movie
- Frames of a movie that were recorded when a still image was being taken may not be played back in a seamless manner.
- The sound of pressing the shutter-release button may be recorded in the movie.
- If the camera moves when the shutter-release button is pressed, the image may be blurred.

Functions That Can Be Set with the MENU Button (Movie Menu)

Enter shooting mode \rightarrow MENU button \rightarrow \clubsuit menu icon \rightarrow \circledast button

The settings of the menu options listed below can be configured.




Option	Description	
Movie options	Select the movie type. Select normal speed to record movies at normal speed, or HS (high speed) to record movies that play in slow or fast motion. • Default setting: 1080/30p (1080/25p)	6 64
Open with HS footage	Set whether to start recording at high speed or normal speed when recording HS movies. • Default setting: On	æ 68
Autofocus mode	Select either Single AF , which locks focus when movie recording begins, or Full-time AF , which continues focusing during movie recording. • Default setting: Single AF	€68
Movie VR	Select the vibration reduction setting used when recording movies. • Default setting: On (hybrid)	6 9
Wind noise reduction	Set whether or not to reduce wind noise during movie recording. • Default setting: Off	6 70
Frame rate	Select the frame rate for recording movies based on the setting of the TV used for playing back movies. • NTSC: 30 fps (30p/60i) • PAL: 25 fps (25p/50i)	60 70

Playing Back Movies

Press the **>** button to enter playback mode. Movies are indicated by the movie options icon (274). Press the 🕑 button to play back movies.

• To adjust the volume, move the zoom control while a movie is playing (\square 1).



Volume indicator

Operation During Movie Playback

Playback controls are displayed at the bottom of the monitor. The operations listed below can be performed by using the multi selector \blacktriangleleft to select a control and then pressing the W button.



Function	lcon	Description		
Rewind	*	Hold down the 欧 button to rewind the movie.		
Advance	*	Hold down the ${f tell}$ button to advance the movie.		
Pause		Pause playback. The operations listed below can be performed while paused.		
		√	Rewind the movie one frame. Hold down the 🞯 button for continuous rewinding.	
		₩	Advance the movie one frame. Hold down the 🔞 button for continuous advancing.	
			Resume playback.	
		5	Extract the desired portion of a movie and save it as a separate file.	
End		Return to full-frame playback mode.		

Deleting Movies

To delete a movie, select the desired movie in full-frame playback mode (\$\box\$28) or thumbnail playback mode (\$\box\$26) and press the \$\vec{m}\$ button (\$\box\$30).

General Camera Setup

Functions That Can Be Set with the MENU Button (Setup Menu)

Press the MENU button \rightarrow Υ (setup) menu icon \rightarrow M button

The settings of the menu options listed below can be configured.



Option	Description	
Welcome screen	Allows you to select whether or not the welcome screen is displayed when the camera is turned on.	6 73
Time zone and date	Allows you to set the camera clock.	66 74
Monitor settings	Allows you to adjust photo information display, post-shooting image review, and monitor brightness settings.	60 76
Print date	Allows you to imprint the shooting date and time on images.	66 78
Photo VR	Allows you to select the vibration reduction setting used when shooting still images.	6-0 79
Motion detection	Allows you to set whether or not the camera reduces blurring caused by camera shake if motion is detected when shooting still images.	6 80

General Camera Setup

Option	Description	
AF assist	Allows you to enable or disable the AF-assist illuminator.	66 81
Digital zoom	Allows you to enable and disable digital zoom.	6 81
Sound settings	Allows you to adjust sound settings.	6 82
Auto off	Allows you to set the amount of time that passes before the monitor turns off to save power.	6 82
Format memory/ Format card	Allows you to format the internal memory or the memory card.	€€ 83
Language	Allows you to change the camera's display language.	6 84
TV settings	Allows you to adjust TV-connection settings.	6 84
Charge by computer	Allows you to set whether or not the battery in the camera is charged when the camera is connected to a computer.	↔ 85
Blink warning	Allows you to set whether or not closed eyes are detected when taking images of people using face detection.	~ 86
Eye-Fi upload	Allows you to set whether or not to enable the function for sending images to a computer using a commercially available Eye-Fi card.	6 87
Reset all	Allows you to reset the camera's settings to their default values.	€ 88
Firmware version	View the current camera firmware version.	~~ 88

Using the Wi-Fi (Wireless LAN) Function

Functions That Can Be Performed Using Wi-Fi

You can perform the following functions if you install the dedicated software "Wireless Mobile Utility" on your smart device that runs on Android OS or iOS, and connect it to the camera.

Take Photos

You can take still images using the two methods described below.

- Release the shutter on the camera and save the captured images to a smart device.
- Use a smart device to remotely* release the camera shutter and save images to the smart device.
 - * Operations cannot be performed on the camera during remote control operation.

View Photos

You can copy the images saved in the camera's memory card and view them on your smart device.

Installing the Software on the Smart Device

- 1 Use your smart device to connect to Google Play Store, App Store or other online apps marketplace and search for "Wireless Mobile Utility."
 - Check the user's manual provided with your smart device for further details.

2 Check the description and other information and install the software.

- For more information about how to operate the software, download the user's manual from the website below.
 - Android OS: http://nikonimglib.com/ManDL/WMAU/
 - iOS: http://nikonimglib.com/ManDL/WMAU-ios/

Connecting the Smart Device to the Camera

Press the MENU button \rightarrow (T°) menu icon \rightarrow (W) button

- When the Wi-Fi function is turned on, the SSID and password of the camera are displayed.
- If no connection confirmation is received from the smart device within 3 minutes, the message "No access." is displayed and the camera returns to the Wi-Fi options screen.



2 Set the Wi-Fi setting on the smart device to On.

- · Check the user's manual provided with your smart device for further details.
- After the network name (SSID) that can be used for the smart device is displayed, select the SSID displayed on the camera.
- When the message for entering a password is displayed, enter the password that is displayed on the camera.
- When the camera is successfully connected to a Wi-Fi network, the shooting screen is displayed on the camera with the Wi-Fi communication indicator (¹).

3 Start the "Wireless Mobile Utility" installed on the smart device.

- The screen for selecting "Take photos" or "View photos" is displayed.
- When the message "Cannot connect to camera." is displayed, return to step 1 and retry the procedure.

To Terminate the Wi-Fi Connection

Perform one of the following operations.

- Turn off the camera.
- Select Disable Wi-Fi in the Wi-Fi options menu on the camera (except when the camera is operated by remote control).
- Set the Wi-Fi setting on the smart device to Off.

Notes About Wi-Fi Connection

- Connect to smart device cannot be selected in the following situations:
 - When no memory card is inserted in the camera
 - When an Eye-Fi card (+87) is inserted in the camera
 - When the camera is connected to a TV, computer, or printer.
 - When the battery level indicator in the monitor indicates (I). In addition, if (I) is indicated when Wi-Fi is connected, the connection is terminated.
- Select Disable Wi-Fi in a place where the use of radio waves is prohibited.
- When Wi-Fi is connected, Auto off is disabled.
- When Wi-Fi is connected, the battery drains faster than normal.


Notes About Security Settings

If the camera is installed with the Wi-Fi function without proper security settings (encryption and password), unauthorized third parties may access the network and cause harm. We strongly recommend performing the required security settings before using the Wi-Fi function. Use **Options** of the Wi-Fi options menu (71) to perform the security settings.

Connecting the Camera to a TV, Computer, or Printer

Connection Methods

You can enhance your enjoyment of images and movies by connecting the camera to a TV, computer, or printer.



- If the AC Adapter EH-62G (available separately) is used, this camera can be powered from an electrical outlet. Do not use any other make or model of AC adapter as it may cause the camera to heat up or malfunction.
- For information about the connection methods and subsequent operations, refer to the documentation included with the device in addition to this document.



Images and movies captured with the camera can be viewed on a TV. Connection method: Connect a commercially available HDMI cable to the TV's HDMI input jack.

Viewing and organizing images on a computer



You can transfer images to a computer to perform simple retouching and manage image data.

Connection method: Connect the camera to the computer's USB port with the USB cable

- Before connecting to a computer, install ViewNX 2 on the computer $(\square 85).$
- If any USB devices that draw the power from the computer are connected. disconnect them from the computer before you connect the camera to it. Connecting the camera and other USB-powered devices to the same computer simultaneously may cause a camera malfunction or excessive power supply from the computer, which could damage the camera or memory card.

Printing images without using a computer

6025

A 22



If you connect the camera to a PictBridge-compatible printer, you can print images without using a computer.

Connection method: Connect the camera directly to the printer's USB port with the USB cable

Using ViewNX 2

Install ViewNX 2 to upload, view, edit, and share photos and movies.



Installing ViewNX 2

An Internet connection is required.

For system requirements and other information, see the Nikon website for your region.

1 Start the computer and download the ViewNX 2 installer from the URL below.

http://nikonimglib.com/nvnx/

2 Double-click the installer file.

3 Follow the on-screen instructions to install the software.

4 Exit the install.

- Windows: Click **Yes**.
- Mac: Click OK.


Transferring Images to the Computer

1 Choose how images will be copied to the computer.

Choose one of the following methods:

• Direct USB connection: Turn the camera off and ensure that the memory card is inserted in the camera. Connect the camera to the computer using the USB cable. The camera automatically turns on.

To transfer images that are saved in the camera's internal memory, remove the memory card from the camera before connecting it to the computer.



- **SD card slot**: If your computer is equipped with an SD card slot, the card can be inserted directly in the slot.
- **SD card reader**: Connect a card reader (available separately from third-party suppliers) to the computer and insert the memory card.

If a message is displayed prompting you to choose a program, select Nikon Transfer 2.

• When using Windows 7

If the dialog shown at right is displayed, follow the steps below to select Nikon Transfer 2.

 Under Import pictures and videos, click Change program. A program selection dialog will be displayed; select Import File using Nikon Transfer 2 and click OK.



2 Double-click Import File.

If the memory card contains a large number of images, it may take a while for Nikon Transfer 2 to start. Wait until Nikon Transfer 2 starts.

Connecting the USB Cable

The connection may not be recognized if the camera is connected to the computer via a USB hub.

2 Transfer images to the computer.

• Click Start Transfer.



• At default settings, all the images on the memory card will be copied to the computer.

3 Terminate the connection.

If the camera is connected to the computer, turn the camera off and disconnect the USB
cable. If you are using a card reader or card slot, choose the appropriate option in the
computer operating system to eject the removable disk corresponding to the memory card
and then remove the card from the card reader or card slot.

Viewing Images

Start ViewNX 2.

- Images are displayed in ViewNX 2 when transfer is complete.
- Consult online help for more information on using ViewNX 2.



Starting ViewNX 2 Manually

- Windows: Double-click the ViewNX 2 shortcut on the desktop.
- Mac: Click the ViewNX 2 icon in the Dock.



Technical Notes and Index

The Camera 0:2 The Battery 0:3 Charging AC Adapter 0:4 Memory Cards 0:5 Cleaning and Storage 0:6 Cleaning 0:6 Storage 0:6 Troubleshooting 0:7 Specifications 0:17 Approved Memory Cards 0:22 Index 0:25	Caring for the Product	ò́-2
Charging AC Adapter		
Charging AC Adapter	The Battery	ò;-3
Memory Cards	Charging AC Adapter	ò-4
Cleaning	Memory Cards	ò ⁻ 5
Cleaning	Cleaning and Storage	
Storage	Cleaning	¢-6
Specifications	Storage	¢-6
Specifications	Troubleshooting	
Approved Memory Cards		
	 Approved Memory Cards 	

Caring for the Product

The Camera

To ensure continued enjoyment of this Nikon product, observe the precautions described below in addition to the warnings in "For Your Safety" (\Box viii-x) when using or storing the device.

Do Not Drop

The product may malfunction if subjected to strong shock or vibration.

Handle the Lens and All Moving Parts with Care

Do not apply force to the lens, lens cover, monitor, memory card slot, or battery chamber. These parts are easily damaged. Applying force to the lens cover could result in camera malfunction or damage to the lens. Should the monitor break, care should be taken to avoid injury caused by broken glass and to prevent the liquid crystal from the display touching the skin or entering the eyes or mouth.

Keep Dry

The device will be damaged if immersed in water or subjected to high humidity.

V Avoid Sudden Changes in Temperature

Sudden changes in temperature, such as when entering or leaving a heated building on a cold day, can cause condensation to form inside the device. To prevent condensation, place the device in a carrying case or a plastic bag before exposing it to sudden changes in temperature.

Keep Away from Strong Magnetic Fields

Do not use or store this device in the vicinity of equipment that generates strong electromagnetic radiation or magnetic fields. Strong static charge or the magnetic fields produced by equipment such as radio transmitters could interfere with the monitor, damage data saved on the memory card, or affect the product's internal circuitry.

Do Not Point the Lens at Strong Light Sources for Extended Periods

Avoid pointing the lens at the sun or other strong light sources for extended periods when using or storing the camera. Intense light may cause deterioration of the image sensor, producing a white blur effect in photographs.

V Turn the Product Off Before Removing or Disconnecting the Power Source or Memory Card

Do not remove the battery while the product is on, or while images are being saved or deleted. Forcibly cutting power in these circumstances could result in loss of data or in damage to product memory or internal circuitry.

Notes About the Monitor

- Monitors and electronic viewfinders are constructed with extremely high precision; at least 99.99%
 of pixels are effective, with no more than 0.01% being missing or defective. Hence while these
 displays may contain pixels that are always lit (white, red, blue, or green) or always off (black), this is
 not a malfunction and has no effect on images recorded with the device.
- Images in the monitor may be difficult to see under bright lighting.
- The monitor is lit by an LED backlight. Should the monitor begin to dim or flicker, contact your Nikon-authorized service representative.

The Battery

Be sure to read and follow the warnings in "For Your Safety" (QViii-x) before use.

- Check the battery level before using the camera and replace or charge the battery if necessary. Do not continue charging once the battery is fully charged as this will result in reduced battery performance. Whenever possible, carry a fully charged spare battery when taking images on important occasions.
- Do not use the battery at ambient temperatures below 0°C (32°F) or above 40°C (104°F).
- Charge the battery indoors with an ambient temperature of 5°C to 35°C (41°F to 95°F) before use.
- When charging the battery inserted into this camera using the Charging AC Adapter or a computer, the battery is not charged at battery temperatures below 0°C (32°F) or above 45°C (113°F).

- Note that the battery may become hot during use; wait for the battery to cool before charging. Failure to observe these precautions could damage the battery, impair its performance, or prevent it from charging normally.
- On cold days, the capacity of batteries tends to decrease. If an exhausted battery is used at a low
 temperature, the camera will not turn on. Be sure that the battery is fully charged before heading
 outside to take images in cold weather. Keep spare batteries in a warm place and exchange as
 necessary. Once warmed, a cold battery may recover some of its charge.
- Dirt on the battery terminals can prevent the camera from functioning. Should the battery terminals become dirty, wipe them off with a clean, dry cloth before use.
- If the battery will not be used for some time, insert it in the camera and completely exhaust it before removing it for storage. The battery should be stored in a cool location with an ambient temperature of 15°C to 25°C (59°F to 77°F). Do not store the battery in hot or extremely cold locations.
- Always remove the battery from the camera or optional battery charger when it is not being used. When inserted, minute amounts of current are drawn from the battery even when not in use. This may result in excessive draining of the battery and complete loss of function. Turning the camera on or off while the battery is exhausted can result in reduced battery life.
- Recharge the battery at least once every six months and completely exhaust it before returning it to storage.
- After removing the battery from the camera or optional battery charger, put the battery in a plastic bag, etc. in order to insulate it and store it in a cool place.
- A marked drop in the time a fully charged battery retains its charge, when used at room temperature, indicates that the battery needs to be replaced. Purchase a new EN-EL19 battery.
- Replace the battery when it no longer holds a charge. Used batteries are a valuable resource. Please recycle used batteries in accordance with local regulations.

Charging AC Adapter

Be sure to read and follow the warnings in "For Your Safety" (Quviii-x) before use.

- The Charging AC Adapter EH-71P is for use only with compatible devices. Do not use with another make or model of device.
- Do not use a USB cable other than the UC-E21. Using a USB cable other than the UC-E21 could result in overheating, fire or electric shock.

- The EH-71P is compatible with AC 100-240 V, 50/60 Hz electrical outlets. When using in other countries, use a plug adapter (commercially available) as necessary. For more information about plug adapters, consult your travel agency.
- Do not, under any circumstances, use another make or model of AC adapter other than Charging AC Adapter EH-71P, and do not use a commercially available USB-AC adapter or a battery charger for a mobile phone. Failure to observe this precaution could result in overheating or in damage to the camera.

Memory Cards

- Use only Secure Digital memory cards. See "Approved Memory Cards" (22) for recommended memory cards.
- Be sure to follow the precautions described in the documentation included with the memory card.
- Do not put labels or stickers on memory cards.
- The first time you insert a memory card that has been used in another device into this camera, be sure to format it with this camera. We recommend formatting new memory cards with this camera before using them with this camera.
- Note that formatting a memory card permanently deletes all images and other data on the memory card. Be sure to make copies of any images you wish to keep before formatting the memory card.
- If the message Card is not formatted. Format card? is displayed when the camera is turned on, the memory card must be formatted. If there is data that you do not want to delete, select No. Copy the necessary data to a computer, etc. If you want to format the card, select Yes. The confirmation dialog will be displayed. To start formatting, press the ^(M) button.
- Do not perform the following during formatting, while data is being written to or deleted from the memory card, or during data transfer to a computer. Failure to observe this precaution could result in the loss of data or in damage to the camera or memory card:
 - Open the battery-chamber/memory card slot cover to remove/insert the battery or memory card.
 - Turn off the camera.
 - Disconnect the AC adapter.
- Do not format the memory card using a computer.

Cleaning and Storage

Cleaning

Do not use alcohol, thinner, or other volatile chemicals.

Lens	Avoid touching glass parts with your fingers. Remove dust or lint with a blower (typically a small device with a rubber bulb attached to one end that is pumped to produce a stream of air out the other end). To remove fingerprints or other stains that cannot be removed with a blower, wipe the lens with a soft cloth, using a spiral motion that starts at the center of them and working toward the edges. If this fails, clean the lens using a cloth lightly dampened with commercial lens cleaner.
Monitor Remove dust or lint with a blower. To remove fingerprints and other stair monitor with a soft, dry cloth, being careful not to apply pressure.	
Body	Use a blower to remove dust, dirt, or sand, then wipe gently with a soft, dry cloth. After using the camera at the beach or other sandy or dusty environment, wipe off any sand, dust, or salt with a dry cloth lightly dampened with fresh water and dry thoroughly. Note that foreign matter inside the camera could cause damage not covered by the warranty.

Storage

Turn the camera off when not in use. Be sure that the power-on lamp is off before putting the camera away. Remove the battery if the camera will not be used for an extended period. Do not store the camera with naphtha or camphor moth balls, or in any of the following locations:

- Next to equipment that produces strong electromagnetic fields, such as televisions or radios
- Exposed to temperatures below –10°C (14°F) or above 50°C (122°F)
- Places that are poorly ventilated or subject to humidity of over 60%

To prevent mold or mildew, take the camera out of storage at least once a month. Turn the camera on and release the shutter a few times before putting the camera away again. For storing the battery, follow the precautions in "The Battery" (23) in "Caring for the Product" (22).

Troubleshooting

If the camera fails to function as expected, check the list of common problems below before consulting your retailer or Nikon-authorized service representative.

Power, Display, Settings Issues

Problem	Cause/Solution	m
The camera is on but does not respond.	Wait for recording to end. If the problem persists, turn the camera off. If the camera does not turn off, remove and reinsert the battery or batteries or, if you are using an AC adapter, disconnect and reconnect the AC adapter. Note that although any data currently being recorded will be lost, data that have already been recorded will not be affected by removing or disconnecting the power source.	20, 🏞 95
Battery inserted in the camera cannot be charged.	 Confirm all connections. When connected to a computer, the camera may not charge for any of the reasons described below. Off is selected for Charge by computer in the setup menu. Battery charging stops if the camera is turned off. Battery charging is not possible if the camera's display language and date and time have not been set, or the date and time were reset after the camera's clock battery was exhausted. Use the Charging AC Adapter to charge the battery. Battery charging may stop if the computer is in sleep mode. Depending upon the computer specifications, settings, and status, battery charging may not be possible. 	12 78, 6 85 - 16, 18 - -

Problem	Cause/Solution	
The camera cannot be turned on.	The battery is exhausted.	20
The camera turns off without warning.	 The camera automatically turns off to save power (auto off function). The camera and battery may not work properly at low temperatures. The inside of the camera has become hot. Leave the camera off until the inside of the camera has cooled, and then try turning it on again. The camera turns off if the USB cable connecting it to a computer or printer is disconnected. Reconnect the USB cable. 	21 2: - 83, 86, 25
Monitor is blank.	 The camera is off. The camera has entered standby mode to save power. Press the power switch, shutter-release button, button, button, of the movie-record) button. The flash lamp flashes while the flash is charging. Wait for the flash to charge. The camera and computer are connected via the USB cable. The camera and TV are connected via an HDMI cable. 	20 1, 21 47 83, 86 83,
Monitor is hard to read.	 Adjust the monitor brightness. The monitor is dirty. Clean the monitor.	77, 6-0 76 0 -6

Problem	Cause/Solution	
Date and time of recording are not correct.	 If the camera clock has not been set, the "Date not set" indicator flashes during shooting and movie recording. Images and movies saved before the clock is set are dated "00/00/0000 00:00" and "01/01/2014 00:00" respectively. Set the correct time and date for Time zone and date in the setup menu. The camera clock is not as accurate as ordinary watches or clocks. Periodically compare the time of the camera clock with that of a more accurate timepiece, and reset as required. 	16,77, 🍽 74
No indicators displayed in monitor.	Hide info is selected for Photo info in Monitor settings in the setup menu.	77, 60 76
Print date not available.	Time zone and date has not been set in the setup menu.	16, 77, 6 74
Date not imprinted on images even when Print date is enabled.	 The current shooting mode does not support Print date. The date cannot be imprinted on movies. 	77, & 78
Screen for setting time zone and date is displayed when the camera is turned on.	The clock battery is exhausted; all settings were restored to their default values.	16, 18
The camera settings reset.		
The camera becomes hot.	The camera may become hot when used for an extended period of time to shoot movies or send images using an Eye-Fi card, or when used in a hot environment; this is not a malfunction.	-
The camera makes sound.	When Autofocus mode is set to Full-time AF or while in some shooting modes, the camera may produce an audible focusing sound.	56, 74

Shooting Issues

Problem	Cause/Solution	
Cannot switch to shooting mode.	Disconnect the HDMI cable or USB cable.	83, 86, •••22, •••25
No image captured when the shutter-release button is pressed.	 When the camera is in playback mode, press the button, shutter-release button, or ● (* movie-record) button. When menus are displayed, press the MENU button. The battery is exhausted. When the flash lamp is flashing, the flash is charging. 	1,28 4 20 47
The camera cannot focus.	 The subject is too close. Try shooting using scene auto selector mode, Close-up scene mode, or macro mode. The subject is hard to focus on. Set AF assist in the setup menu to Auto. Turn the camera off and then on again. 	32, 36, 51 64 78, ↔81 20
Images are blurred.	 Use the flash. Increase the ISO sensitivity value. Enable Photo VR and/or Motion detection when shooting still images. Enable Movie VR when recording movies. Use BSS (Best Shot Selector). Use a tripod to stabilize the camera when shooting (using the self-timer at the same time is more effective). 	47 56 74, 77 37, 56, •••339 49

Problem	Cause/Solution	
Bright specks appear in images captured with flash.	The flash is reflecting off particles in the air. Set the flash mode setting to 🕲 (off).	48
Flash does not fire.	 The flash mode is set to ③ (off). A scene mode that restricts the flash is selected. On is selected for Blink proof in the smart portrait menu. On (continuous) or On (BSS) is selected for Smile timer in the smart portrait menu. A function that restricts the flash is enabled. 	47 53 57 57 58
Digital zoom cannot be used.	 Digital zoom is set to Off in the setup menu. Digital zoom cannot be used in the following situations: When Portrait, Night portrait, Night landscape, Backlighting (when HDR is set to ON), Easy panorama, or Pet portrait is selected in scene mode When smart portrait mode is selected When Continuous in the shooting menu is set to Multi-shot 16 When AF area mode in the shooting menu is set to Subject tracking 	78, 6 81 34 42 56, 6 39 56, 6 44
Image mode not available.	A function that restricts Image mode is enabled.	58
No sound when the shutter is released.	Off is selected for Shutter sound in the Sound settings setup menu. No sound is produced with some shooting modes and settings, even when On is selected.	78, 🏍 82

Problem	Cause/Solution	
AF-assist illuminator does not light.	Off is selected for AF assist in the setup menu. AF- assist illuminator may not light depending on the position of the focus area or the current scene mode, even when Auto is selected.	78, 🏍81
Images appear smeared.	The lens is dirty. Clean the lens.	Ö 6
Colors are unnatural.	White balance or hue is not adjusted properly.	36, 56, 🍽 36
Randomly spaced bright pixels ("noise") appear in image.	The subject is dark and the shutter speed is too slow, or ISO sensitivity is too high. Noise can be reduced by: • Using the flash • Specifying a lower ISO sensitivity setting	47 56, ** 42
lmages are too dark (underexposed).	 The flash mode is set to (2) (off). The flash window is blocked. The subject is beyond the range of the flash. Adjust exposure compensation. Increase ISO sensitivity. The subject is backlit. Select Backlighting scene mode or set the flash mode setting to \$ (fill flash). 	47 24 47 52 56,
Images are too bright (overexposed).	Adjust exposure compensation.	52
Unexpected results when flash set to ∳ (auto with red-eye reduction).	When taking images with \$ (auto with red-eye reduction), scene auto selector mode, or fill flash with slow sync and red-eye reduction in Night portrait scene mode, the In-Camera Red Eye Fix may be applied to areas not affected by red-eye in rare cases. Use any scene mode other than Night portrait , and change the flash mode to any setting other than \$ (auto with red-eye reduction) and try taking an image again.	32, 35, 47

Problem	Cause/Solution	
Skin tones are not softened.	 In some shooting conditions, facial skin tones may not be softened. For images containing four or more faces, try using the Skin softening effect in Glamour retouch in the playback menu. 	42 68, 200 18
Saving images takes time.	It may take more time to save images in the following situations: • When the noise reduction function is in operation, such as when shooting in a dark environment • When the flash mode is set to \$@ (auto with redey ereduction) • When shooting in Night landscape , Night portrait , or Backlighting (when HDR is set to ON) scene mode • When the skin softening function is applied while shooting • When using continuous shooting mode	- 48 35, 36, 37 57 56, \$\circ\$ 39
A ring-shaped belt or rainbow-colored stripe appears in the monitor or images.	When shooting with backlighting or when a very strong light source (such as sunlight) is in the frame, a ring-shaped belt or rainbow-colored stripe (ghosting) may occur. Change the position of the light source, or frame the image so that the light source does not enter the frame, and try again.	-

Playback Issues

Problem	Cause/Solution	
File cannot be played back.	 This camera may not be able to play back images saved with another make or model of digital camera. This camera cannot play back movies recorded with another make or model of digital camera. This camera may not be able to play back data edited on a computer. 	-
Cannot zoom in on image.	 Playback zoom cannot be used with movies. This camera may not be able to zoom in on images captured with another make or model of digital camera. 	-
Cannot record voice memos.	 Voice memos cannot be attached to movies. Voice memos cannot be attached to images captured with other cameras. Voice memos attached to images using another camera cannot be played back on this camera. 	- 68, ** 60
Cannot edit images.	 Some images cannot be edited. Images that have already been edited may not be edited again. There is not enough free space in the internal memory or on the memory card. This camera is unable to edit images captured with other cameras. Editing functions used for images are not available for movies. 	38, * 1 4 - - -

Problem	Cause/Solution	
Cannot rotate image.	This camera cannot rotate images captured with another make or model of digital camera.	-
lmages are not displayed on TV.	 TV settings is not correctly set in the setup menu. Both HDMI and USB cables are connected simultaneously. The memory card contains no images. Replace the memory card. Remove the memory card to play back images from the internal memory. 	78,
Nikon Transfer 2 does not start when the camera is connected to a computer.	 The camera is off. The battery is exhausted. The USB cable is not correctly connected. The camera is not recognized by the computer. The computer is not set to start Nikon Transfer 2 automatically. For more information about Nikon Transfer 2, refer to help information contained in ViewNX 2. 	20 20 83, 86 - 89
The PictBridge startup screen is not displayed when the camera is connected to a printer.	With some PictBridge-compatible printers, the PictBridge startup screen may not be displayed and it may be impossible to print images when Auto is selected for Charge by computer in the setup menu. Set Charge by computer to Off and reconnect the camera to the printer.	78, 🍽 85

Problem	Cause/Solution	
Images to be printed are not displayed.	 The memory card contains no images. Replace the memory card. Remove the memory card to print images from the internal memory. 	
Cannot select paper size with the camera.	The camera cannot be used to select the paper size in the following situations, even when printing from a PictBridge-compatible printer. Use the printer to select the paper size. • The printer does not support the paper sizes specified by the camera. • The printer automatically selects the paper size.	83, 🏞 28, 🏞 29 –

Specifications

Nikon COOLPIX S5300 Digital Camera

Ту	vpe	Compact digital camera	
Number of effective pixels		16.0 million	
In	nage sensor	¹ /2.3-in. type CMOS; approx. 16.76 million total pixels	
Le	ens	NIKKOR lens with 8× optical zoom	
Focal length		4.5-36.0 mm (angle of view equivalent to that of 25-200 mm lens in 35mm [135] format)	
	f/-number	f/3.7-6.6	
	Construction	8 elements in 7 groups	
	igital zoom agnification	Up to 4x (angle of view equivalent to that of approx. 800 mm lens in 35mm [135] format)	
Vibration reduction		Lens shift (still pictures) Lens shift and electronic VR (movies)	
Μ	otion blur reduction	Motion detection (still pictures)	
Autofocus (AF)		Contrast-detect AF	
Focus range		 [W]: Approx. 50 cm (1 ft 8 in.)-∞, [T]: Approx. 1.5 m (5 ft)-∞ Macro mode: Approx. 2 cm (0.8 in.)-∞ (wide-angle position) (All distances measured from center of front surface of lens) 	
	Focus-area selection	Face priority, manual with 99 focus areas, center, subject tracking, target finding AF	
М	onitor	7.5 cm (3-in.), approx. 460k-dot, TFT LCD with anti-reflection coating and 5-level brightness adjustment	
	Frame coverage (shooting mode)	Approx. 97% horizontal and 97% vertical (compared to actual picture)	
	Frame coverage (playback mode)	Approx. 99% horizontal and 99% vertical (compared to actual picture)	

St	torage	
Media		Internal memory (approx. 25 MB), SD/SDHC/SDXC memory card
File system		DCF, Exif 2.3, and DPOF compliant
	File formats	Still pictures: JPEG Sound files (Voice Memo): WAV Movies: MOV (Video: H.264/MPEG-4 AVC, Audio: LPCM stereo)
	nage size iixels)	 16M (High) [4608 × 3456 ★] 16M [4608 × 3456] 8M [3264 × 2448] 4M [2272 × 1704] 2M [1600 × 1200] VGA [640 × 480] 16.9 [4608 × 2592] 1:1 [3456 × 3456]
ISO sensitivity (Standard output sensitivity)		ISO 125-1600ISO 3200, 6400 (available when using Auto mode)
Exposure		
	Metering mode	Matrix, center-weighted (digital zoom less than 2x), spot (digital zoom 2x or more)
	Exposure control	Programmed auto exposure and exposure compensation $(-2.0 - +2.0 \text{ EV} \text{ in steps of }^{1}/3 \text{ EV})$
S	nutter	Mechanical and CMOS electronic shutter
	Speed	 ¹/1500-1 s ¹/4000 s (maximum speed during high-speed continuous shooting) 4 s (Fireworks show scene mode)
A	perture	Electronically-controlled ND filter (-3 AV) selection
	Range	2 steps (f/3.7 and f/10.5 [W])
Se	elf-timer	Can be selected from 10 s and 2 s

Flash	
Range (approx.) (ISO sensitivity: Auto)	[W]: 0.5–3.5 m (1 ft 8 in.−11 ft) [∏]: 1.5–2.0 m (5 ft–6 ft 6 in.)
Flash control	TTL auto flash with monitor preflashes
Interface	Hi-Speed USB equivalent
Data transfer protocol	MTP, PTP
HDMI output	Can be selected from Auto, 480p, 720p, and 1080i
I/O terminal	Micro-USB connector, HDMI micro connector (Type D) (HDMI output)
Supported languages	Arabic, Bengali, Bulgarian, Chinese (Simplified and Traditional), Czech, Danish, Dutch, English, Finnish, French, German, Greek, Hindi, Hungarian, Indonesian, Italian, Japanese, Korean, Marathi, Norwegian, Persian, Polish, Portuguese (European and Brazilian), Romanian, Russian, Serbian, Spanish, Swedish, Tamil, Telugu, Thai, Turkish, Ukrainian, Vietnamese
Power sources	One Rechargeable Li-ion Battery EN-EL19 (included) AC Adapter EH-62G (available separately)
Charging time	Approx. 1 h 50 min (when using Charging AC Adapter EH-71P and when no charge remains)
Battery life ¹	
Still pictures	Approx. 180 shots when using EN-EL19
Movies (actual battery life for recording) ²	Approx. 35 min (1080/30p) when using EN-EL19 Approx. 40 min (1080/25p) when using EN-EL19
Tripod socket	1/4 (ISO 1222)
Dimensions (W \times H \times D)	Approx. 96.9 \times 58.0 \times 20.9 mm (3.9 \times 2.3 \times 0.9 in.) (excluding projections)
Weight	Approx. 138 g (4.9 oz) (including battery and SD memory card)

0	perating environment	
	Temperature	0°C-40°C (32°F-104°F)
	Humidity	85% or less (no condensation)
W	'i-Fi (Wireless LAN)	
	Standards	IEEE 802.11b/g/n (standard wireless LAN protocol)
	Communications protocols	IEEE 802.11b: DBPSK/DQPSK/CCK IEEE 802.11g: OFDM IEEE 802.11n: OFDM
	Range (line of sight)	Approx. 10 m (11 yd)
	Operating frequency	2412-2462 MHz (1-11 channels)
	Data rates (actual measured values)	IEEE 802.11b: 5 Mbps IEEE 802.11g: 20 Mbps IEEE 802.11n: 20 Mbps
	Security	WPA2
	Access protocols	Infrastructure

- Unless otherwise stated, all figures assume a fully-charged battery and an ambient temperature of 23 ±3°C (73.4 ±5.4°F) as specified by the Camera and Imaging Products Association (CIPA).
- Battery life may vary depending on conditions of use, such as the interval between shots or the length of time that menus and images are displayed.
- ² Individual movie files cannot exceed 4 GB in size or 29 minutes in length. Recording may end before this limit is reached if camera temperature becomes elevated.

Rechargeable Li-ion Battery EN-EL19

Туре	Rechargeable lithium-ion battery	
Rated capacity	DC 3.7 V, 700 mAh	
Operating temperature	0°C-40°C (32°F-104°F)	
Dimensions (W \times H \times D)	Approx. 31.5 × 39.5 × 6 mm (1.3 × 1.6 × 0.3 in.)	
Weight	Approx. 14.5 g (0.5 oz)	

Charging AC Adapter EH-71P

Rated input	AC 100-240 V, 50/60 Hz, MAX 0.2 A	
Rated output	DC 5.0 V, 1.0 A	
Operating temperature	0°C-40°C (32°F-104°F)	
Dimensions (W \times H \times D)	Approx. $55 \times 22 \times 54$ mm (2.2 × 0.9 × 2.2 in.) (excluding plug adapter) For Argentina: Approx. $55 \times 63 \times 59$ mm (2.2 × 2.5 × 2.4 in.) For Brazil: Approx. $55 \times 67 \times 59$ mm (2.2 × 2.7 × 2.4 in.)	
Weight	Approx. 48 g (1.7 oz) (excluding plug adapter) For Argentina: Approx. 73 g (2.6 oz) For Brazil: Approx. 70 g (2.5 oz)	

Specifications

- Nikon will not be held liable for any errors this manual may contain.
- The appearance of this product and its specifications are subject to change without notice.

Approved Memory Cards

The following Secure Digital (SD) memory cards have been tested and approved for use in this camera.

 Memory cards with an SD Speed Class rating of 6 or faster are recommended for recording movies. When using a memory card with a lower Speed Class rating, movie recording may stop unexpectedly.

	SD memory card	SDHC memory card ²	SDXC memory card ³
SanDisk	2 GB ¹	4 GB, 8 GB, 16 GB, 32 GB	64 GB, 128 GB
TOSHIBA	-	4 GB, 8 GB, 16 GB, 32 GB	64 GB
Panasonic	2 GB ¹	4 GB, 8 GB, 16 GB, 32 GB	64 GB
Lexar	-	4 GB, 8 GB, 16 GB, 32 GB	64 GB, 128 GB

¹ If the memory card will be used with a card reader or similar device, make sure that the device supports 2 GB cards.

² SDHC compliant.

If the memory card will be used with a card reader or similar device, make sure that the device supports SDHC.

³ SDXC compliant.

If the memory card will be used with a card reader or similar device, make sure that the device supports SDXC.

• Contact the manufacturer for details on the above cards. We cannot guarantee camera performance when using memory cards made by other manufacturers.



AVC Patent Portfolio License

This product is licensed under the AVC Patent Portfolio License for the personal and noncommercial use of a consumer to (i) encode video in compliance with the AVC standard ("AVC video") and/or (ii) decode AVC video that was encoded by a consumer engaged in a personal and non-commercial activity and/or was obtained from a video provider licensed to provide AVC video. No license is granted or shall be implied for any other use. Additional information may be obtained from MPEG LA, L.L.C.

See http://www.mpegla.com.

Trademark Information

- Microsoft, Windows and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Mac, OS X, the iFrame logo and the iFrame symbol are trademarks or registered trademarks of Apple Inc., in the U.S. and other countries.
- Adobe and Acrobat are registered trademarks of Adobe Systems Inc.
- SDXC, SDHC, and SD Logos are trademarks of SD-3C, LLC.
- PictBridge is a trademark.
- HDMI, HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

HOMI

- Wi-Fi and the Wi-Fi logo are trademarks or registered trademarks of the Wi-Fi Alliance.
- Android and Google Play are trademarks or registered trademarks of Google, Inc.
- All other trade names mentioned in this manual or the other documentation provided with your Nikon product are the trademarks or registered trademarks of their respective holders.

FreeType License (FreeType2)

• Portions of this software are copyright © 2012 The FreeType Project (http://www.freetype.org). All rights reserved.

MIT License (HarfBuzz)

 Portions of this software are copyright © 2014 The HarfBuzz Project (http://www.freedesktop.org/wiki/Software/HarfBuzz). All rights reserved.

Index

<u>Symbols</u>

🗺 Scene auto selector mode	32
Z Scene mode	
SO Special effects mode	40
Smart portrait mode	
Auto mode	
Playback mode	
Favorite pictures mode	
Auto sort mode	
List by date mode	
۲» Wi-Fi options menu 81	
T (Telephoto)	
W (Wide-angle)	
Q Playback zoom	
Thumbnail playback	
Help	
Shooting mode button	
 Playback button 	
• (MR movie-record) button	
Apply selection button	
MENU Menu button	Z
	77 01
Delete button 2, 30	
Flash mode	
రు Self-timer	

💥 Macro mode	
Exposure compensation	52
<u>A</u>	
AC adapter 83	, 🏍 95
Adding favorites pictures 69	9, 🏍6
AF area mode 56,	6-0 44
AF assist 1, 78	, 🏍81
Album	🏍 9
Aperture value	27
Auto flash	48
Auto mode	
Auto off 21, 78,	, 🏍82
Auto sort mode	🍋 10
Auto with red-eye reduction	
Autofocus 56, 72, 🗢 48,	, 🏍 68
Autofocus mode	
	, 🏍 68
<u>B</u>	
Backlighting 😰	34, 37
Battery 10,	12, 18
Battery chamber	🍽 95
Battery charger 13	, 🍋 95
Battery latch	10
Battery level indicator	
Battery-chamber/memory card sl	ot cover
	10, 14

Refer to the *Reference Manual* for pages indicated with 🏍.

Beach 😤	
Best Shot Selector	37, 🏍 40
Black and white copy 🖵	
Black-and-white	
Blink proof	. 57, 🏍 51
Blink warning	
Brightness	
BSS	
Built-in microphone (stereo).	
Button sound	
С	
Calendar Display	67
Capturing still images while r	
movies	-
Charge by computer	
Charge lamp	
Charging AC Adapter	
Choose key picture	
	012, 0-0 63
Close-up 🗱	
Cloudy	
Color options	
Compression ratio	
Computer	
Connecting to smart devices	
	81, 🍽71
Connector cover	-
Continuous	56, 🍋 39

Copying images		69,	6 61
Crop			6 021
Cross process 💸			41
Current settings			
Cyanotype			
D			
Date and time	16,	77,	6 74
Date format		17,	6 74
Daylight			∂− 036
Daylight saving time			
Delete			
Digital zoom			
Direct print			
D-Lighting			
DPOF printing			
DSCN			
Dusk/dawn ՝			
<u>E</u>			
Easy panorama 🛱	34	, 38	, 🏍2
Easy panorama playback		38	, 🍋 5
Editing images			
EH-71P			
EN-EL19			. Ø 21
Exposure compensation.			52
Extension			
Eye-Fi upload			
Eyelet for camera strap			

Ö-26

<u>F</u>

Face detection				61
Face priority			. 0-0	44
Favorite pictures mode				
File names			. 0-0	94
Fill flash				
Fireworks show 🏶				
Firmware version		78,	8	88
Fixed range auto			. 8	942
Flash				
Flash lamp				
Flash mode			47,	48
Flash off				48
Fluorescent				
Focus	26,	56,	0	44
Focus area			26,	61
Focus indicator				
Focus lock				
Food			34,	36
Format internal memory		78,	8	83
Format memory cards				
Formatting				
Frame rate				
FSCN				
Full-frame playback				66
Full-time AF 56, 74,				
Functions that cannot be				
simultaneously				58
· ·				

<u>G</u> Glamour retouch <u>H</u>	. 68,	6-6 18
HDMI		
HDMI cable		
HDMI device control		6 84
HDMI micro connector		1, 83
HDR		37
Help		34
High key 🛍		
High-contrast monochrome		40
High-speed continuous		
HS movie 74, 🎮	65,	66 66
<u>I</u>		
Identifier		ð ð 94
Image mode	56,	6- 034
Image review	77,	ð ð 76
Image size	56,	6 34
Imprinting date and time	. 18,	ð ð 78
Incandescent		ð ð 36
Internal memory		15, 20
Internal memory indicator		
ISO sensitivity	56,	6 •042
Ţ		
JPG		ð ð 94
L		
Landscape 🖌		34
Language		
	. /0,	0-004

Refer to the *Reference Manual* for pages indicated with 🏍.

Ö-27

Lens 1,	Ö ⁻ 17
Lens cover	1
List by date mode	6-0 11
Low key Lo.	40

M

Macro mode	51
Memory card	14, Ö [.] 22
Memory card slot	
Micro-USB connector	1, 83
Mirror	41
Monitor	
Monitor settings	
Motion detection	
MOV	
Movie editing	
Movie length	
Movie menu	
Movie options	
Movie playback	
Movie recording	
Movie VR	
Multi selector	
Multi-shot 16	🏍 40
Museum 🏛	
N	
Night landscape 🖬	
Night portrait	
Nikon Transfer 2	

Nostalgic sepia SE			40
Number of exposures remainin			
	20,	0	35
<u>0</u>			
Open with HS footage		_	
Optical zoom			
Optional accessories			
Dptions		. 0-0	5/1
– Painting 🛱			40
Paper size 🏍 2			
Party/indoor 💥			
Pet portrait auto release			
Pet portrait 🦋			
Photo info	77,	0	576
Photo VR	77,	8	579
PictBridge	34,	0	24
Playback			
$ ho$ layback menu ϵ			
Playback mode			
Playback zoom			
Pop POP			
Portrait 💈			
^o ower			20
Power connector cover			1
Power switch		1,	20
Power-on lamp			

Refer to the *Reference Manual* for pages indicated with 🏍.

Preset manual		ð ð 37
Pre-shooting cache &		
Pressing halfway		27
Print 68, 84, 🗢 27, 🗖		
Print date		
18, 77, 🏍 53, 🅭	0 55,	6 78
Print order		
Printer	. 84,	6 024
Protect	. 68,	ð - ð57
Q		
Quick effects 29, 45, 🗲	014,	6-0 48
Quick retouch		
<u>R</u>		
Rechargeable Li-ion battery		🏷 21
Recording slow motion movi		-
		66 66
Red-eye correction		
Removing favorite pictures		
Reset all		
Restore default settings		
Rotate image	. 68,	∂ €59
RSCN		
<u>S</u>		
		34
Selective color 🖋		40
Self-timer		
Self-timer lamp		1, 50
Sepia		

Sequence display options		
	ð ð 12, ð	063
Setup menu	77, 8	073
Shooting	22, 24	, 26
Shooting menu	56, ð	034
Shooting mode		22
Shutter sound	ð	082
Shutter speed		27
Shutter-release button	1	, 26
Single	56, 8	039
Single AF 56, 74,	6 648, 6	068
Skin softening 5		
Slide show		
Slow sync		48
Small picture	68, 🕭	020
Smart portrait menu		
Smart portrait mode		42
Smile timer	57, 8	050
Snow 🚨		34
Soft SO		40
Sound settings	78, ð	082
Speaker		2
Special effects mode		40
Sports 💐		, 35
SSCN	ð	ð 94
Standard color	56, 8	0 43
Strap		3
Subject tracking	6 645, 6	0 47

Refer to the *Reference Manual* for pages indicated with 🏍.

Ö-29

Sunset 🚔 Super vivid 🚺			34 40
<u>T</u> Target finding AF Telephoto			
Televisions			
Thumbnail display			67
Time difference			
Time zone			
Time zone and date	. 16,	77,	6 74
Toy camera effect 1 👫.			40
Toy camera effect 2 🔛			41
Tripod socket		2	, 🍎 19
TV settings		78,	6 84
<u>U</u>			
USB cable	84,	86,	ð ð 25
USB cable <u>V</u>	84,	86,	ð t ð25
	-	-	
V			85
<u>V</u> ViewNX 2			85 •••43
⊻ ViewNX 2 Vivid color		68,	
⊻ ViewNX 2 Vivid color Voice memo		68,	
<u>V</u> ViewNX 2 Vivid color Voice memo Volume		68, 75,	
V ViewNX 2 Vivid color Voice memo Volume W		68, 75,	85 0 043 0 060 0 060 0 094
V ViewNX 2 Vivid color Voice memo Volume W WAV		68, 75, .77,	
⊻ ViewNX 2 Vivid color Voice memo Volume ₩ WAV Welcome screen		68, 75, 77, 56,	85 0 0 43 0 0 60 0 0 60 0 0 94 0 0 73 0 0 36
⊻ ViewNX 2 Vivid color Voice memo Volume ₩ WAV Welcome screen White balance		68, 75, 77, 56,	

Wind noise reduction	9
Zoom control	

Refer to the *Reference Manual* for pages indicated with 🏍.

Ö-30

No reproduction in any form of this manual, in whole or in part (except for brief quotation in critical articles or reviews), may be made without written authorization from NIKON CORPORATION.

Please visit the Nikon website below to download the Reference Manual in English.

संदर्भ मैनुअल को हिंदी में डाउनलोड करने के लिए नीचे दी गई Nikon वेबसाइट पर जाएँ।

অনুগ্রহ করে বাংলায় *রেফারেন্স পুস্তিকা* ডাউনলোড করতে নিচে Nikon ওয়েবসাইটে যান।

தமிழில் *சரிபார்ப்புக் கையேட்டைப்* பதிவிறக்குவதற்கு, தயவுசெய்து கீழுள்ள Nikon வலைத்தளத்துக்குச் செல்லவும்.

मराठीत संदर्भ सूचना-पुस्तिका डाउनलोड करण्यासाठी कृपया खालील Nikon वेबसाईटला भेट दया.

తెలుగులో *అన్వయ మార్గదర్శక పుస్తకం డౌ*న్లోడ్ చేసుకునేందుకు దయచేసి Nikon పెట్రైట్ సందర్పించండి.

http://nikonimglib.com/manual/

NIKON CORPORATION

Printed in China

CE YP3L01(11) 6MN38011-01

© 2014 Nikon Corporation