

# ***Nikon***

DIGITAL CAMERA

# COOLPIX S9600

## User's Manual



**En**



<b>Introduction</b>	
<b>Parts of the Camera</b>	
<b>The Basics of Shooting and Playback</b>	
<b>Shooting Features</b>	
<b>Playback Features</b>	
<b>Recording and Playing Back Movies</b>	
<b>General Camera Setup</b>	
<b>Using the Wi-Fi (Wireless LAN) Function</b>	
<b>Connecting the Camera to a TV, Computer, or Printer</b>	
<b>Technical Notes and Index</b>	

# Introduction

## Read This First

Thank you for purchasing the Nikon COOLPIX S9600 digital camera. Before using the camera, please read the information in "For Your Safety" (📖vii-ix) and familiarize yourself with the information provided in this manual. After reading, please keep this manual handy and refer to it to enhance your enjoyment of your new camera.

## Confirming the Package Contents

In the event that any items are missing, please contact the store where you purchased the camera.



COOLPIX S9600  
Digital Camera




Camera Strap



Rechargeable Li-ion  
Battery EN-EL12



Charging AC Adapter  
EH-71P\*



USB Cable UC-E21

- *User's Manual* (this manual)
- *Warranty*

\* A plug adapter is included if the camera was purchased in a country or region that requires a plug adapter. The shape of the plug adapter varies with the country or region of purchase (📖12).

**NOTE:** A memory card is not included with the camera.

## About This Manual

If you want to start using the camera right away, see “The Basics of Shooting and Playback” (10).

To learn about the parts of the camera and information that is displayed in the monitor, see “Parts of the Camera” (1).

### Downloading the “Reference Manual”

Refer to the *Reference Manual* (PDF format) for more detailed information.

The *Reference Manual* can be downloaded from the Nikon website.






<http://nikonimglib.com/manual/>


The *Reference Manual* can be viewed using Adobe Reader, available for free download from the Adobe website.

### Other Information

- Symbols and Conventions

To make it easier to find the information you need, the following symbols and conventions are used in this manual:

Symbol	Description
	This icon indicates cautions and information that should be read before using the camera.
	This icon indicates notes and information that should be read before using the camera.
	These icons indicate other pages containing relevant information;  *: “Reference Section”,  : “Technical Notes and Index.”

\* Refer to the *Reference Manual* for pages indicated with .

- SD and SDHC/SDXC memory cards are referred to as “memory cards” in this manual.
- The setting at the time of purchase is referred to as the “default setting.”
- The names of menu items displayed in the camera monitor, and the names of buttons or messages displayed on a computer monitor appear in bold.
- In this manual, images are sometimes omitted from monitor display samples so that monitor indicators can be more clearly shown.
- Illustrations and monitor content shown in this manual may differ from the actual product.

# Information and Precautions

## Life-Long Learning

As part of Nikon's "Life-Long Learning" commitment to ongoing product support and education, continually updated information is available online at the following sites:

- For users in the U.S.A.: <http://www.nikonusa.com/>
- For users in Europe and Africa: <http://www.europe-nikon.com/support/>
- For users in Asia, Oceania, and the Middle East: <http://www.nikon-asia.com/>

Visit these sites to keep up-to-date with the latest product information, tips, answers to frequently asked questions (FAQs), and general advice on digital imaging and photography. Additional information may be available from the Nikon representative in your area. Visit the site below for contact information:

<http://imaging.nikon.com/>

## Use Only Nikon Brand Electronic Accessories

Nikon COOLPIX cameras are designed to the highest standards and include complex electronic circuitry. Only Nikon brand electronic accessories (including battery chargers, batteries, charging AC adapters, AC adapters, and cables) certified by Nikon specifically for use with this Nikon digital camera are engineered and proven to operate within the operational and safety requirements of this electronic circuitry.

THE USE OF NON-NIKON ELECTRONIC ACCESSORIES COULD DAMAGE THE CAMERA AND MAY VOID YOUR NIKON WARRANTY.

The use of third-party rechargeable Li-ion batteries not bearing the Nikon holographic seal could interfere with normal operation of the camera or result in the batteries overheating, igniting, rupturing, or leaking.

For more information about Nikon brand accessories, contact a local authorized Nikon dealer.

**Holographic seal:** Identifies this device as an authentic Nikon product.



## Before Taking Important Pictures

Before taking pictures on important occasions (such as at weddings or before taking the camera on a trip), take a test shot to ensure that the camera is functioning normally. Nikon will not be held liable for damages or lost profits that may result from product malfunction.

## About the Manuals

- No part of the manuals included with this product may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form, by any means, without Nikon's prior written permission.
- Nikon reserves the right to change the specifications of the hardware and software described in these manuals at any time and without prior notice.
- Nikon will not be held liable for any damages resulting from the use of this product.
- While every effort was made to ensure that the information in these manuals is accurate and complete, we would appreciate it were you to bring any errors or omissions to the attention of the Nikon representative in your area (address provided separately).

## Notice Concerning Prohibition of Copying or Reproduction

Note that simply being in possession of material that was digitally copied or reproduced by means of a scanner, digital camera or other device may be punishable by law.

### • Items prohibited by law from being copied or reproduced

Do not copy or reproduce paper money, coins, securities, government bonds or local government bonds, even if such copies or reproductions are stamped "Sample." The copying or reproduction of paper money, coins, or securities which are circulated in a foreign country is prohibited. Unless the prior permission of the government was obtained, the copying or reproduction of unused postage stamps or post cards issued by the government is prohibited.

The copying or reproduction of stamps issued by the government and of certified documents stipulated by law is prohibited.

### • Cautions on certain copies and reproductions

The government has issued cautions on copies or reproductions of securities issued by private companies (shares, bills, checks, gift certificates, etc.), commuter passes, or coupon tickets, except when a minimum of necessary copies are to be provided for business use by a company. Also, do not copy or reproduce passports issued by the government, licenses issued by public agencies and private groups, ID cards and tickets, such as passes and meal coupons.

### • Comply with copyright notices

The copying or reproduction of copyrighted creative works such as books, music, paintings, woodcut prints, maps, drawings, movies, and photographs is governed by national and international copyright laws. Do not use this product for the purpose of making illegal copies or to infringe copyright laws.

## Disposing of Data Storage Devices

Please note that deleting images or formatting data storage devices such as memory cards or built-in camera memory does not completely erase the original image data. Deleted files can sometimes be recovered from discarded storage devices using commercially available software, potentially resulting in the malicious use of personal image data. Ensuring the privacy of such data is the user's responsibility.

Before discarding a data storage device or transferring ownership to another person, erase all data using commercial deletion software, or format the device and then completely refill it with images containing no private information (for example, pictures of empty sky). Be sure to also replace any pictures selected for the **Select an image** option in the **Welcome screen** setting (📖78). Care should be taken to avoid injury or damage to property when physically destroying data storage devices. You can clear the Wi-Fi settings using **Restore default settings** in the Wi-Fi options menu (🔌78).

## For Your Safety

To prevent damage to your Nikon product or injury to yourself or to others, read the following safety precautions in their entirety before using this equipment. Keep these safety instructions where all those who use the product will read them.

The consequences that could result from failure to observe the precautions listed in this section are indicated by the following symbol:



This icon marks warnings, information that should be read before using this Nikon product, to prevent possible injury.

### WARNINGS



#### **Turn off in the event of malfunction**

Should you notice smoke or an unusual smell coming from the camera or charging AC adapter, unplug the charging AC adapter and remove the battery immediately, taking care to avoid burns. Continued operation could result in injury. After removing or disconnecting the power source, take the equipment to a Nikon-authorized service representative for inspection.



#### **Do not disassemble**

Touching the internal parts of the camera or charging AC adapter could result in injury. Repairs should be performed only by qualified technicians. Should the camera or charging AC adapter break open as the result of a fall or other accident, take the product to a Nikon-authorized service representative for inspection, after unplugging the product and/or removing the battery.



#### **Do not use the camera or charging AC adapter in the presence of flammable gas**

Do not use electronic equipment in the presence of flammable gas, as this could result in explosion or fire.



#### **Handle the camera strap with care**

Never place the strap around the neck of an infant or child.



#### **Keep out of reach of children**

Particular care should be taken to prevent infants from putting the battery or other small parts into their mouths.



#### **Do not remain in contact with the camera, charging AC adapter, or AC adapter for extended periods while the devices are on or in use**

Parts of the devices become hot. Leaving the devices in direct contact with the skin for extended periods may result in low-temperature burns.



**Do not leave the product where it will be exposed to extremely high temperatures, such as in an enclosed automobile or in direct sunlight**

Failure to observe this precaution could cause damage or fire.



**Use the appropriate power supply (battery, charging AC adapter, AC adapter, USB cable)**

Using a power supply other than those provided or sold by Nikon could result in damage or malfunction.



**Observe caution when handling the battery**

The battery may leak, overheat, or explode if improperly handled. Observe the following precautions when handling the battery for use in this product:

- Before replacing the battery, turn the product off. If you are using the charging AC adapter/AC adapter, be sure it is unplugged.
- Use only a Rechargeable Li-ion Battery EN-EL12 (included). Charge the battery by using a camera that supports battery charging. To perform this operation, use the Charging AC Adapter EH-71P (included) and USB Cable UC-E21 (included). The Battery Charger MH-65 (available separately) is also available to charge the battery without using a camera.
- When inserting the battery, do not attempt to insert it upside down or backwards.
- Do not short or disassemble the battery or attempt to remove or

break the battery insulation or casing.

- Do not expose the battery to flame or to excessive heat.
- Do not immerse in or expose to water.
- Put the battery in a plastic bag, etc. to insulate the terminal before transporting it. Do not transport or store with metal objects such as necklaces or hairpins.
- The battery is prone to leakage when fully discharged. To avoid damage to the product, be sure to remove the battery when no charge remains.
- Discontinue use immediately should you notice any change in the battery, such as discoloration or deformation.
- If liquid from the damaged battery comes in contact with clothing or skin, rinse immediately with plenty of water.



**Observe the following precautions when handling the charging AC adapter**

- Keep dry. Failure to observe this precaution could result in fire or electric shock.
- Dust on or near the metal parts of the plug should be removed with a dry cloth. Continued use could result in fire.
- Do not handle the plug or go near the charging AC adapter during lightning storms. Failure to observe this precaution could result in electric shock.

- Do not damage, modify, forcibly tug or bend the USB cable, place it under heavy objects, or expose it to heat or flames. Should the insulation be damaged and the wires become exposed, take it to a Nikon-authorized service representative for inspection. Failure to observe these precautions could result in fire or electric shock.
- Do not handle the plug or charging AC adapter with wet hands. Failure to observe this precaution could result in electric shock.
- Do not use with travel converters or adapters designed to convert from one voltage to another or with DC-to-AC inverters. Failure to observe this precaution could damage the product or cause overheating or fire.

### **Use appropriate cables**

When connecting cables to the input and output jacks, use only the cables provided or sold by Nikon for the purpose, to maintain compliance with product regulations.

### **Handle moving parts with care**

Be careful that your fingers or other objects are not pinched by the lens cover or other moving parts.

### **Using the flash close to your subject's eyes could cause temporary visual impairment**

The flash should be no less than 1 m (3 ft 4 in.) from the subject. Particular care should be observed when photographing infants.

### **Do not operate the flash with the flash window touching a person or object**

Failure to observe this precaution could result in burns or fire.

### **Avoid contact with liquid crystal**

Should the monitor break, care should be taken to avoid injury caused by broken glass and to prevent liquid crystal from the monitor touching the skin or entering the eyes or mouth.

### **Turn the power off when using inside an airplane or the hospital**

Turn the power off while inside the airplane during take off or landing. Do not use wireless network functions while in the air. Follow the instructions of the hospital when using while in a hospital. The electromagnetic waves emitted by this camera may disrupt the electronic systems of the airplane or the instruments of the hospital. If you are using an Eye-Fi card, remove it from the camera before boarding an aircraft or entering a hospital.

# Notices

## **Notices for Customers in the U.S.A.**

### **IMPORTANT SAFETY INSTRUCTIONS -**

#### **SAVE THESE INSTRUCTIONS.**

#### **DANGER - TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS**

For connection to a supply not in the U.S.A., use an attachment plug adapter of the proper configuration for the power outlet if needed.

The power supply unit is intended to be correctly orientated in a vertical or floor mount position.

#### **Federal Communications Commission (FCC) Radio Frequency Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will

not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



**Nikon**

COOLPIX S9600

### **CAUTIONS**

#### **Modifications**

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Nikon Corporation may void the user's authority to operate the equipment.

#### **Interface Cables**

Use the interface cables sold or provided by Nikon for your equipment. Using other interface cables may exceed the limits of Class B Part 15 of the FCC Rules.

## Notice for customers in the State of California

### WARNING

Handling the cord on this product will expose you to lead, a chemical known to the State of California to cause birth defects or other reproductive harm.

***Wash hands after handling.***

Nikon Inc.,

1300 Walt Whitman Road  
Melville, New York 11747-3064  
USA

Tel: 631-547-4200

## Notice for customers in Canada

CAN ICES-3 B / NMB-3 B

## Notices for customers in Europe

### CAUTIONS

### RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.

### DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

This symbol indicates that electrical and electronic equipment is to be collected separately.



The following apply only to users in European countries:

- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- Separate collection and recycling helps conserve natural resources and prevent negative consequences for human health and the environment that might result from incorrect disposal.
- For more information, contact the retailer or the local authorities in charge of waste management.

This symbol on the battery indicates that the battery is to be collected separately.



The following apply only to users in European countries:

- All batteries, whether marked with this symbol or not, are designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- For more information, contact the retailer or the local authorities in charge of waste management.

## Wi-Fi (Wireless LAN Network)

This product is controlled by the United States Export Administration Regulations, and you are required to obtain permission from the United States government if you export or re-export this product to any country to which the United States embargoes goods. The following countries were subject to embargo: Cuba, Iran, North Korea, Sudan, and Syria. Since the target countries are subject to change, please contact the United States Department of Commerce for the latest information.

### **Restrictions on Wireless Devices**

The wireless transceiver included in this product conforms to wireless regulations in the country of sale and is not for use in other countries (products purchased in the EU or EFTA can be used anywhere within the EU and EFTA). Nikon does not accept liability for use in other countries. Users who are unsure as to the original country of sale should consult with their local Nikon service center or Nikon-authorized service representative. This restriction applies to wireless operation only and not to any other use of the product.

### **Notice for Customers in the U.S.A. and Canada**

#### **Federal Communications Commission (FCC) and Industry of Canada (IC)**

#### **Declaration of Conformity**

This device complies with Part 15 of FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device.

#### **FCC/IC RF Exposure Statement**

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

The available scientific evidence does not show that any health problems are associated with using low power wireless devices. There is no proof, however, that these low power wireless devices are absolutely safe. Low power wireless devices emit low levels of radio frequency energy (RF) in the microwave range while being used. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low-level RF that does not produce heating effects causes no known adverse health effects. Many studies of low-level RF exposures have not found any biological effects. Some studies have suggested that some biological effects might occur, but such findings have not been confirmed by additional research.

COOLPIX S9600, which is equipped with a DW092 (FCC ID: EW4DW092/IC ID: 4634A-3149EC) Wireless LAN Module, has been tested and found to comply with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65 and RSS-102 of the IC radio frequency (RF) Exposure rules. Please refer to the SAR test report that was uploaded to FCC website.

### **Declaration of Conformity (Europe)**

Hereby, Nikon Corporation, declares that COOLPIX S9600 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of conformity may be consulted at [http://imaging.nikon.com/support/pdf/DoC\\_S9600.pdf](http://imaging.nikon.com/support/pdf/DoC_S9600.pdf).

### **Notice for Customers in Jamaica**

This product contains a Type Approved Module by Jamaica:  
"SMA - DW092"

## **הודעה ללקוחות במדינת ישראל**

ההתקן תואם לתקנות תדרי רדיו.

יש לנהוג באמצעי זהירות בעת השימוש באפשרויות התקשורת

א. נקודות הגישה תהיה מיועדת אך ורק לחיבור משתמש תמצוי בחצרים מתוחמים (דוגמת בית, בית עסק, מתחם שדה תעופה, קמפוס אוניברסיטאי וכו')

ב. לצורך גישה לאינטרנט, נקודת הגישה תקושר מחוץ לחצרים אך ורק אל בעל רשיון למתן שירות גישה לאינטרנט (ISP, להלן-ספק אינטרנט). הקישור לספק אינטרנט יהיה אך ורק באמצעות קו תקשורת נתונים המסופק בידי בעל רשיון למתן שירותי תקשורת נתונים;

ג. קישור נקודת הגישה מחוץ לחצרים לצורך תקשורת נתונים ייעשה באמצעות תשתיות של בעל רשיון מתאים ובלבד שלא ייעשה שימוש בקישור כאמור לצורך העברת קול (VOICE)

ד. לצורך שרות לצד ג' נדרש רשיון נוסף מאגף הנדסה ורישוי (משרד התקשורת).


## Precautions when Using Radio Transmissions

Always keep in mind that radio transmission or reception of data is subject to interception by third parties. Note that Nikon is not responsible for data or information leaks that may occur during data transfer.




























## Personal Information Management and Disclaimer


- User information registered and configured on the product, including wireless LAN connection settings and other personal information, is susceptible to alteration and loss resulting from operational error, static electricity, accident, malfunction, repair or other handling. Always keep separate copies of important information. Nikon is not responsible for any direct or indirect damages or lost profits resulting from alteration or loss of content that is not attributable to Nikon.
- Before discarding this product or transferring it to another owner, perform **Restore default settings** in the Wi-Fi options menu (🔑 078) to delete all user information registered and configured with the product, including wireless LAN connection settings and other personal information.































# Table of Contents

<b>Introduction .....</b>	<b>ii</b>
<b>Read This First .....</b>	<b>ii</b>
Confirming the Package Contents .....	ii
About This Manual .....	iii
Information and Precautions .....	iv
<b>For Your Safety .....</b>	<b>vii</b>
WARNINGS .....	vii
<b>Notices .....</b>	<b>x</b>
<b>Wi-Fi (Wireless LAN Network) .....</b>	<b>xii</b>
<b>Parts of the Camera .....</b>	<b>1</b>
<b>The Camera Body .....</b>	<b>1</b>
Attaching the Camera Strap .....	3
<b>Using Menus (the MENU Button) .....</b>	<b>4</b>
<b>The Monitor .....</b>	<b>6</b>
Shooting Mode .....	6
Playback Mode .....	8
<b>The Basics of Shooting and Playback .....</b>	<b>10</b>
<b>Preparation 1 Insert the Battery .....</b>	<b>10</b>
<b>Preparation 2 Charge the Battery .....</b>	<b>12</b>
<b>Preparation 3 Insert a Memory Card .....</b>	<b>14</b>
Internal Memory and Memory Cards .....	15
<b>Preparation 4 Setting the Display Language, Date, and Time .....</b>	<b>16</b>
<b>Step 1 Turn the Camera On .....</b>	<b>20</b>
<b>Step 2 Select a Shooting Mode .....</b>	<b>22</b>
Available Shooting Modes .....	23
<b>Step 3 Frame a Picture .....</b>	<b>24</b>
Using the Zoom .....	25
<b>Step 4 Focus and Shoot .....</b>	<b>26</b>
The Shutter-release Button .....	27
<b>Step 5 Play Back Images .....</b>	<b>28</b>
<b>Step 6 Delete Images .....</b>	<b>29</b>
<b>Shooting Features .....</b>	<b>31</b>
 <b>(Auto) Mode .....</b>	<b>31</b>

Using Quick Effects .....	32
Scene Mode (Shooting Suited to Scenes) .....	33
Tips and Notes .....	34
Smart Portrait Mode (Capturing Images of Smiling Faces) .....	40
Special Effects Mode (Applying Effects When Shooting) .....	42
Functions That Can Be Set Using the Multi Selector .....	44
Using the Flash .....	45
Using the Self-timer .....	48
Using Macro Mode .....	49
Adjusting Brightness (Exposure Compensation), Vividness, and Hue (Creative Slider) .....	50
Adjusting Brightness (Exposure Compensation) .....	53
Default Settings .....	54
Functions That Can Be Set with the <b>MENU</b> Button (Shooting Menu) .....	56
Options Available in the Shooting Menu .....	57
Functions That Cannot Be Used Simultaneously .....	59
Focusing .....	63
Using Target Finding AF .....	63
Using Face Detection .....	64
Using Skin Softening .....	65
Subjects Not Suitable for Autofocus .....	65
Focus Lock .....	66
 Playback Features .....	 67
Playback Zoom .....	67
Thumbnail Playback, Calendar Display .....	68
Functions That Can Be Set with the <b>MENU</b> Button (Playback Menu) .....	69
 Recording and Playing Back Movies .....	 71
Recording Movies .....	71
Functions That Can Be Set with the <b>MENU</b> Button (Movie Menu) .....	75
Playing Back Movies .....	76
 General Camera Setup .....	 78
Functions That Can Be Set with the <b>MENU</b> Button (Setup Menu) .....	78
 Using the Wi-Fi (Wireless LAN) Function .....	 80
Functions That Can Be Performed Using Wi-Fi .....	80
Take Photos .....	80

View Photos .....	80
Installing the Software on the Smart Device .....	80
Connecting the Smart Device to the Camera.....	81
<b>Connecting the Camera to a TV, Computer, or Printer.....</b>	<b>83</b>
Connection Methods.....	83
Using ViewNX 2 .....	85
Installing ViewNX 2 .....	85
Transferring Images to the Computer .....	86
Viewing Images.....	88
<b>Reference Section .....</b>	<b>1 </b>
<b>Using Easy Panorama (Shooting and Playback) .....</b>	<b>2 </b>
Shooting with Easy Panorama.....	2 
Viewing Images Captured with Easy Panorama.....	4 
<b>Favorite Pictures Mode.....</b>	<b>5 </b>
Adding Images to Albums .....	5 
Playing Back Images in Albums .....	6 
Removing Images from Albums.....	7 
Changing the Favorites Album Icon .....	8 
<b>Auto Sort Mode .....</b>	<b>9 </b>
<b>List by Date Mode.....</b>	<b>10 </b>
<b>Viewing and Deleting Images Captured Continuously (Sequence).....</b>	<b>11 </b>
Viewing Images in a Sequence .....	11 
Deleting Images in a Sequence .....	12 
<b>Editing Still Images.....</b>	<b>13 </b>
Before Editing Images .....	13 
Quick Effects: Changing Hue or Mood .....	14 
Quick Retouch: Enhancing Contrast and Saturation .....	15 
D-Lighting: Enhancing Brightness and Contrast .....	15 
Red-eye Correction: Correcting Red-eye When Shooting with the Flash ...	16 
Glamour Retouch: Enhancing Human Faces.....	17 
Small Picture: Reducing the Size of an Image .....	18 
Crop: Creating a Cropped Copy .....	19 
<b>Connecting the Camera to a TV (Viewing Images on a TV) .....</b>	<b>20 </b>
<b>Connecting the Camera to a Printer (Direct Print).....</b>	<b>21 </b>
Connecting the Camera to a Printer .....	22 
Printing Individual Images.....	23 

Printing Multiple Images .....	25
<b>Editing Movies .....</b>	<b>27</b>
Extracting Only the Desired Portion of a Movie .....	27
Saving a Frame from a Movie as a Still Image .....	28
<b>The Shooting Menu (for  (Auto) Mode) .....</b>	<b>29</b>
Image Mode Settings (Image Size and Quality) .....	29
White Balance (Adjusting Hue) .....	31
Metering .....	33
Continuous Shooting .....	34
ISO Sensitivity .....	37
AF Area Mode .....	38
Autofocus Mode .....	41
Quick Effects .....	41
<b>The Smart Portrait Menu .....</b>	<b>42</b>
Skin Softening .....	42
Smile Timer .....	43
Blink Proof .....	44
<b>The Playback Menu .....</b>	<b>45</b>
Print Order (Creating a DPOF Print Order) .....	45
Slide Show .....	48
Protect .....	49
Rotate Image .....	50
Voice Memo .....	51
Copy (Copy Between Internal Memory and Memory Card) .....	52
Sequence Display Options .....	53
Choose Key Picture .....	53
<b>The Movie Menu .....</b>	<b>54</b>
Movie Options .....	54
Open with HS Footage .....	58
AF Area Mode .....	58
Autofocus Mode .....	59
Movie VR .....	60
Wind Noise Reduction .....	61
Frame Rate .....	61
<b>The Setup Menu .....</b>	<b>62</b>
Welcome Screen .....	62
Time Zone and Date .....	63
Monitor Settings .....	65
Print Date (Imprinting Date and Time) .....	67
Photo VR .....	68


Motion Detection.....	 69
AF Assist .....	 69
Digital Zoom .....	 70
Sound Settings .....	 71
Auto Off .....	 71
Format Memory/Format Card.....	 72
Language .....	 73
TV Settings.....	 73
Charge by Computer.....	 74
Blink Warning.....	 75
Eye-Fi Upload.....	 76
Reset All.....	 77
Firmware Version .....	 77
<b>The Wi-Fi Options Menu.....</b>	 78
<b>Error Messages.....</b>	 80
<b>File Names .....</b>	 84
<b>Optional Accessories .....</b>	 85
<hr/>	
<b>Technical Notes and Index.....</b>	 1
<hr/>	
<b>Caring for the Product .....</b>	 2
The Camera.....	 2
The Battery .....	 3
Charging AC Adapter .....	 4
Memory Cards.....	 5
<b>Cleaning and Storage.....</b>	 6
Cleaning .....	 6
Storage .....	 7
<b>Troubleshooting .....</b>	 8
<b>Specifications .....</b>	 17
Approved Memory Cards.....	 21
<b>Index.....</b>	 24




A series of horizontal dashed lines for handwriting practice, spanning the width of the page.

# Parts of the Camera


## The Camera Body



Flash raised




Lens cover closed



<b>1</b>	Mode dial.....	22
<b>2</b>	Shutter-release button.....	26
<b>3</b>	Power switch/power-on lamp.....	20
<b>4</b>	Microphone (stereo).....	69, 71
<b>5</b>	Flash.....	45
<b>6</b>	Zoom control.....	25
	<b>W</b> : wide-angle.....	25
	<b>T</b> : telephoto.....	25
	[checkered flag] : thumbnail playback.....	68
	[magnifying glass] : playback zoom.....	67
	[question mark] : help.....	34

<b>7</b>	Self-timer lamp.....	48
<b>8</b>	AF-assist illuminator.....	78
<b>9</b>	Speaker.....	76, 78
<b>10</b>	Lens cover.....	






1	Monitor .....	6, 20
2	<b>MENU</b> (menu) button .....	4
3	Rotary multi selector (multi selector)* .....	4
4	(apply selection) button .....	4
5	(playback) button .....	28
6	(delete) button .....	29, 77
7	Charge lamp .....	12
	Flash lamp .....	45
8	movie-record) button .....	71
9	Tripod socket	

10	Power connector cover (for connection with optional AC adapter) .....	85
11	Battery-chamber/ memory card slot cover .....	10, 14
12	HDMI connector cover .....	83
13	Eyelet for camera strap .....	3
14	USB connector cover .....	12, 83, 86
15	HDMI micro connector (Type D) .....	83
16	Micro-USB connector .....	12, 83, 86

\* Also referred to as the "multi selector" in this manual.

## Attaching the Camera Strap




# Using Menus (the MENU Button)

Use the multi selector and **OK** button to navigate the menus.


## 1 Press the **MENU** button.

- The menu is displayed.



## 2 Press the multi selector .


- The current menu icon is displayed in yellow.



Menu icons


## 3 Select the desired menu icon.

- The menu is changed.
- The menu icons can also be selected by rotating the multi selector.




## 4 Press the **OK** button.

- The menu options become selectable.




## 5 Select a menu option.

- The menu options can also be selected by rotating the multi selector.




## 6 Press the **OK** button.

- The settings for the option you selected are displayed.



## 7 Select a setting.

- The settings can also be selected by rotating the multi selector.




## 8 Press the **OK** button.

- The setting you selected is applied.
- When you are finished using the menu, press the **MENU** button.



### Notes About Setting Menu Options


- Certain menu options cannot be set depending on the current shooting mode or the state of the camera. Unavailable options are displayed in gray and cannot be selected.
- When a menu is displayed, you can switch to shooting mode by pressing the shutter-release button or  (movie-record) button.



# The Monitor

The information that is displayed in the monitor during shooting and playback changes depending on the camera's settings and state of use.


By default, information is displayed when the camera is first turned on and when you operate the camera, and turns off after a few seconds (when **Photo info** is set to **Auto info** in **Monitor settings** (78)).






















## Shooting Mode



<b>1</b>	Shooting mode.....	22, 23
<b>2</b>	Flash mode.....	45
<b>3</b>	Macro mode.....	49
<b>4</b>	Zoom indicator.....	25, 49
<b>5</b>	Focus indicator.....	26
<b>6</b>	Movie options (normal speed movies).....	75,  54
<b>7</b>	Movie options (HS movies).....	75,  55
<b>8</b>	Image mode.....	57,  29
<b>9</b>	Easy panorama.....	38
<b>10</b>	Vibration reduction icon.....	75, 78
<b>11</b>	Motion detection icon.....	78
<b>12</b>	Wind noise reduction.....	75
<b>13</b>	Exposure compensation value.....	51, 53
<b>14</b>	Movie recording time remaining.....	71
<b>15</b>	Number of exposures remaining (still images).....	20
<b>16</b>	Internal memory indicator.....	20
<b>17</b>	Aperture value.....	27
<b>18</b>	Focus area (target finding AF).....	26, 57, 63
<b>19</b>	Focus area (for manual or center).....	57, 66
<b>20</b>	Focus area (face detection, pet detection).....	39, 40, 57, 64
<b>21</b>	Focus area (subject tracking).....	57,  40
<b>22</b>	Center-weighted area.....	57
<b>23</b>	Shutter speed.....	27
<b>24</b>	ISO sensitivity.....	57
<b>25</b>	(a) Battery level indicator.....	20
	(b) Charging AC adapter connection indicator.....	
<b>26</b>	Print date.....	78
<b>27</b>	Travel destination icon.....	 64
<b>28</b>	"Date not set" indicator.....	16
<b>29</b>	Eye-Fi communication indicator.....	79
<b>30</b>	Wi-Fi communication indicator.....	80
<b>31</b>	White balance mode.....	57
<b>32</b>	Skin softening.....	58
<b>33</b>	Hue.....	52
<b>34</b>	Vividness.....	52
<b>35</b>	Quick effects icon.....	32, 57
<b>36</b>	Continuous shooting mode.....	57
<b>37</b>	Blink proof icon.....	58
<b>38</b>	Hand-held/tripod.....	35, 35
<b>39</b>	Backlighting (HDR).....	36
<b>40</b>	Self-timer indicator.....	48
<b>41</b>	Smile timer.....	58
<b>42</b>	Pet portrait auto release.....	39

# Playback Mode




<b>1</b>	Album icon in favorite pictures mode.....  5	<b>15</b>	Image mode ..... 57,  29
<b>2</b>	Category icon in auto sort mode .....  9	<b>16</b>	Easy panorama.....38
<b>3</b>	List by date icon.....  10	<b>17</b>	Movie options..... 75,  54
<b>4</b>	Protect icon ..... 69,  49	<b>18</b>	Small picture icon ..... 69,  18
<b>5</b>	Sequence display (when <b>Individual pictures</b> is selected) ..... 70,  53	<b>19</b>	Crop icon ..... 67,  19
<b>6</b>	Print order icon ..... 69,  45	<b>20</b>	Volume indicator ..... 76,  51
<b>7</b>	Voice memo indicator .... 69,  51	<b>21</b>	Quick effects guide ..... 28
<b>8</b>	Glamour retouch icon .... 69,  17		Easy panorama playback guide ..... 38,  4
<b>9</b>	Quick effects icon.....28, 32,  14	<b>22</b>	Sequence playback guide ..... 70,  11
<b>10</b>	D-Lighting icon..... 69,  15		Movie playback guide ..... 76
<b>11</b>	Quick retouch icon..... 69,  15	<b>23</b>	Time of recording
<b>12</b>	Red-eye correction ..... 69,  16	<b>24</b>	Date of recording
<b>13</b>	Internal memory indicator..... 20		(a) Battery level indicator.....20
<b>14</b>	(a) Current image number/ total number of images	<b>25</b>	(b) Charging AC adapter connection indicator
	(b) Movie length	<b>26</b>	File number and type .....  84
		<b>27</b>	Eye-Fi communication indicator ..... 79,  76

# The Basics of Shooting and Playback


## Preparation 1 Insert the Battery

- 1 Open the battery-chamber/memory card slot cover.



- 2 Insert the battery.

- Push the orange battery latch in the direction indicated by the arrow (①), and fully insert the battery (②).
- The battery locks into place when inserted correctly.




- ✓ Be Careful to Insert the Battery in Correct Direction**

*Inserting the battery upside down or backwards could damage the camera.*




- 3 Close the battery-chamber/memory card slot cover.



## Removing the Battery

Turn the camera off and make sure that the power-on lamp and the monitor have turned off, and then open the battery-chamber/memory card slot cover.

Move the battery latch in the direction indicated by the arrow (①) to eject the battery (②).



### High Temperature Caution

The camera, battery, and memory card may be hot immediately after using the camera.




## Preparation 2 Charge the Battery

### 1 Prepare the included charging AC adapter.

If a plug adapter\* is included with your camera, attach the plug adapter to the plug on the charging AC adapter. Push the plug adapter firmly until it is securely held in place. Once the two are connected, attempting to forcibly remove the plug adapter could damage the product.

\* The shape of the plug adapter varies according to the country or region in which the camera was purchased.

This step can be omitted if the plug adapter comes permanently bonded to the charging AC adapter.




### 2 Make sure the battery is installed in the camera, and then connect the camera to the charging AC adapter in order of ① to ③.

- Keep the camera turned off.
- Make sure that the plugs are properly oriented. Do not insert or remove the plugs at an angle when connecting or disconnecting them.



#### Notes

Do not use a USB cable other than the UC-E21. Using a USB cable other than the UC-E21 could result in overheating, fire or electric shock.



- The charge lamp slowly flashes green to indicate that the battery is charging.




Charge lamp	Description
Flashes slowly (green)	The battery is charging.
Off	When charging is complete, the charge lamp stops flashing green and turns off. About 2 hours and 20 minutes are required to charge a fully exhausted battery.
Flashes quickly (green)	<ul style="list-style-type: none"> <li>The ambient temperature is not suited to charging. Charge the battery indoors with an ambient temperature of 5°C to 35°C (41°F to 95°F).</li> <li>The USB cable or charging AC adapter is not properly connected, or there is a problem with the battery. Disconnect the USB cable or unplug the charging AC adapter and correctly connect it again, or change the battery.</li> </ul>

### 3 Disconnect the charging AC adapter from the electrical outlet and then disconnect the USB cable.

#### Notes About Charging


Do not, under any circumstances, use another make or model of AC adapter other than Charging AC Adapter EH-71P, and do not use a commercially available USB-AC adapter or a battery charger for a mobile phone. Failure to observe this precaution could result in overheating or in damage to the camera.

#### Charging Using a Computer or Battery Charger

- You can also charge the battery by connecting the camera to a computer ( 83,  74).
- You can use the Battery Charger MH-65 (available separately;  85) to charge the battery without using the camera.

## Preparation 3 Insert a Memory Card


- 1 Turn off the camera and open the battery-chamber/memory card slot cover.



- 2 Insert the memory card.

- Slide the memory card in until it clicks into place.

Memory card slot




- ☒ **Be Careful to Insert the Memory Card in Correct Direction**

*Inserting the memory card upside down or backwards could damage the camera and the memory card.*



- 3 Close the battery-chamber/memory card slot cover.




- ☒ **Formatting Memory Cards**

The first time you insert a memory card that has been used in another device into this camera, make sure to format it with this camera. Insert the card into the camera, press the **MENU** button, and select **Format card** in the setup menu.

## Removing Memory Cards

Turn the camera off and make sure that the power-on lamp and the monitor have turned off, and then open the battery-chamber/memory card slot cover.

Gently push the memory card into the camera (①) to partially eject the card (②).



### High Temperature Caution


The camera, battery, and memory card may be hot immediately after using the camera.

## Internal Memory and Memory Cards


Camera data, including images and movies, can be saved either in the camera's internal memory or on a memory card. To use the camera's internal memory, first remove the memory card.




## Preparation 4 Setting the Display Language, Date, and Time


When the camera is turned on for the first time, the language-selection screen and the date and time setting screen for the camera clock are displayed.


- If you exit without setting the date and time,  will flash when the shooting screen is displayed.


- 1 Press the power switch to turn on the camera.




- 2 Use the multi selector   to select the desired language and press the  button.




- 3 Select **Yes** and press the  button.




## 4 Select your home time zone and press the **OK** button.

- To enable daylight saving time, press **▲**. When the daylight saving time function is enabled,  is displayed above the map.

To turn off the daylight saving time function, press **▼**.




## 5 Select the date format and press the **OK** button.




## 6 Set the date and time, and press the **OK** button.

- Select a field: Press **◀▶** (changes between **D**, **M**, **Y**, **h**, and **m**).
- Edit the date and time: Press **▲▼**.  
Date and time can also be changed by rotating the multi selector.
- Confirm the setting: Select the **m** field and press the **OK** button.



## 7 Select **Yes** and press the **OK** button.

- When settings are finished, the lens extends and the camera switches to shooting mode.





## Changing the Language Setting and the Date and Time Setting

- You can change these settings using the **Language** and **Time zone and date** settings in the **Y** setup menu (📖78).
- You can enable or disable daylight saving time in the **Y** setup menu by selecting **Time zone and date** followed by **Time zone**. Enabling daylight saving time moves the clock forward one hour, and disabling it moves the clock back one hour.



## The Clock Battery

- The camera's clock is powered by a built-in backup battery. The backup battery charges when the main battery is inserted into the camera or when the camera is connected to an optional AC adapter, and it can run the clock for several days after about 10 hours of charging.
- If the camera's backup battery becomes exhausted, the date and time setting screen is displayed when the camera is turned on. Set the date and time again. See step 3 (📖16) of "Preparation 4 Setting the Display Language, Date, and Time" for more information.



## Imprinting the Shooting Date on Printed Images

- You can permanently imprint the shooting date on images as they are captured by setting **Print date** in the setup menu (📖78).
- If you want the shooting date to be printed without using the **Print date** setting, print using the ViewNX 2 software (📖85).




A series of horizontal dashed lines for handwriting practice, spanning the width of the page.

# Step 1 Turn the Camera On

## 1 Press the power switch.

- The monitor turns on.
- To turn the camera off, press the power switch again.






## 2 Check the battery level indicator and the number of exposures remaining.



Battery level indicator


Number of exposures remaining

### Battery level indicator

Display	Description
	The battery level is high.
	The battery level is low.
 <b>i</b> Battery exhausted.	The camera cannot capture images. Recharge the battery.


### Number of Exposures Remaining

The number of images that can be taken is displayed.

-  is displayed when no memory card is inserted in the camera, and images are saved in the internal memory.





## The Auto Off Function




- The time that elapses before the camera enters standby mode is about 1 minute. The time can be changed using the **Auto off** setting in the setup menu (78).
- While the camera is in standby mode, the monitor turns back on if you perform any of the following operations:
  - Press the power switch, shutter-release button, button, or (movie-record) button.
  - Rotate the mode dial.
- While the charging AC adapter is connected to the camera, the monitor turns back on if you press the power switch. The camera turns off if you operate the shutter-release button, mode dial, button, or (movie-record) button.

## Step 2 Select a Shooting Mode

Rotate the mode dial to select a shooting mode.

-  (auto) mode is used in this example.  
Rotate the mode dial to .



## Available Shooting Modes



### Auto mode

31

Used for general shooting. Settings can be adjusted to suit the shooting conditions and the type of shot you want to capture.



### SCENE, Scene mode

33

Camera settings are optimized according to the scene that you select. **SCENE** (scene auto selector): The camera automatically selects the optimum scene mode when you frame an image, making it even easier to take images using settings that suit the scene.

**SCENE** (scene): Press the **MENU** button to select a scene.

(night landscape): Captures the atmosphere of night landscapes.

(night portrait): Best suited to capture images of people with a night view in the background.

(backlighting): Fill flash fires to prevent the backlit subject from being hidden in shadow, or the HDR function can be used to shoot scenes with high contrast.



### Smart portrait

40

The camera detects smiling faces and releases the shutter automatically.

### EFFECTS

#### Special effects


42

Effects can be applied to images during shooting.

## Step 3 Frame a Picture

### 1 Hold the camera steady.


- Keep fingers and other objects away from the lens, flash, AF-assist illuminator, microphones, and speaker.
- When taking pictures in portrait ("tall") orientation, turn the camera so that the flash is above the lens.



### 2 Frame the picture.



#### When Using a Tripod

- We recommend using a tripod to stabilize the camera in the following situations.
  - When shooting in dim lighting
  - When shooting with the flash mode (📖47) set to  (off)
  - When using the telephoto setting
- When using a tripod to stabilize the camera during shooting, set **Photo VR** to **Off** in the setup menu (📖78) to prevent potential errors caused by this function.



## Using the Zoom

When you move the zoom control, the zoom lens position changes.

- To zoom in closer to the subject: Move toward **T** (telephoto)
- To zoom out and view a larger area: Move toward **W** (wide-angle)

When you turn the camera on, the zoom moves to the maximum wide-angle position.

- A zoom indicator is displayed at the top of the shooting screen when the zoom control is moved.
- Digital zoom, which allows you to further magnify the subject up to approximately 4× the maximum optical zoom ratio, can be activated by moving and holding the zoom control toward **T** when the camera is zoomed in to the maximum optical zoom position.



### Notes About Digital Zoom


The zoom indicator turns blue when the digital zoom is activated, and it turns yellow when the zoom magnification is increased further.

- Zoom indicator is blue: Image quality is not noticeably reduced by using the Dynamic Fine Zoom.
- Zoom indicator is yellow: Image quality is noticeably reduced.
- The indicator remains blue across a wider area when the image size is smaller.

## Step 4 Focus and Shoot

### 1 Press the shutter-release button halfway.

- When the subject is in focus, the focus area that includes the subject or focus indicator (📖7) glows green (multiple focus areas can glow green).
- When you are using digital zoom, the camera focuses on the subject in the center of the frame and the focus area is not displayed. When the camera has focused, the focus indicator (📖7) glows green.
- If the focus area or focus indicator flashes red, the camera is unable to focus. Modify the composition and try pressing the shutter-release button halfway again.




### 2 Without lifting your finger, press the shutter-release button the rest of the way down.



### 3 To apply an effect to the captured image, press the **OK** button.

- The screen for selecting an effect is displayed. See "Using Quick Effects" (📖32) for more information.
- When you press the **MENU** button or when no operations are performed for about 5 seconds, the monitor display returns to the shooting screen.
- To not display the screen shown on the right, set **Quick effects** to **Off** in the shooting menu (📖56).



## The Shutter-release Button

Press halfway



To set focus and exposure (shutter speed and aperture value), press the shutter-release button lightly until you feel a slight resistance. Focus and exposure remain locked while the shutter-release button is pressed halfway.

Press all the way



Press the shutter-release button all the way to release the shutter and take an image. Do not use force when pressing the shutter-release button, as this may result in camera shake and blurred images. Press the button gently.




### Notes About Saving Images and Recording Movies

The indicator showing the number of exposures remaining or the indicator showing the maximum movie length flashes while images are being saved or while a movie is being recorded. **Do not open the battery-chamber/memory card slot cover or remove the battery or memory card** while an indicator is flashing. Doing this could result in loss of data, or in damage to the camera or the memory card.




### Flash

- If the subject is dimly lit, the flash will pop up automatically when you press the shutter-release button halfway when the flash mode is set to **⚡ AUTO** (auto; default setting). The flash will fire when you press the shutter-release button all the way. See “Using the Flash” (📖45) for more information.
- Lower the flash by gently pushing it down. When not taking images, lower the flash.




## Step 5 Play Back Images

### 1 Press the (playback) button.

- If you press and hold down the  (playback) button while the camera is turned off, the camera turns on in playback mode.




### 2 Use the multi selector to select an image to display.

- Press and hold down     to scroll through the images quickly.
- Images can also be selected by rotating the multi selector.

Display the previous image











Display the next image

- To return to shooting mode, press the  button or shutter-release button.




### Notes About the Quick Effects Function

- When   is displayed in full-frame playback mode, you can press the  button to apply an effect to the image.
  - When the effect selection screen is displayed, use the multi selector   or rotate it to select an effect, press the  button, and then select **Yes** in the confirmation dialog and press the  button to save the image as a separate file.
- See “Quick Effects: Changing Hue or Mood” ( 14) for more information.






## Step 6 Delete Images


- 1 Press the  button to delete the image currently displayed in the monitor.



- 2 Use the multi selector   to select the desired deletion method and press the  button.
  - To exit without deleting, press the **MENU** button.



- 3 Select **Yes** and press the  button.
  - Deleted images cannot be recovered.
  - To cancel, select **No** and press the .



## Operating the Erase Selected Images Screen

- 1 Use the multi selector ◀▶ to select an image to be deleted, and then use ▲ to display 🗑️.

- To undo the selection, press ▼ to remove 🗑️.
- Move the zoom control (📖1) toward T (🔍) to switch to full-frame playback or W (🖼️) to switch to thumbnail playback.



- 2 Add 🗑️ to all images that you want to delete and then press the OK button to confirm the selection.

- A confirmation dialog is displayed. Follow the instructions displayed in the monitor.

### ✓ Deleting Images in a Sequence

- If you press the 🗑️ button and delete a key picture while only key pictures are displayed for sequences of images (📖70), all images in the sequence, including the key picture, are deleted.
- To delete individual images in a sequence, press the OK button to display them one at a time and press the 🗑️ button.



### 📎 Deleting the Last Image Captured While in Shooting Mode


When using shooting mode, press the 🗑️ button to delete the last image that was saved.

# Shooting Features






## (Auto) Mode

Used for general shooting. Settings can be adjusted to suit the shooting conditions and the type of shot you want to capture.


- You can change how the camera selects the area of the frame to focus on by changing the **AF area mode** setting ( 57). The default setting is **Target finding AF** (.



### Functions Available in (Auto) Mode


- Flash mode ( 45)
- Self-timer ( 48)
- Macro mode ( 49)
- Creative slider ( 50)
- Shooting menu ( 56)


## Using Quick Effects

When in  (auto) mode, you can apply effects to images immediately after releasing the shutter.






- The edited image is saved as a separate file with a different name.


### 1 Press the button when the image is displayed after it is taken in (auto) mode.

- When you press the **MENU** button or when no operations are performed for about 5 seconds, the monitor display returns to the shooting screen.
- To not display the screen shown on the right, set **Quick effects** to **Off** in the shooting menu ( 56).



### 2 Use the multi selector or rotate it to select the desired effect and press the button.


- Move the zoom control ( 1) toward **T** () to display a confirmation dialog for the applied effect. Move the zoom control toward **W** () to return to the selection screen for effects.
- To exit without saving the edited image, press the **MENU** button. When a confirmation dialog is displayed, select **Yes** and press the  button.
- See “Quick Effects: Changing Hue or Mood” ( 14) for information about the effect types.




### 3 Select **Yes** and press the button.


# Scene Mode (Shooting Suited to Scenes)


When a scene is selected, camera settings are automatically optimized for the selected scene.


 (Scene auto selector) (📖34)

When you frame a picture, the camera automatically selects the optimum scene for simpler shooting.



 (Night landscape) (📖35)<sup>1</sup>
















 (Night portrait) (📖35)



 (Backlighting) (📖36)<sup>2</sup>

Rotate the mode dial to  or  and take images.

## SCENE (Scene)

Press the **MENU** button to display the scene menu and select one of the following shooting scenes.

 Portrait (default setting)	 Close-up (📖37)
 Landscape <sup>1</sup>	 Food (📖37)
 Sports (📖36) <sup>2</sup>	 Museum (📖37) <sup>2</sup>
 Party/indoor (📖36) <sup>2</sup>	 Fireworks show (📖37) <sup>1, 3</sup>
 Beach <sup>2</sup>	 Black and white copy (📖37) <sup>2</sup>
 Snow <sup>2</sup>	 Easy panorama (📖38)
 Sunset <sup>2, 3</sup>	 Pet portrait (📖39)
 Dusk/dawn <sup>1, 3</sup>	



<sup>1</sup> The camera focuses at infinity.

<sup>2</sup> The camera focuses on the area in the center of the frame.

<sup>3</sup> Use of a tripod is recommended because the shutter speed is slow. Set **Photo VR** to **Off** in the setup menu (📖78) when using a tripod to stabilize the camera during shooting.











## To View a Description (Help Display) of Each Scene


Select a scene and move the zoom control (📖1) toward **T** (🔍) to view a description of that scene. To return to the original screen, move the zoom control toward **T** (🔍) again.

## Tips and Notes


### Scene auto selector

- When you point the camera at the subject, the camera automatically selects the optimum scene mode from the list below and adjusts the shooting settings accordingly.

	Portrait (for taking close-up portraits of one or two people)
	Portrait (for taking portraits of three or more people, or framing images with a large background size)
	Landscape
	Night portrait (for taking close-up portraits of one or two people)
	Night portrait (for taking portraits of three or more people, or framing images with a large background size)
	Night landscape
	Close-up
	Backlighting (for taking images of subjects other than people)
	Backlighting (for taking portrait images)
	Other scenes

- The focus area depends on the composition of the image. When the camera detects a human face, it focuses on that face (📖64).
- In some shooting conditions, the camera may not select the appropriate scene mode that you intended. If this happens, switch to  (auto) mode or select the scene mode that you want to use when taking images (📖22).

## Night landscape

- Press the **MENU** button to select **Hand-held** or **Tripod** in **Night landscape**.
- **Hand-held** (default setting):
  - When the  icon at the top left of the monitor glows green, press the shutter-release button all the way to capture a series of images which are combined into a single image and saved.
  - Once the shutter-release button is pressed all the way, hold the camera still until a still image is displayed. After taking an image, do not turn the camera off before the monitor switches to the shooting screen.
  - The angle of view (i.e., the area visible in the frame) seen in the saved image is narrower than that seen in the monitor at the time of shooting.
- **Tripod:**
  - One image is captured at a slow shutter speed when the shutter-release button is pressed all the way.
  - Vibration reduction is disabled regardless of the **Photo VR** (78) setting in the setup menu.

## Night portrait

- Press the **MENU** button to select **Hand-held** or **Tripod** in **Night portrait**.
- **Hand-held** (default setting):
  - When the  icon at the top left of the monitor glows green, press the shutter-release button all the way to capture a series of images which are combined into a single image and saved.
  - Once the shutter-release button is pressed all the way, hold the camera still until a still image is displayed. After taking an image, do not turn the camera off before the monitor switches to the shooting screen.
  - If the subject moves while the camera is shooting continuously, the image may be distorted, overlapped, or blurred.
- **Tripod:**
  - One image is captured at a slow shutter speed when the shutter-release button is pressed all the way.
  - Vibration reduction is disabled regardless of the **Photo VR** (78) setting in the setup menu.

## Backlighting

- Press the **MENU** button to select **On** or **Off** in **HDR** to enable or disable the high dynamic range (HDR) function based on the type of image you want to take.
- **Off** (default setting): The flash fires to prevent the subject from being hidden in shadow.
  - When the shutter-release button is pressed all the way down, one image is captured.
- **On**: Use when taking images with very bright and dark areas in the same frame.
  - When the shutter-release button is pressed all the way, the camera shoots images continuously at high speed, and saves the following two images.
    - A non-HDR composite image
    - An HDR composite image in which the loss of details in highlights or shadows is minimized
  - If there is only enough memory to save one image, an image processed by D-Lighting (p.69) at the time of shooting, in which dark areas of the image are corrected, is the only image saved.
  - Once the shutter-release button is pressed all the way, hold the camera still until a still image is displayed. After taking an image, do not turn the camera off before the monitor switches to the shooting screen.
  - The angle of view (i.e., the area visible in the frame) seen in the saved image is narrower than that seen in the monitor at the time of shooting.

## SCENE → Sports

- While the shutter-release button is held all the way down, the camera shoots up to about 5 images continuously at a rate of about 6.7 fps (when image mode is set to **16M 4608×3456**).
- The frame rate for continuous shooting may vary depending upon the current image mode setting, the memory card used, or shooting condition.
- Focus, exposure, and hue are fixed at the values determined with the first image in each series.

## SCENE → Party/indoor

- To avoid the effects of camera shake, hold the camera steady. Set **Photo VR** to **Off** in the setup menu (p.78) when using a tripod to stabilize the camera during shooting.

## SCENE → 🍷 Close-up

- Macro mode (📖49) is enabled and the camera automatically zooms to the closest position at which it can focus.
- You can move the focus area. Press the **OK** button, use the multi selector **▲▼◀▶** or rotate it to move the focus area, and press the **OK** button to apply the setting.

## SCENE → 🍴 Food

- Macro mode (📖49) is enabled and the camera automatically zooms to the closest position at which it can focus.
- You can adjust hue by using the multi selector **▲▼**. The hue setting is saved in the camera's memory even after the camera is turned off.
- You can move the focus area. Press the **OK** button, use the multi selector **▲▼◀▶** or rotate it to move the focus area, and press the **OK** button to apply the setting.



## SCENE → 🏛️ Museum

- The camera captures a series of up to 10 images while the shutter-release button is held all the way down, and the sharpest image in the series is automatically selected and saved (BSS (Best Shot Selector)).
- The flash does not fire.



## SCENE → ⚙️ Fireworks show

- The shutter speed is fixed at about 4 seconds.

## SCENE → 🖼️ Black and white copy

- Use together with macro mode (📖49) when shooting subjects that are close to the camera.

## SCENE → Easy panorama

- From the screen displayed after  **Easy panorama** is selected, select the shooting range from **Normal (180°)** or **Wide (360°)**.
- The zoom position is fixed at wide-angle.
- Press the shutter-release button all the way down, remove your finger from the button, and then slowly pan the camera horizontally. Shooting ends when the camera captures the specified shooting range.
- Focus and exposure are locked when shooting starts.
- If you press the  button when a captured image is displayed in full-frame playback mode, the image scrolls automatically.
- You cannot use any image editing functions other than cropping for images captured with easy panorama on this camera.

See “Using Easy Panorama (Shooting and Playback)” ( 2) for more information.




### **Notes About Printing Panorama Images**

The entire image may not be able to be printed depending on the printer's settings. Additionally, printing may not be possible depending on the printer.

## SCENE → 🐾 Pet portrait


- When you point the camera at a dog or cat, the camera detects the pet's face and focuses on it. By default, the shutter is automatically released when the camera detects a dog or cat face (pet portrait auto release).
- From the screen displayed after 🐾 **Pet portrait** is selected, select **Single** or **Continuous**.
  - **Single**: Whenever the camera detects a dog or cat face, the camera captures 1 image.
  - **Continuous**: Whenever the camera detects a dog or cat face, the camera captures 3 images continuously.

### ✓ **Pet Portrait Auto Release**

- Press the multi selector ◀ (📷) to change the **Pet portrait auto release** settings.
  - : When the camera detects a dog or cat face, the camera automatically releases the shutter.
  - **OFF**: The camera does not release the shutter automatically, even if a dog or cat face is detected. Press the shutter-release button. The camera also detects human faces when **OFF** is selected.
- **Pet portrait auto release** is set to **OFF** after five bursts have been taken.
- Shooting is also possible by pressing the shutter-release button, regardless of the **Pet portrait auto release** setting.


### ✓ **Focus Area**

- When the camera detects a face, the face is displayed inside a yellow border. When the camera acquires focus on a face displayed inside a double border (focus area), the double border turns green. If no faces are detected, the camera focuses on the subject in the center of the frame.
- In some shooting conditions, the pet face may not be detected and other subjects may be displayed inside a border.



# Smart Portrait Mode (Capturing Images of Smiling Faces)

When the camera detects a smiling face, you can take an image automatically without pressing the shutter-release button (smile timer (📖58)). You can use the skin softening option to smooth the skin tones of human faces.



## 1 Frame the picture.

- Point the camera at a human face.

## 2 Without pressing the shutter-release button, wait for the subject to smile.

- If the camera detects that the face framed by the double border is smiling, the shutter is automatically released.
- Whenever the camera detects a smiling face, it automatically releases the shutter.

## 3 End automatic shooting.

- Perform one of the operations listed below to end shooting.
  - Set **Smile timer** to **Off**.
  - Rotate the mode dial to switch to a shooting mode other than 📷 (smart portrait) mode.
  - Turn off the camera.

### ✓ Notes About Smart Portrait Mode

Under some shooting conditions, the camera may be unable to detect faces or detect smiles (📖64). The shutter-release button can also be used for shooting.



## **When the Self-timer Lamp Flashes**


When using smile timer, the self-timer lamp flashes when the camera detects a face and flashes quickly immediately after the shutter is released.

## **Functions Available in Smart Portrait Mode**

- Flash mode (📖45)
- Self-timer (📖48)
- Exposure compensation (📖53)
- Shooting menu (📖56)




## Special Effects Mode (Applying Effects When Shooting)







Effects can be applied to images during shooting.




Press the **MENU** button to display the special effects menu and select an effect using the multi selector.

Category	Description
<b>SOFT</b> Soft (default setting)	Softens the image by adding a slight blur to the entire image.
<b>SEPIA</b> Nostalgic sepia	Adds a sepia tone and reduces the contrast to simulate the qualities of an old photograph.
High-contrast monochrome	Changes the image to black and white and gives it sharp contrast.
High key	Gives the entire image a bright tone.
Low key	Gives the entire image a dark tone.
Selective color	Creates a black and white image in which only the specified color remains.
<b>POP</b> Pop	Increases the color saturation of the entire image to create a bright look.
<b>VI</b> Super vivid	Increases the color saturation of the entire image and sharpens the contrast.

Category	Description
 Cross process	Gives the image a mysterious appearance based on a specific color.
 Toy camera effect 1	Gives the entire image a yellowish hue and darkens the image periphery.
 Toy camera effect 2	Decreases the color saturation of the entire image and darkens the image periphery.


- The camera focuses on the area in the center of the frame.
- When **Selective color** or **Cross process** is selected, use the multi selector ▲▼ to select the desired color from the slider.  
To change settings for any of the following functions, press the  button to cancel color selection.
  - Flash mode ( 45)
  - Self-timer ( 48)
  - Macro mode ( 49)
  - Exposure compensation ( 53)
 To return to the color selection screen, press the  button again.



Slider

# Functions That Can Be Set Using the Multi Selector

The functions that are available vary with the shooting mode, as shown below.




Function		SCENE,		EFFECTS
1  Flash mode (📖45)	✓	*	✓*	✓
2  Self-timer (📖48)	✓		✓*	✓
3  Macro mode (📖49)	✓		-	✓
4  Creative slider ( Brightness (Exp. +/-)/ Vividness/ Hue) (📖50)	✓		-	-
Exposure compensation (📖53)	-		✓	✓

\* Availability depends on the setting. See "Default Settings" (📖54) for more information.

# Using the Flash


You can select the flash mode to match the shooting conditions.

- 1 Press the multi selector **▲** (⚡).



- 2 Select the desired flash mode (book 47) and press the **OK** button.

- If a setting is not applied by pressing the **OK** button within a few seconds, the selection will be canceled.



## ✓ The Flash Lamp


- The status of the flash can be confirmed by pressing the shutter-release button halfway.
  - On: The flash fires when you press the shutter-release button all the way down.
  - Flashing: The flash is charging. The camera cannot shoot images.
  - Off: The flash does not fire when an image is taken.
- If the battery level is low, the monitor turns off while the flash is charging.



## Raising the Flash


When you press the shutter-release button halfway, the flash will automatically pop up if the conditions required for flash photography are met.

- Auto flash (⚡ **AUTO** auto, ⚡👁 auto with red-eye reduction, or ⚡ **SLOW** slow sync): If the lighting is dim, the flash automatically pops up when the shutter-release button is pressed halfway. The camera determines whether or not the flash pops up based on the brightness of the subject and the settings used during shooting.
- 🚫 off: The flash does not pop up, even when the shutter-release button is pressed halfway. The camera can shoot pictures with the flash lowered.
- ⚡ fill flash: The flash pops up when the shutter-release button is pressed halfway during shooting.



## Lowering the Flash

When not using the flash, gently push to lower the flash until it clicks shut.



## Available Flash Modes



### Auto

The flash fires when necessary, such as in dim lighting.

- The flash mode icon on the shooting screen is displayed only immediately after the setting is made.



### Auto with red-eye reduction

Reduce “red-eye” in portraits caused by the flash.



### Off

The flash does not fire.

- We recommend using a tripod to stabilize the camera when shooting in dark surroundings.



### Fill flash

The flash fires whenever an image is taken. Use to “fill-in” (illuminate) shadows and backlit subjects.



### Slow sync

Suited to evening and night portraits that include background scenery. The flash fires when necessary to illuminate the main subject; slow shutter speeds are used to capture background at night or under dim lighting.



## The Flash Mode Setting

- The setting may not be available with some shooting modes.
- The setting applied in (auto) mode is saved in the camera’s memory even after the camera is turned off.



## Auto with Red-eye Reduction

Pre-flashes are fired repeatedly at low intensity before the main flash, reducing the red-eye effect. If the camera detects red-eye while saving an image, the affected area is processed to reduce red-eye before the image is saved.


Note the following when shooting:

- Because pre-flashes are fired, there is a slight lag between when the shutter-release button is pressed and when the image is shot.
- More time than usual is required to save images.
- Red-eye reduction may not produce the desired results in all situations.
- In some rare cases, red-eye reduction may be applied unnecessarily to other areas of the image. In these cases, select another flash mode and take the image again.

## Using the Self-timer


The camera is equipped with a self-timer that releases the shutter about 10 seconds or 2 seconds after you press the shutter-release button. Set **Photo VR** to **Off** in the setup menu (📖78) when using a tripod to stabilize the camera during shooting.

### 1 Press the multi selector ◀ (⏸).



### 2 Select ⏸ 10s or ⏸ 2s, and press the OK button.

- ⏸ 10s (10 seconds): Use on important occasions, such as weddings.
- ⏸ 2s (2 seconds): Use to prevent camera shake.
- If a setting is not applied by pressing the OK button within a few seconds, the selection will be canceled.
- When the shooting mode is **Pet portrait** scene mode, 🐾 (pet portrait auto release) is displayed (📖39). The self-timer cannot be used.




### 3 Frame the picture and press the shutter-release button halfway.

- Focus and exposure are set.

### 4 Press the shutter-release button the rest of the way down.


- Countdown starts. The self-timer lamp flashes and then glows steadily about one second before the shutter is released.
- When the shutter is released, the self-timer is set to **OFF**.
- To stop the countdown, press the shutter-release button again.



# Using Macro Mode


Use macro mode when taking close-up images.

- 1 Press the multi selector ▼ (🌸).



- 2 Select ON and press the (OK) button.

- If a setting is not applied by pressing the (OK) button within a few seconds, the selection will be canceled.



- 3 Move the zoom control to set the zoom ratio to a position where 🌸 and the zoom indicator glow green.



- When the zoom ratio is set to a position where the zoom indicator glows green, the camera can focus on subjects as close as approximately 10 cm (4 in.) from the lens.  
When the zoom is at the position where 🌸 is displayed, the camera can focus on subjects as close as approximately 1 cm (0.4 in.) from the lens.

## ✓ Notes About Using the Flash

The flash may be unable to light the entire subject at distances of less than 50 cm (1 ft 8 in.).

## 📎 The Macro Mode Setting


- The setting may not be available with some shooting modes.
- The setting applied in 📷 (auto) mode is saved in the camera's memory even after the camera is turned off.

## Adjusting Brightness (Exposure Compensation), Vividness, and Hue (Creative Slider)

When the shooting mode is set to (auto) mode, use the creative slider to adjust brightness (exposure compensation), vividness, and hue for taking images.


### Operating the Creative Slider

- 1 Press the multi selector .



- 2 Select the item you want to adjust and make an adjustment.

- : Select an item.
  - : "Adjusting Brightness (Exposure Compensation)" (book icon 51)
  - : "Adjusting Vividness (Saturation Adjustment)" (book icon 52)
  - : "Adjusting Hue (White Balance Adjustment)" (book icon 52)



- or rotation: The slider moves. The effect can be adjusted while confirming the results on the monitor.
- To turn off the effects of the creative slider, select **R** and press the button.

- 3 When adjustment is complete, select and press the button.

- If the (except when **R** is selected) or the shutter-release button is pressed in step 2, the selected amount of effect is applied. When the effect is applied, the camera returns to the shooting screen.




### Creative Slider Settings

The settings for Brightness (Exp. +/-) (exposure compensation), Vividness and Hue are saved in the camera's memory even after the camera is turned off.

## Adjusting Brightness (Exposure Compensation)

Adjust the overall brightness of the image.

- To brighten the image, set a positive (+) value.
- To darken the image, set a negative (–) value.



### Using the Histogram


A histogram is a graph showing the distribution of tones in the image. Use as a guide when using exposure compensation and shooting without the flash.

- The horizontal axis corresponds to pixel brightness, with dark tones to the left and bright tones to the right. The vertical axis shows the number of pixels.
- Increasing exposure compensation shifts tone distribution to the right, and decreasing it shifts tone distribution to the left.

## Adjusting Vividness (Saturation Adjustment)

Adjust the overall vividness of the image.


- The overall image vividness increases as the slider is moved up. The overall image vividness decreases as the slider is moved down.



## Adjusting Hue (White Balance Adjustment)

Adjust the overall hue of the image.

- The overall image becomes more reddish as the slider is moved up. The overall image becomes more bluish as the slider is moved down.




### Notes About White Balance Adjustment

The setting may not be changed when using certain settings of other functions.

# Adjusting Brightness (Exposure Compensation)


When the shooting mode is set to scene mode, smart portrait mode or special effects mode, you can adjust the brightness (exposure compensation).

- 1 Press the multi selector ► (⏏).



- 2 Select a compensation value and press the **OK** button.

- To brighten the image, set a positive (+) value.
- To darken the image, set a negative (-) value.
- The compensation value is applied, even without pressing the **OK** button.



## Exposure Compensation Value

- When the shooting mode is **Fireworks show** (📖37) in scene mode, the exposure compensation cannot be used.
- When the exposure compensation is set while using the flash, the compensation is applied to both the background exposure and to the flash output.














## Default Settings

Default settings for each shooting mode are described below.

Shooting mode	Flash ( <a href="#">45</a> )	Self-timer ( <a href="#">48</a> )	Macro ( <a href="#">49</a> )	Creative slider ( <a href="#">50</a> )
(auto)	AUTO	OFF	OFF	Off

Shooting mode	Flash ( <a href="#">45</a> )	Self-timer ( <a href="#">48</a> )	Macro ( <a href="#">49</a> )	Exposure compensation ( <a href="#">53</a> )
(smart portrait)	AUTO <sup>1</sup>	OFF <sup>2</sup>	OFF <sup>3</sup>	0.0
<b>EFFECTS</b> (special effects)		OFF	OFF	0.0


Shooting mode	Flash ( <a href="#">45</a> )	Self-timer ( <a href="#">48</a> )	Macro ( <a href="#">49</a> )	Exposure compensation ( <a href="#">53</a> )
(scene auto selector)	AUTO <sup>4</sup>	OFF	OFF <sup>5</sup>	0.0
(night landscape)	<sup>3</sup>	OFF	OFF <sup>3</sup>	0.0
(night portrait)	<sup>3</sup>	OFF	OFF <sup>3</sup>	0.0
(backlighting)	<sup>6</sup>	OFF	OFF <sup>3</sup>	0.0
<b>SCENE</b>				
(portrait)		OFF	OFF <sup>3</sup>	0.0
(landscape)	<sup>3</sup>	OFF	OFF <sup>3</sup>	0.0
(sports)	<sup>3</sup>	OFF <sup>3</sup>	OFF <sup>3</sup>	0.0
(party/indoor)	<sup>7</sup>	OFF	OFF <sup>3</sup>	0.0
(beach)	AUTO	OFF	OFF <sup>3</sup>	0.0
(snow)	AUTO	OFF	OFF <sup>3</sup>	0.0
(sunset)	<sup>3</sup>	OFF	OFF <sup>3</sup>	0.0
(dusk/dawn)	<sup>3</sup>	OFF	OFF <sup>3</sup>	0.0
(close-up)	<sup>3</sup>	OFF	ON <sup>3</sup>	0.0
(food)	<sup>3</sup>	OFF	ON <sup>3</sup>	0.0
(museum)	<sup>3</sup>	OFF	OFF	0.0


Shooting mode	Flash (  45)	Self-timer (  48)	Macro (  49)	Exposure compensation (  53)
 (fireworks show)	 <sup>3</sup>	OFF <sup>3</sup>	OFF <sup>3</sup>	0.0 <sup>3</sup>
 (black and white copy)		OFF	OFF	0.0
 (easy panorama)	 <sup>3</sup>	OFF <sup>3</sup>	OFF <sup>3</sup>	0.0
 (pet portrait)	 <sup>3</sup>	 <sup>8</sup>	OFF	0.0



<sup>1</sup> Cannot be used when **Blink proof** is set to **On** or when **Smile timer** is set to **On (continuous)** or **On (BSS)**.

<sup>2</sup> Can be set when **Smile timer** is set to **Off**.


<sup>3</sup> The setting cannot be changed.

<sup>4</sup> The camera automatically selects the flash mode appropriate for the scene it has selected.  (off) can be selected manually.

<sup>5</sup> Cannot be changed. The camera enters macro mode when  is selected.


<sup>6</sup> Flash is fixed at  (fill flash) when **HDR** is set to **Off**, and is fixed at  (off) when **HDR** is set to **On**.

<sup>7</sup> Slow sync with red-eye reduction flash mode may be used.

<sup>8</sup> Self-timer cannot be used. Pet portrait auto release can be turned on or off ( 39).

# Functions That Can Be Set with the MENU Button (Shooting Menu)

The settings listed below can be changed by pressing the **MENU** button during shooting (📖4).
















Available functions vary depending on the shooting mode, as shown below.





Function		SCENE, 2		EFFECTS
Image mode <sup>1</sup>	✓	✓	✓	✓
White balance	✓	–	–	–
Metering	✓	–	–	–
Continuous	✓	–	–	–
ISO sensitivity	✓	–	–	–
AF area mode	✓	–	–	–
Autofocus mode	✓	–	–	–
Quick effects	✓	–	–	–
Skin softening	–	–	✓	–
Smile timer	–	–	✓	–
Blink proof	–	–	✓	–

<sup>1</sup> The setting is also applied to other shooting modes.

<sup>2</sup> Additional settings are available for some scene modes. See “Tips and Notes” (📖34) for more information.

## Options Available in the Shooting Menu

Option	Description	
Image mode	Allows you to set the combination of image size and image quality used when saving images. • Default setting:  <b>4608×3456</b>	 29
White balance	Allows you to adjust white balance to suit the weather conditions or light source in order to make the colors in images match what you see with your eyes. • Default setting: <b>Auto</b>	 31
Metering	Allows you to set the method that the camera uses to measure the brightness of the subject. • Default setting: <b>Matrix</b>	 33
Continuous	Allows you to select single or continuous shooting. • Default setting: <b>Single</b>	 34
ISO sensitivity	Allows you to control the camera's sensitivity to light. • Default setting: <b>Auto</b> When <b>Auto</b> is selected,  is displayed in the monitor while shooting if ISO sensitivity increases.	 37
AF area mode	Allows you to determine how the camera selects the focus area that is used for autofocus. • Default setting: <b>Target finding AF</b> (  63)	 38
Autofocus mode	Allows you to set the method how the camera focuses. • Default setting: <b>Pre-focus</b>	 41
Quick effects	Allows you to enable or disable the quick effects function (  32). • Default setting: <b>On</b>	 41

Option	Description	
Skin softening	Allows you to select the skin softening level for human faces. • Default setting: <b>Normal</b>	 42
Smile timer	Allows you to select whether or not the camera automatically releases the shutter when it detects a human smiling face. • Default setting: <b>On (single)</b>	 43
Blink proof	The camera automatically releases the shutter twice with every shot and saves one image in which the subject's eyes are open. • Default setting: <b>Off</b>	 44

## Functions That Cannot Be Used Simultaneously

Some functions cannot be used with other menu options.

Restricted function	Option	Description
Flash mode	Continuous (📖57)	When a setting other than <b>Single</b> is selected, the flash cannot be used.
	Blink proof (📖58)	When <b>Blink proof</b> is set to <b>On</b> , the flash cannot be used.
Self-timer	Smile timer (📖58)	When <b>Smile timer</b> is selected, the self-timer cannot be used.
	AF area mode (📖57)	When <b>Subject tracking</b> is selected, the self-timer cannot be used.
Macro mode	AF area mode (📖57)	When <b>Subject tracking</b> is selected, macro mode cannot be used.
Image mode	Continuous (📖57)	<p><b>Image mode</b> is fixed as follows depending on the continuous shooting setting:</p> <ul style="list-style-type: none"> <li>• <b>Pre-shooting cache:</b>  <b>1M</b> (image size: 1280 × 960 pixels)</li> <li>• <b>Continuous H: 120 fps:</b>  <b>VGA 640×480</b></li> <li>• <b>Continuous H: 60 fps:</b>  <b>1M</b> (image size: 1280 × 960 pixels)</li> <li>• <b>Multi-shot 16:</b>  <b>5M</b> (image size: 2560 × 1920 pixels)</li> </ul>
White balance	Hue (using the creative slider) (📖50)	When hue is adjusted using the creative slider, <b>White balance</b> in the shooting menu cannot be set. To set <b>White balance</b> , select <b>R</b> in the creative slider setting screen to reset the brightness, vividness, and hue.
Continuous	Self-timer (📖48)	If the self-timer is used when <b>Pre-shooting cache</b> is selected, <b>Continuous</b> operates using the <b>Single</b> setting.

Restricted function	Option	Description
ISO sensitivity	Continuous (📖57)	When <b>Pre-shooting cache</b> , <b>Continuous H: 120 fps</b> , <b>Continuous H: 60 fps</b> , or <b>Multi-shot 16</b> is selected, the <b>ISO sensitivity</b> setting is automatically specified according to the brightness.
AF area mode	White balance (📖57)	When a setting other than <b>Auto</b> is selected for <b>White balance</b> in <b>Target finding AF</b> mode, the camera does not detect the main subject.
Quick effects	Continuous (📖57)	The quick effects function cannot be used for images with continuous shooting.
Smile timer	Blink proof (📖58)	When <b>Blink proof</b> is set to <b>On</b> , <b>Smile timer</b> operates using the <b>On (single)</b> setting if <b>On (continuous)</b> or <b>On (BSS)</b> is set.
Blink proof	Smile timer (📖58)	When <b>Smile timer</b> is set to <b>On (continuous)</b> or <b>On (BSS)</b> , <b>Blink proof</b> operates using the <b>Off</b> setting.
Monitor settings	Quick effects (📖57)	When <b>Quick effects</b> is set to <b>On</b> , the captured image is displayed after each shot regardless of the <b>Image review</b> setting.
Print date	Continuous (📖57)	When <b>Continuous H</b> , <b>Continuous L</b> , <b>Pre-shooting cache</b> , <b>Continuous H: 120 fps</b> , <b>Continuous H: 60 fps</b> or <b>BSS</b> is selected, date and time cannot be imprinted on images.
	Smile timer (📖58)	When <b>Smile timer</b> is set to <b>On (continuous)</b> or <b>On (BSS)</b> , date and time cannot be imprinted on images.
	Blink proof (📖58)	When <b>Blink proof</b> is set to <b>On</b> , date and time cannot be imprinted on images.

Restricted function	Option	Description
Photo VR	Flash mode (📖45)	If the flash fires when <b>On (hybrid)</b> is selected, <b>Photo VR</b> operates using the <b>On</b> setting.
	Self-timer (📖48)	If the self-timer is used when <b>On (hybrid)</b> is selected, <b>Photo VR</b> operates using the <b>On</b> setting.
	Continuous (📖57)	If <b>Continuous</b> is set to any setting other than <b>Single</b> when <b>On (hybrid)</b> is selected, <b>Photo VR</b> operates using the <b>On</b> setting.
	ISO sensitivity (📖57)	If <b>ISO sensitivity</b> is set to <b>Fixed range auto</b> or ISO 400 or higher when <b>On (hybrid)</b> is selected, <b>Photo VR</b> operates using the <b>On</b> setting.
	Motion detection (📖78)	If <b>Motion detection</b> is set to <b>Auto</b> when <b>On (hybrid)</b> is selected, <b>Photo VR</b> operates using the <b>On</b> setting.
Motion detection	Flash mode (📖45)	When the flash fires, <b>Motion detection</b> is disabled.
	Continuous (📖57)	When <b>Pre-shooting cache</b> , <b>Continuous H: 120 fps</b> , <b>Continuous H: 60 fps</b> or <b>Multi-shot 16</b> is selected, <b>Motion detection</b> is disabled.
	ISO sensitivity (📖57)	When <b>ISO sensitivity</b> is set to any setting other than <b>Auto</b> , <b>Motion detection</b> is disabled.
Blink warning	Continuous (📖57)	When a setting other than <b>Single</b> is selected, <b>Blink warning</b> is disabled.

Restricted function	Option	Description
Digital zoom	Continuous (📖57)	When <b>Multi-shot 16</b> is selected, digital zoom cannot be used.
	AF area mode (📖57)	When <b>Subject tracking</b> is selected, digital zoom cannot be used.
Shutter sound	Continuous (📖57)	When a setting other than <b>Single</b> is selected, the shutter sound is disabled.



### Notes About Digital Zoom

- Depending on the shooting mode or the current settings, digital zoom may not be available (📖70).
- When digital zoom is in effect, the camera focuses in the center of the frame.


# Focusing

The focus area varies depending on the shooting mode.

## Using Target Finding AF


When **AF area mode** (📖57) in 📷 (auto) mode is set to **Target finding AF**, the camera focuses in the manner described below.

- When the camera detects the main subject, a yellow border (focus area) is displayed around it. If a human face is detected, the camera automatically sets focus priority on it. When you press the shutter-release button halfway, the focus area that is in focus glows green.



Focus areas

- If no main subject is detected, the camera automatically selects one or more of the 9 focus areas containing the subject closest to the camera when you press the shutter-release button halfway. When the subject is in focus, the focus areas that are in focus glow green.



Focus areas


### ✓ Notes About Target Finding AF

- Depending on shooting conditions, the subject that the camera determines to be the main subject may vary.
- The main subject may not be detected when using certain **White balance** settings.
- The camera may not detect the main subject appropriately in the following situations:
  - When the subject is very dark or bright
  - When the main subject lacks clearly defined colors
  - When the shot is framed so that the main subject is at the edge of the monitor
  - When the main subject is composed of a repeating pattern

## Using Face Detection

In the following shooting modes, the camera uses face detection to automatically focus on human faces.

- **SCN** (scene auto selector) mode (34)
- **[Night Portrait]** (night portrait) mode (35)
- **Portrait** scene mode (33)
- Smart portrait mode (40)
- When **AF area mode** (57) in **[Auto]** mode (31) is set to **Face priority**.



If the camera detects more than one face, a double border is displayed around the face that the camera focuses on, and single borders are displayed around the other faces.

If the shutter-release button is pressed halfway when no faces are detected:

- In **SCN** (scene auto selector) mode, the focus area changes depending on the scene.
- In **[Night Portrait]** mode, **Portrait** scene mode or smart portrait mode, the camera focuses on the area in the center of the frame.
- In **[Auto]** mode, the camera selects the focus area containing the subject closest to the camera.



### Notes About Face Detection

- The camera's ability to detect faces depends on a variety of factors, including the direction in which the faces are looking.
- The camera may be unable to detect faces in the following situations:
  - When faces are partially hidden by sunglasses or otherwise obstructed
  - When faces take up too much or too little of the frame





### Face Detection During Movie Recording

When **AF area mode** (75) in the movie menu is set to **Face priority**, the camera focuses on human faces during movie recording.

If the **[Movie Record]** button is pressed when no faces are detected, the camera focuses on the area in the center of the frame.

## Using Skin Softening

When the shutter is released while using one of the shooting modes listed below, the camera detects human faces and processes the image to soften facial skin tones (up to 3 faces).

- Smart portrait mode (📖40)
  - The skin softening level can be adjusted.
-  (scene auto selector) mode (📖34)
-  (night portrait) mode (📖35)
- **Portrait** scene mode (📖33)

Editing functions such as **Skin softening** can be applied to saved images by using **Glamour retouch** (📖69) even after shooting.

### Notes About Skin Softening

- It may take more time than usual to save images after shooting.
- Under some shooting conditions, the desired skin softening results may not be achieved, and skin softening may be applied to areas of the image where there are no faces.

## Subjects Not Suitable for Autofocus

The camera may not focus as expected in the following situations. In some rare cases, the subject may not be in focus despite the fact that the focus area or the focus indicator glows green:

- Subject is very dark
- Objects of sharply differing brightness are included in the scene (e.g. the sun behind the subject makes that subject appear very dark)
- No contrast between the subject and surroundings (e.g. a portrait subject wearing a white shirt is standing in front of a white wall)
- Several objects are at different distances from the camera (e.g. the subject is inside a cage)
- Subjects with repeating patterns (window blinds, buildings with multiple rows of similarly shaped windows, etc.)
- Subject is moving rapidly

In the situations noted above, try pressing the shutter-release button halfway to refocus several times, or focus on another subject positioned at the same distance from the camera as the actual desired subject, and use focus lock (📖66).


## Focus Lock

Focus lock shooting is recommended when the camera does not activate the focus area that contains the desired subject.

**1** Set **AF area mode** to **Center** in  (auto) mode ( 56).


**2** Position the subject in the center of the frame and press the shutter-release button halfway.

- Confirm that the focus area glows green.
- Focus and exposure are locked.



**3** Without lifting your finger, recompose the picture.

- Make sure to maintain the same distance between the camera and the subject.




**4** Press the shutter-release button the rest of the way down to take the picture.



# Playback Features

## Playback Zoom

Moving the zoom control toward **T** (Q) in full-frame playback mode (📖28) zooms in on the image.



- You can change the zoom ratio by moving the zoom control toward **W** (checkered icon) or **T** (Q).
- To view a different area of the image, press the multi selector ▲▼◀▶.
- If you are viewing an image that was captured using face detection or pet detection, the camera zooms in on the face detected at the time of shooting (except when viewing an image captured in a series). To zoom in on an area of the image where there are no faces, adjust the zoom ratio and then press ▲▼◀▶.
- When a zoomed image is displayed, press the **OK** button to return to full-frame playback mode.

### Cropping Images

When a zoomed image is displayed, you can press the **MENU** button to crop the image to include only the visible portion and save it as a separate file (🔑19).

# Thumbnail Playback, Calendar Display

Moving the zoom control toward **W** (🔍) in full-frame playback mode (📖28) displays images as thumbnails.





- You can change the number of thumbnails displayed by moving the zoom control toward **W** (🔍) or **T** (🔍).
- While using thumbnail playback mode, use the multi selector ▲▼◀▶ or rotate it to select an image, and then press the **OK** button to display that image full-frame.
- While using calendar display mode, use the multi selector ▲▼◀▶ or rotate it to select a date, and then press the **OK** button to display the images captured on that day.

## ✓ Calendar Display








Images captured when the camera's date is not set are treated as images captured on January 1, 2014.

## Functions That Can Be Set with the MENU Button (Playback Menu)

When viewing images in full-frame playback mode or thumbnail playback mode, you can configure the menu operations listed below by pressing the **MENU** button (📖4).



Option	Description	📖
Quick retouch*	Allows you to create retouched copies in which contrast and saturation have been enhanced.	👁️15
D-Lighting*	Allows you to create copies with enhanced brightness and contrast, brightening dark portions of an image.	👁️15
Red-eye correction*	Corrects “red-eye” that may occur in images when shooting with a flash.	👁️16
Glamour retouch*	Detects faces in images and retouches the detected faces glamorously.	👁️17
Print order	Allows you to select which images are printed, and how many copies of each image are printed, prior to printing.	👁️45
Slide show	Allows you to view images in an automatic slide show.	👁️48
Protect	Protects selected images from accidental deletion.	👁️49
Rotate image	Allows you to rotate the displayed image to portrait or landscape orientation.	👁️50
Small picture*	Creates a small copy of images.	👁️18
Voice memo	Allows you to use the camera’s microphones to record voice memos and attach them to images.	👁️51
Copy	Allows you to copy images between the internal memory and a memory card.	👁️52

Option	Description	
Sequence display options	<p>Allows you to select whether to display only the key picture for a sequence of images captured continuously or to display the sequence as individual images.</p> <ul style="list-style-type: none"> <li>When only the key picture is displayed for a sequence, press the  button to display each image in the sequence. Press the multi selector  to return to the key picture display.</li> </ul>	 53
Choose key picture	Allows you to change the key picture for images captured in sequence.	 53
Favorite pictures	<p>Allows you to add images to an album.</p> <p>This option is not displayed in favorite pictures mode.</p>	 5
Remove from favorites	<p>Allows you to remove images from an album.</p> <p>This option is displayed only in favorite pictures mode.</p>	 7


\* Edited images are saved as separate files. Some images may not be edited.

# Recording and Playing Back Movies

## Recording Movies

### 1 Display the shooting screen.

- Check the remaining amount of movie recording time.
- If **Photo info** in the **Monitor settings** (p.78) in the setup menu is set to **Movie frame+auto info**, the area that will be visible in the movie can be confirmed before movie recording starts.







Movie recording time remaining

### 2 Press the movie-record button to start movie recording.

- The focus area for autofocus differs depending on the setting of **AF area mode** (p.75).

The default setting is **Face priority**.

- Press the multi selector  to pause recording, and press  again to resume recording (except when  **iFrame 720/30p** or an HS movie option is selected in **Movie options**). Recording automatically ends if it remains paused for about five minutes.



### 3 Press the movie-record button again to end recording.

## ✓ Maximum Movie Length

Individual movie files cannot exceed 4 GB in size or 29 minutes in length, even when there is sufficient free space on the memory card for longer recording.

- The maximum movie length for a single movie is displayed on the shooting screen.
- Recording may end before either limit is reached if camera temperature becomes elevated.
- The actual movie length may vary depending on the movie content, subject movement, or type of memory card.

## ✓ Notes About Saving Images and Recording Movies

The indicator showing the number of exposures remaining or the indicator showing the maximum movie length flashes while images are being saved or while a movie is being recorded. **Do not open the battery-chamber/memory card slot cover or remove the battery or memory card** while an indicator is flashing. Doing this could result in loss of data, or in damage to the camera or the memory card.

## ✓ Notes About Movie Recording

- Memory cards with an SD Speed Class rating of 6 or faster are recommended when recording movies (P.21). Movie recording may stop unexpectedly when memory cards with a lower Speed Class rating are used.
- When using the camera's internal memory, saving movies may take some time.
- There may be some degradation in image quality when digital zoom is used.
- The sounds of zoom control operation, zoom, autofocus lens drive movement, vibration reduction, and aperture operation when brightness changes may be recorded.
- The following phenomena may be seen in the monitor while recording movies. These phenomena are saved in the recorded movies.
  - Banding may occur in images under fluorescent, mercury-vapor, or sodium-vapor lighting.
  - Subjects that move quickly from one side of the frame to the other, such as a moving train or car, may appear skewed.
  - The entire movie image may be skewed when the camera is panned.
  - Lighting or other bright areas may leave residual images when the camera is moved.
- Depending on the distance to the subject or the amount of zoom applied, subjects with repeating patterns (fabrics, lattice windows, etc.) may have colored stripes (interference patterns, moire, etc.) in them during movie recording and playback. This occurs when the pattern in the subject and the layout of the image sensor interfere with each other; it is not a malfunction.

## ✓ Notes About Vibration Reduction During Movie Recording

- When **Movie VR** (📖75) in the movie menu is set to **On (hybrid)**, the angle of view (i.e., the area visible in the frame) becomes narrower during movie recording.
- When using a tripod to stabilize the camera during recording, set **Movie VR** to **Off** to prevent potential errors caused by this function.

## ✓ Camera Temperature

- The camera may become warm when shooting movies for an extended period of time or when the camera is used in a hot area.
- If the inside of the camera becomes extremely hot when recording movies, the camera will automatically stop recording.  
The amount of time remaining until the camera stops recording (🕒10s) is displayed.  
After the camera stops recording, it turns itself off.  
Leave the camera off until the inside of the camera has cooled.




## ✓ Notes About Autofocus


Autofocus may not perform as expected (📖65). Should this occur, try the following:

1. Set **AF area mode** to **Center** and **Autofocus mode** to **Single AF** (default setting) in the movie menu before starting movie recording.
2. Frame another subject—positioned at the same distance from the camera as the intended subject—in the center of the frame, press the ● (📹 movie-record) button to start recording, and then modify the composition.





## Saving Still Images While Recording Movies

If the shutter-release button is pressed all the way while recording a movie, one frame is saved as a still image. Movie recording continues while the still image is being saved.

-  is displayed at the top left of the monitor. When  is displayed, a still image cannot be saved.
- The image size of the still images to be saved is the same as the **Movie options** () setting.




### Notes About Saving Still Images During Movie Recording











- Still images cannot be saved during movie recording in the following situations.
  - When movie recording is paused
  - When the remaining movie length is less than 5 seconds
  - When **Movie options** is set to  **1080/60i**,  **1080/50i**,  **480/30p**,  **480/25p** or HS movie
- Frames of a movie that were recorded when a still image was being taken may not be played back in a seamless manner.
- The sounds of operating the shutter-release button when saving a still image may be heard in the recorded movie.
- If the camera moves when the shutter-release button is pressed, the image may be blurred.

## Functions That Can Be Set with the MENU Button (Movie Menu)



Enter shooting mode → MENU button →  menu icon →  button


The settings of the menu options listed below can be configured.





Option	Description	
Movie options	Select the movie type. Select normal speed to record movies at normal speed, or HS (high speed) to record movies that play in slow or fast motion. • Default setting:  <b>1080/30p</b>  <b>1080/25p</b>	 54
Open with HS footage	Set whether to start recording HS movies or at normal speed when recording HS movies. • Default setting: <b>On</b>	 58
AF area mode	Set the method how the camera selects the focus area for autofocus during movie recording. • Default setting: <b>Face priority</b>	 58
Autofocus mode	Select either <b>Single AF</b> , which locks focus when movie recording begins, or <b>Full-time AF</b> , which continues focusing during movie recording. • Default setting: <b>Single AF</b>	 59
Movie VR	Select the vibration reduction setting used when recording movies. • Default setting: <b>On (hybrid)</b>	 60
Wind noise reduction	Set whether or not to reduce wind noise during movie recording. • Default setting: <b>Off</b>	 61
Frame rate	Select the frame rate used when recording movies.	 61

## Playing Back Movies


Press the  button to enter playback mode.  
Movies are indicated by the movie options icon  
(75).

Press the  button to play back movies.

- To adjust the volume, move the zoom control  
(1).



Movie options





Volume indicator














## Functions Available During Playback

Rotate the multi selector to fast forward or rewind.

Playback controls are displayed at the bottom of the monitor.

The operations listed below can be performed by using the multi selector  to select a control and then pressing the  button.



Function	Icon	Description
Rewind		Hold down the  button to rewind the movie.
Advance		Hold down the  button to advance the movie.
Pause		Pause playback. The operations listed below can be performed while paused.
		 Rewind the movie one frame. Hold down the  button for continuous rewinding.*
		 Advance the movie one frame. Hold down the  button for continuous advancing.*
		 Resume playback.
		 Extract the desired portion of a movie and save it as a separate file.
		 Extract a single frame of a movie and save it as a still image.
End		Return to full-frame playback mode.

\* The movie can also be advanced or rewound by rotating the multi selector.

## Deleting Movies


To delete a movie, select the desired movie in full-frame playback mode (28) or thumbnail playback mode (68) and press the  button (29).

# General Camera Setup










## Functions That Can Be Set with the MENU Button (Setup Menu)

Press the **MENU** button → **Y** (setup) menu icon → **OK** button

The settings of the menu options listed below can be configured.



Option	Description	
Welcome screen	Allows you to select whether or not the welcome screen is displayed in the monitor when the camera is turned on.	62
Time zone and date	Allows you to set the camera clock.	63
Monitor settings	Allows you to adjust photo information display, post-shooting image review, and monitor brightness settings.	65
Print date	Allows you to imprint the shooting date and time on images.	67
Photo VR	Allows you to select the vibration reduction setting used when shooting still images.	68
Motion detection	Allows you to set whether or not the camera automatically increases the shutter speed to reduce blurring caused by camera shake if motion is detected when shooting still images.	69
AF assist	Allows you to enable or disable the AF-assist illuminator.	69
Digital zoom	Allows you to enable and disable digital zoom.	70
Sound settings	Allows you to adjust sound settings.	71
Auto off	Allows you to set the amount of time that passes before the monitor turns off to save power.	71

Option	Description	
<b>Format memory/ Format card</b>	Allows you to format the internal memory or the memory card.	 72
<b>Language</b>	Allows you to change the camera's display language.	 73
<b>TV settings</b>	Allows you to adjust TV-connection settings.	 73
<b>Charge by computer</b>	Allows you to set whether or not the battery in the camera is charged when the camera is connected to a computer.	 74
<b>Blink warning</b>	Allows you to set whether or not closed eyes are detected when taking images of people using face detection.	 75
<b>Eye-Fi upload</b>	Allows you to set whether or not to enable the function for sending images to a computer using a commercially available Eye-Fi card.	 76
<b>Reset all</b>	Allows you to reset the camera's settings to their default values.	 77
<b>Firmware version</b>	View the current camera firmware version.	 77

# Using the Wi-Fi (Wireless LAN) Function

## Functions That Can Be Performed Using Wi-Fi

You can perform the following functions if you install the dedicated software “Wireless Mobile Utility” on your smart device that runs on Android OS or iOS, and connect it to the camera.

### Take Photos

You can take still images using the two methods described below.

- Release the shutter on the camera and save the captured images to a smart device.
- Use a smart device to remotely\* release the camera shutter and save images to the smart device.

\* Operations cannot be performed on the camera during remote control operation.

### View Photos

You can copy the images saved in the camera’s memory card and view them on your smart device.

## Installing the Software on the Smart Device



- 1** Use your smart device to connect to Google Play Store, App Store or other online apps marketplace and search for “Wireless Mobile Utility.”
  - Check the user’s manual provided with your smart device for further details.
- 2** Check the description and other information and install the software.
  - For more information about how to operate the software, download the user’s manual from the website below.
    - Android OS: <http://nikonimglib.com/MandL/WMAU/>
    - iOS: <http://nikonimglib.com/MandL/WMAU-ios/>

# Connecting the Smart Device to the Camera


Press the MENU button →  menu icon →  button

## 1 Use the multi selector ▲▼ to select **Connect to smart device** and press the button.

- If **Connect to smart device** cannot be selected, see “Notes About Wi-Fi Connection” (82).
- When the Wi-Fi function is turned on, the SSID and password of the camera are displayed.
- If no connection confirmation is received from the smart device within 3 minutes, the message “No access.” is displayed and the camera returns to the Wi-Fi options screen.



## 2 Set the Wi-Fi setting on the smart device to On.

- Check the user's manual provided with your smart device for further details.
- After the network name (SSID) that can be used for the smart device is displayed, select the SSID displayed on the camera.
- When the message for entering a password is displayed, enter the password that is displayed on the camera.
- When the camera is successfully connected to a Wi-Fi network, the shooting screen is displayed on the camera with the Wi-Fi communication indicator (7).

## 3 Start the “Wireless Mobile Utility” installed on the smart device.

- The screen for selecting “Take photos” or “View photos” is displayed.
- When the message “Cannot connect to camera.” is displayed, return to step 1 and retry the procedure.



## To Terminate the Wi-Fi Connection

Perform one of the following operations.

- Turn off the camera.
- Select **Disable Wi-Fi** in the Wi-Fi options menu on the camera (except when the camera is operated by remote control).
- Set the Wi-Fi setting on the smart device to Off.



### Notes About Wi-Fi Connection

- **Connect to smart device** cannot be selected in the following situations:
  - When no memory card is inserted in the camera.
  - When an Eye-Fi card (E76) is inserted in the camera.
  - When the camera is connected to a TV, computer, or printer.
  - When the battery level indicator in the monitor indicates . In addition, if  is indicated when Wi-Fi is connected, the connection is terminated.
- Select **Disable Wi-Fi** in a place where the use of radio waves is prohibited.
- When Wi-Fi is connected, **Auto off** is disabled.
- When Wi-Fi is connected, the battery drains faster than normal.



### Notes About Security Settings


If the camera is installed with the Wi-Fi function without proper security settings (encryption and password), unauthorized third parties may access the network and cause harm. We strongly recommend performing the required security settings before using the Wi-Fi function.

Use **Options** of the Wi-Fi options menu (E78) to perform the security settings.

# Connecting the Camera to a TV, Computer, or Printer

## Connection Methods

You can enhance your enjoyment of images and movies by connecting the camera to a TV, computer, or printer.



- Before connecting the camera to an external device, make sure the remaining battery level is sufficient and turn the camera off. Before disconnecting, make sure to turn the camera off.
- If the AC Adapter EH-62F (available separately) is used, this camera can be powered from an electrical outlet. Do not use any other make or model of AC adapter as it may cause the camera to heat up or malfunction.
- For information about the connection methods and subsequent operations, refer to the documentation included with the device in addition to this document.

## Viewing images on a TV

20



Images and movies captured with the camera can be viewed on a TV.

Connection method: Connect a commercially available HDMI cable to the TV's HDMI input jack.

## Viewing and organizing images on a computer

86



You can transfer images to a computer to perform simple retouching and manage image data.

Connection method: Connect the camera to the computer's USB port with the USB cable.

- Before connecting to a computer, install ViewNX 2 on the computer (85).
- If any USB devices that draw the power from the computer are connected, disconnect them from the computer before you connect the camera to it. Connecting the camera and other USB-powered devices to the same computer simultaneously may cause a camera malfunction or excessive power supply from the computer, which could damage the camera or memory card.

## Printing images without using a computer

22



If you connect the camera to a PictBridge-compatible printer, you can print images without using a computer.

Connection method: Connect the camera directly to the printer's USB port with the USB cable.

## Using ViewNX 2

Install ViewNX 2 to upload, view, edit, and share photos and movies.

### Your Imaging Toolbox

ViewNX 2™



## Installing ViewNX 2

An Internet connection is required. For system requirements and other information, see the Nikon website for your region.

### 1 Download the ViewNX 2 installer.

Start the computer and download the installer from:  
<http://nikonimglib.com/nvnx/>

### 2 Double-click the downloaded file.

### 3 Follow the on-screen instructions.

### 4 Exit the installer.


Click **Yes** (Windows) or **OK** (Mac).

# Transferring Images to the Computer

## 1 Choose how images will be copied to the computer.

Choose one of the following methods:

- **Direct USB connection:** Turn the camera off and ensure that the memory card is inserted in the camera. Connect the camera to the computer using the USB cable. The camera automatically turns on.  
To transfer images that are saved in the camera's internal memory, remove the memory card from the camera before connecting it to the computer.



- **SD card slot:** If your computer is equipped with an SD card slot, the card can be inserted directly in the slot.
- **SD card reader:** Connect a card reader (available separately from third-party suppliers) to the computer and insert the memory card.

If a message is displayed prompting you to choose a program, select Nikon Transfer 2.

### • When using Windows 7

If the dialog shown at right is displayed, follow the steps below to select Nikon Transfer 2.

- 1 Under **Import pictures and videos**, click **Change program**. A program selection dialog will be displayed; select **Import File using Nikon Transfer 2** and click **OK**.
- 2 Double-click **Import File**.




If the memory card contains a large number of images, it may take a while for Nikon Transfer 2 to start. Wait until Nikon Transfer 2 starts.

## ✓ Connecting the USB Cable

The connection may not be recognized if the camera is connected to the computer via a USB hub.

## 2 Transfer images to the computer.

- Click **Start Transfer**.



- At default settings, all the images on the memory card will be copied to the computer.


## 3 Terminate the connection.

- If the camera is connected to the computer, turn the camera off and disconnect the USB cable.
- If you are using a card reader or card slot, choose the appropriate option in the computer operating system to eject the removable disk corresponding to the memory card and then remove the card from the card reader or card slot.

# Viewing Images

## Start ViewNX 2.

- Images are displayed in ViewNX 2 when transfer is complete.
- Consult online help for more information on using ViewNX 2.



### Starting ViewNX 2 Manually

- **Windows:** Double-click the **ViewNX 2** shortcut on the desktop.
- **Mac:** Click the **ViewNX 2** icon in the Dock.



# Technical Notes and Index

<b>Caring for the Product.....</b>	<b>2</b>
The Camera.....	2
The Battery.....	3
Charging AC Adapter.....	4
Memory Cards.....	5
<b>Cleaning and Storage.....</b>	<b>6</b>
Cleaning.....	6
Storage.....	7
<b>Troubleshooting.....</b>	<b>8</b>
<b>Specifications.....</b>	<b>17</b>
Approved Memory Cards.....	21
<b>Index.....</b>	<b>24</b>

# Caring for the Product

## The Camera

To ensure continued enjoyment of this Nikon product, observe the precautions described below in addition to the warnings in "For Your Safety" (📖vii-ix) when using or storing the device.



### Do Not Drop

The product may malfunction if subjected to strong shock or vibration.



### Handle the Lens and All Moving Parts with Care

Do not apply force to the lens, lens cover, monitor, memory card slot, or battery chamber. These parts are easily damaged. Applying force to the lens cover could result in camera malfunction or damage to the lens. Should the monitor break, care should be taken to avoid injury caused by broken glass and to prevent the liquid crystal from the display touching the skin or entering the eyes or mouth.



### Keep Dry

The device will be damaged if immersed in water or subjected to high humidity.



### Avoid Sudden Changes in Temperature

Sudden changes in temperature, such as when entering or leaving a heated building on a cold day, can cause condensation to form inside the device. To prevent condensation, place the device in a carrying case or a plastic bag before exposing it to sudden changes in temperature.



### Keep away from Strong Magnetic Fields

Do not use or store this device in the vicinity of equipment that generates strong electromagnetic radiation or magnetic fields. Strong static charge or the magnetic fields produced by equipment such as radio transmitters could interfere with the monitor, damage data saved on the memory card, or affect the product's internal circuitry.



### Do Not Point the Lens at Strong Light Sources for Extended Periods

Avoid pointing the lens at the sun or other strong light sources for extended periods when using or storing the camera. Intense light may cause deterioration of the image sensor, producing a white blur effect in photographs.



## Turn the Product off Before Removing or Disconnecting the Power Source

Do not remove the battery while the product is on, or while images are being saved or deleted. Forcibly cutting power in these circumstances could result in loss of data or in damage to product memory or internal circuitry.



## Notes About the Monitor

- Monitors and electronic viewfinders are constructed with extremely high precision; at least 99.99% of pixels are effective, with no more than 0.01% being missing or defective. Hence while these displays may contain pixels that are always lit (white, red, blue, or green) or always off (black), this is not a malfunction and has no effect on images recorded with the device.
- Images in the monitor may be difficult to see under bright lighting.
- The monitor is lit by an LED backlight. Should the monitor begin to dim or flicker, contact your Nikon-authorized service representative.

## The Battery

Be sure to read and follow the warnings in “For Your Safety” (📖vii-ix) before use.

- Check the battery level before using the camera and replace or charge the battery if necessary. Do not continue charging once the battery is fully charged as this will result in reduced battery performance. Whenever possible, carry a fully charged spare battery when taking images on important occasions.
- Do not use the battery at ambient temperatures below 0°C (32°F) or above 40°C (104°F).
- Charge the battery indoors with an ambient temperature of 5°C to 35°C (41°F to 95°F) before use.
- When charging the battery inserted into this camera using the charging AC adapter or a computer, the battery is not charged at battery temperatures below 0°C (32°F) or above 45°C (113°F).
- Note that the battery may become hot during use; wait for the battery to cool before charging. Failure to observe these precautions could damage the battery, impair its performance, or prevent it from charging normally.
- On cold days, the capacity of batteries tends to decrease. If an exhausted battery is used at a low temperature, the camera will not turn on. Be sure that the battery is fully charged before heading outside to take images in cold weather. Keep spare batteries in a warm place and exchange as necessary. Once warmed, a cold battery may recover some of its charge.
- Dirt on the battery terminals can prevent the camera from functioning. Should the battery terminals become dirty, wipe them off with a clean, dry cloth before use.


- If the battery will not be used for some time, insert it in the camera and completely exhaust it before removing it for storage. The battery should be stored in a cool location with an ambient temperature of 15°C to 25°C (59°F to 77°F). Do not store the battery in hot or extremely cold locations.
- Always remove the battery from the camera or optional battery charger when it is not being used. When inserted, minute amounts of current are drawn from the battery even when not in use. This may result in excessive draining of the battery and complete loss of function. Turning the camera on or off while the battery is exhausted can result in reduced battery life.
- Recharge the battery at least once every six months and completely exhaust it before returning it to storage.
- After removing the battery from the camera or optional battery charger, put the battery in a plastic bag, etc. to insulate the terminal and store it in a cool place.
- A marked drop in the time a fully-charged battery retains its charge, when used at room temperature, indicates that the battery needs to be replaced. Purchase a new EN-EL12 battery.
- Replace the battery when it no longer holds a charge. Used batteries are a valuable resource. Please recycle used batteries in accordance with local regulations.

## Charging AC Adapter

Be sure to read and follow the warnings in “For Your Safety” (📖vii-ix) before use.

- The Charging AC Adapter EH-71P is for use only with compatible devices. Do not use with another make or model of device.
- Do not use a USB cable other than the UC-E21. Using a USB cable other than the UC-E21 could result in overheating, fire or electric shock.
- Do not, under any circumstances, use another make or model of AC adapter other than Charging AC Adapter EH-71P, and do not use a commercially available USB-AC adapter or a battery charger for a mobile phone. Failure to observe this precaution could result in overheating or in damage to the camera.
- The EH-71P is compatible with AC 100-240 V, 50/60 Hz electrical outlets. When using in other countries, use a plug adapter (available commercially) as necessary. For more information about plug adapters, consult your travel agency.

## Memory Cards

- Use only Secure Digital memory cards. See “Approved Memory Cards” (p. 21) for recommended memory cards.
- Observe the precautions noted in the documentation included with your memory card.
- Do not affix labels or stickers to the memory card.
- Do not format the memory card using a computer.
- The first time you insert a memory card that has been used in another device into this camera, be sure to format it with this camera. We recommend formatting new memory cards with this camera before using them with this camera.
- Note that **formatting a memory card permanently deletes all images and other data on the memory card**. If there is data saved on the memory card that you wish to keep, copy that data to a computer before formatting.
- If the message **Card is not formatted. Format card?** is displayed when the camera is turned on, the memory card must be formatted. If there is data on the memory card that you do not want to delete, select **No** and press the  button. Copy that data to a computer before formatting. To format the memory card, select **Yes**.
- Observe the following precautions while formatting the memory card, saving and deleting images, and copying images to a computer, otherwise data or the memory card itself may be damaged.
  - Do not open the battery-chamber/memory card slot cover or remove the memory card or battery.
  - Do not turn off the camera.
  - Do not disconnect the AC adapter.

# Cleaning and Storage

## Cleaning

Do not use alcohol, thinner, or other volatile chemicals.

Lens	Avoid touching glass parts with your fingers. Remove dust or lint with a blower (typically a small device with a rubber bulb attached to one end that is pumped to produce a stream of air out the other end). To remove fingerprints or other stains that cannot be removed with a blower, wipe the lens with a soft cloth, using a spiral motion that starts at the center of them and working toward the edges. If this fails, clean the lens using a cloth lightly dampened with commercial lens cleaner.
Monitor	Remove dust or lint with a blower. To remove fingerprints and other stains, clean the monitor with a soft, dry cloth, being careful not to apply pressure.
Body	Use a blower to remove dust, dirt, or sand, then wipe gently with a soft, dry cloth. After using the camera at the beach or other sandy or dusty environment, wipe off any sand, dust, or salt with a dry cloth lightly dampened with fresh water and dry thoroughly. <b><i>Note that foreign matter inside the camera could cause damage not covered by the warranty.</i></b>

## Storage

Turn the camera off when not in use. Be sure that the power-on lamp is off before putting the camera away. Remove the battery if the camera will not be used for an extended period. Do not store the camera with naphtha or camphor moth balls, or in any of the following locations:

- Next to equipment that produces strong electromagnetic fields, such as televisions or radios
- Exposed to temperatures below  $-10^{\circ}\text{C}$  ( $14^{\circ}\text{F}$ ) or above  $50^{\circ}\text{C}$  ( $122^{\circ}\text{F}$ )
- Places that are poorly ventilated or subject to humidity of over 60%




To prevent mold or mildew, take the camera out of storage at least once a month. Turn the camera on and release the shutter a few times before putting the camera away again.










For storing the battery, follow the precautions in "The Battery" (🔋:3) in "Caring for the Product" (🔧:2).





# Troubleshooting

If the camera fails to function as expected, check the list of common problems below before consulting your retailer or Nikon-authorized service representative.




## Power, Display, Settings Issues









Problem	Cause/Solution	
The camera is on but does not respond.	<ul style="list-style-type: none"> <li>• Wait for recording to end.</li> <li>• If the problem persists, turn the camera off. If the camera does not turn off, remove and reinsert the battery or batteries or, if you are using an AC adapter, disconnect and reconnect the AC adapter.</li> </ul> <p>Note that although any data currently being recorded will be lost, data that have already been recorded will not be affected by removing or disconnecting the power source.</p>	– 20,  85
Battery inserted in the camera cannot be charged.	<ul style="list-style-type: none"> <li>• Confirm all connections.</li> <li>• When connected to a computer, the camera may not charge for any of the reasons described below.               <ul style="list-style-type: none"> <li>- <b>Off</b> is selected for <b>Charge by computer</b> in the setup menu.</li> <li>- Battery charging stops if the camera is turned off.</li> <li>- Battery charging is not possible if the camera's display language and date and time have not been set, or the date and time were reset after the camera's clock battery was exhausted. Use the charging AC adapter to charge the battery.</li> <li>- Battery charging may stop if the computer is in sleep mode.</li> <li>- Depending upon the computer specifications, settings, and status, battery charging may not be possible.</li> </ul> </li> </ul>	12  79,  74 – 16, 18  – –
Camera cannot be turned on.	The battery is exhausted.	20














Problem	Cause/Solution	
Camera turns off without warning.	<ul style="list-style-type: none"> <li>The camera automatically turns off to save power (auto off function).</li> <li>The camera or battery has become too cold and cannot operate properly.</li> <li>The inside of the camera has become hot. Leave the camera off until the inside of the camera has cooled, and then try turning it on again.</li> <li>The camera turns off if the USB cable connecting it to a computer or printer is disconnected. Reconnect the USB cable.</li> </ul>	21  3 – 83, 86,  22
Monitor is blank.	<ul style="list-style-type: none"> <li>The camera is off.</li> <li>The camera has entered standby mode to save power. Press the power switch, shutter-release button,  button, or  (movie-record) button, or rotate the mode dial.</li> <li>The flash lamp flashes while the flash is charging. Wait for the flash to charge.</li> <li>The camera and computer are connected via the USB cable.</li> <li>The camera and TV are connected via an HDMI cable.</li> <li>The camera and smart device are connected using Wi-Fi connection and the camera is operated by remote control.</li> </ul>	20 1, 21 45 83, 86 83,  20 80
Monitor is hard to read.	<ul style="list-style-type: none"> <li>Adjust the monitor brightness.</li> <li>The monitor is dirty. Clean the monitor.</li> </ul>	78,  65  6
Date and time of recording are not correct.	<ul style="list-style-type: none"> <li>If the camera clock has not been set, the "Date not set" indicator flashes during shooting and movie recording. Images and movies saved before the clock is set are dated "00/00/0000 00:00" or "01/01/2014 00:00" respectively. Set the correct time and date from the <b>Time zone and date</b> option in the setup menu.</li> <li>The camera clock is not as accurate as ordinary watches or clocks. Periodically compare the time of the camera clock with that of a more accurate timepiece and reset as required.</li> </ul>	16, 78,  63

















Problem	Cause/Solution	
No indicators displayed in monitor.	<b>Hide info</b> is selected for <b>Photo info</b> in <b>Monitor settings</b> in the setup menu.	78,  65
<b>Print date</b> not available.	<b>Time zone and date</b> has not been set in the setup menu.	16, 78,  63
Date not imprinted on images even when <b>Print date</b> is enabled.	<ul style="list-style-type: none"> <li>The current shooting mode does not support <b>Print date</b>.</li> <li>A function that restricts the print date is enabled.</li> <li>The date cannot be imprinted on movies.</li> </ul>	 67  59  –
Screen for setting time zone and date is displayed when camera is turned on.	The clock battery is exhausted; all settings were restored to their default values.	16, 18
Camera settings reset.		
Camera becomes hot.	The camera may become hot when used for an extended period of time to record movies or send images using an Eye-Fi card, or when used in a hot environment; this is not a malfunction.	–
Camera makes sound.	Depending on the <b>Autofocus mode</b> setting or the shooting mode, the camera may produce an audible focusing sound.	57, 75
Unable to select a menu	<ul style="list-style-type: none"> <li>Some functions cannot be used with other menu options.</li> <li>Some menus are not available when Wi-Fi is connected. Terminate the Wi-Fi connection.</li> </ul>	59
		82


## Shooting Issues

Problem	Cause/Solution	
Cannot switch to shooting mode.	Disconnect the HDMI cable or USB cable.	83, 86,  20,  22





Problem	Cause/Solution	
No image captured when the shutter-release button is pressed.	<ul style="list-style-type: none"> <li>When the camera is in playback mode, press the  button, the shutter-release button, or the  button.</li> <li>When menus are displayed, press the <b>MENU</b> button.</li> <li>The battery is exhausted.</li> <li>When the flash lamp is flashing, the flash is charging.</li> <li>The camera and smart device are connected using Wi-Fi connection and the camera is operated by remote control.</li> </ul>	1, 28  4  20 45  80
Camera cannot focus.	<ul style="list-style-type: none"> <li>The subject is too close. Try shooting using , <b>Close-up</b> scene mode, or macro mode.</li> <li>The subject is hard to focus on.</li> <li>Set <b>AF assist</b> in the setup menu to <b>Auto</b>.</li> <li>Turn the camera off and then on again.</li> </ul>	34, 37, 49  65 78,  69 20
Images are blurred.	<ul style="list-style-type: none"> <li>Use the flash.</li> <li>Increase the ISO sensitivity value.</li> <li>Enable vibration reduction or motion detection.</li> <li>Use <b>BSS</b> (Best Shot Selector).</li> <li>Use a tripod to stabilize the camera when shooting (using the self-timer at the same time is more effective).</li> </ul>	45 57 78  37, 57,  34 48
Bright specks appear in images captured with flash.	The flash is reflecting off particles in the air. Set the flash mode setting to  (off).	47
Flash does not fire.	<ul style="list-style-type: none"> <li>The flash mode is set to  (off).</li> <li>A shooting mode that restricts the flash is selected.</li> <li><b>On</b> is selected for <b>Blink proof</b> in the smart portrait menu.</li> <li><b>On (continuous)</b> or <b>On (BSS)</b> is selected for <b>Smile timer</b> in the smart portrait menu.</li> <li>A function that restricts the flash is enabled.</li> </ul>	45 54  58 58  59







Problem	Cause/Solution	
Digital zoom cannot be used.	<ul style="list-style-type: none"> <li>• <b>Digital zoom</b> is set to <b>Off</b> or <b>Crop</b> in the setup menu.</li> <li>• Digital zoom cannot be used in the following situations. <ul style="list-style-type: none"> <li>- When the scene mode is  (scene auto selector),  (night landscape),  (night portrait),  (backlighting) with <b>HDR</b> set to <b>On</b>, <b>Portrait</b>, <b>Easy panorama</b> or <b>Pet portrait</b></li> <li>- When smart portrait mode is selected</li> <li>- When <b>Continuous</b> in the shooting menu is set to <b>Multi-shot 16</b></li> <li>- When <b>AF area mode</b> in the shooting menu is set to <b>Subject tracking</b></li> </ul> </li> <li>• Other functions that restrict the use of digital zoom are set.</li> </ul>	78,  70  33  40 57,  34 57,  38 59
<b>Image mode</b> not available.	A function that restricts the <b>Image mode</b> option is enabled.	59
No sound when shutter is released.	<b>Off</b> is selected for <b>Sound settings</b> > <b>Shutter sound</b> in the setup menu. No sound is produced with some shooting modes and settings, even when <b>On</b> is selected.	78,  71
AF-assist illuminator does not light.	<b>Off</b> is selected for the <b>AF assist</b> option in the setup menu. AF-assist illuminator may not light depending on the position of the focus area or the current scene mode, even when <b>Auto</b> is selected.	78,  69
Images appear smeared.	The lens is dirty. Clean the lens.	 6
Colors are unnatural.	White balance or hue is not adjusted properly.	37, 57,  31
Randomly spaced bright pixels ("noise") appear in image.	The subject is dark, and the shutter speed is too slow or ISO sensitivity is too high. Noise can be reduced by: <ul style="list-style-type: none"> <li>• Using the flash.</li> <li>• Specifying a lower ISO sensitivity setting.</li> </ul>	45 57,  37

Problem	Cause/Solution	
Images are too dark (underexposed).	<ul style="list-style-type: none"> <li>The flash mode is set to  (off).</li> <li>The flash window is blocked.</li> <li>The subject is beyond the range of the flash.</li> <li>Adjust exposure compensation.</li> <li>Increase ISO sensitivity.</li> <li>The subject is backlit. Set the scene mode to  (backlighting) with <b>HDR</b> set to <b>Off</b>, or set the flash mode to .</li> </ul>	45 24 45 53 57,  37 36, 45
Images are too bright (overexposed).	Adjust exposure compensation.	53
Unexpected results when flash set to  (auto with red-eye reduction).	When taking images with  (auto with red-eye reduction) or  (scene auto selector), In-Camera Red Eye Fix may be applied to areas not affected by red-eye in rare cases. Use any shooting mode other than  , and change the flash mode to any setting other than  (auto with red-eye reduction) and try taking an image again.	34, 35, 45
Skin tones are not softened.	<ul style="list-style-type: none"> <li>In some shooting conditions, facial skin tones may not be softened.</li> <li>For images containing four or more faces, try using the <b>Skin softening</b> effect in <b>Glamour retouch</b> in the playback menu.</li> </ul>	40 69,  17
Saving images takes time.	It may take more time to save images in the following situations. <ul style="list-style-type: none"> <li>When the noise reduction function is in operation, such as when shooting in a dark environment</li> <li>When the flash mode is set to  (auto with red-eye reduction)</li> <li>When taking images in the following scene modes               <ul style="list-style-type: none"> <li><b>Hand-held</b> in  (night landscape) or  (night portrait)</li> <li><b>HDR</b> set to <b>On</b> in  (backlighting)</li> <li><b>Easy panorama</b></li> </ul> </li> <li>When the skin softening function is applied while shooting</li> <li>When using continuous shooting mode</li> </ul>	– 47 35 36 38 58 57,  34


Problem	Cause/Solution	
A ring-shaped belt or rainbow-colored stripe appears in the monitor or images.	When shooting with backlighting or when a very strong light source (such as sunlight) is in the frame, a ring-shaped belt or rainbow-colored stripe (ghosting) may occur. Change the position of the light source, or frame the image so that the light source does not enter the frame, and try again.	–

## Playback Issues

Problem	Cause/Solution	
File cannot be played back.	<ul style="list-style-type: none"> <li>This camera may not be able to play back images saved with another make or model of digital camera.</li> <li>This camera cannot play back movies recorded with another make or model of digital camera.</li> <li>This camera may not be able to play back data edited on a computer.</li> </ul>	–
Cannot zoom in on image.	<ul style="list-style-type: none"> <li>Playback zoom cannot be used with movies.</li> <li>When zooming in on a small-sized image, the zoom ratio shown on the screen may differ from the actual zoom ratio of the image.</li> <li>This camera may not be able to zoom in on images captured with another make or model of digital camera.</li> </ul>	–
Cannot record voice memos.	<ul style="list-style-type: none"> <li>Voice memos cannot be attached to movies.</li> <li>Voice memos cannot be attached to images captured with other cameras. Voice memos attached to images using another camera cannot be played back on this camera.</li> </ul>	– 69,  51
Cannot edit image.	<ul style="list-style-type: none"> <li>Some images cannot be edited. Images that have already been edited may not be edited again.</li> <li>There is not enough free space in the internal memory or on the memory card.</li> <li>This camera is unable to edit images captured with other cameras.</li> <li>Editing functions used for images are not available for movies.</li> </ul>	38,  – 69,  13 –

Problem	Cause/Solution	
Cannot rotate image.	This camera cannot rotate images captured with another make or model of digital camera.	–
Images are not displayed on TV.	<ul style="list-style-type: none"> <li>• <b>HDMI</b> is not correctly set in the <b>TV settings</b> setup menu.</li> <li>• A computer or printer is connected to the camera.</li> <li>• The memory card contains no images. Replace the memory card. Remove the memory card to play back images from the internal memory.</li> </ul>	79,  73 83, 86,  22 15
Nikon Transfer 2 does not start when camera is connected to a computer.	<ul style="list-style-type: none"> <li>• The camera is off.</li> <li>• The battery is exhausted.</li> <li>• The USB cable is not correctly connected.</li> <li>• The camera is not recognized by the computer.</li> <li>• The computer is not set to start Nikon Transfer 2 automatically. For more information about Nikon Transfer 2, refer to help information contained in ViewNX 2.</li> </ul>	20 20 83, 86 –  88
The PictBridge startup screen is not displayed when the camera is connected to a printer.	With some PictBridge-compatible printers, the PictBridge startup screen may not be displayed and it may be impossible to print images when <b>Auto</b> is selected for the <b>Charge by computer</b> option in the setup menu. Set the <b>Charge by computer</b> option to <b>Off</b> and reconnect the camera to the printer.	79,  74
Images to be printed are not displayed.	<ul style="list-style-type: none"> <li>• The memory card contains no images. Replace the memory card.</li> <li>• Remove the memory card to print images from the internal memory.</li> </ul>	14  15
Cannot select paper size with camera.	<p>The camera cannot be used to select the paper size in the following situations, even when printing from a PictBridge-compatible printer. Use the printer to select the paper size.</p> <ul style="list-style-type: none"> <li>• The printer does not support the paper sizes specified by the camera.</li> <li>• The printer automatically selects the paper size.</li> </ul>	83,  24,  25 –

## Wi-Fi

Problem	Cause/Solution	
SSID (network name) of the camera is not displayed on the smart device.	Select <b>Connect to smart device</b> in the Wi-Fi options menu on the camera to enter connection standby mode. Turn off the Wi-Fi function of the smart device and then turn it on again.	81

# Specifications

## Nikon COOLPIX S9600 Digital Camera

Type	Compact digital camera
Number of effective pixels	16.0 million
Image sensor	1/2.3-in. type CMOS; approx. 16.76 million total pixels
Lens	NIKKOR lens with 22× optical zoom
Focal length	4.5-99.0 mm (angle of view equivalent to that of 25-550 mm lens in 35mm [135] format)
f/-number	f/3.4-6.3
Construction	12 elements in 10 groups (1 ED lens element)
Digital zoom magnification	Up to 4× (angle of view equivalent to that of approx. 2200 mm lens in 35mm [135] format)
Vibration reduction	Combination of lens shift and electronic VR
Motion blur reduction	Motion detection (still pictures)
Autofocus (AF)	Contrast-detect AF
Focus range	<ul style="list-style-type: none"> <li>• [W]: Approx. 50 cm (1 ft 8 in.) - ∞,</li> <li>  [T]: Approx. 1.5 m (5 ft) - ∞</li> <li>• Macro mode: Approx. 1 cm (0.4 in.) - ∞ (wide-angle position)</li> </ul> (All distances measured from center of front surface of lens)
Focus-area selection	Face priority, manual with 99 focus areas, center, subject tracking, target finding AF
Monitor	7.5 cm (3-in.), approx. 460k-dot, LCD with anti-reflection coating and 5-level brightness adjustment
Frame coverage (shooting mode)	Approx. 98% horizontal and 98% vertical (compared to actual picture)
Frame coverage (playback mode)	Approx. 100% horizontal and 100% vertical (compared to actual picture)
Storage	
Media	Internal memory (approx. 59 MB) SD/SDHC/SDXC memory card
File system	DCF, Exif 2.3, and DPOF compliant
File formats	Still pictures: JPEG Sound files (voice memo): WAV Movies: MOV (video: H.264/MPEG-4 AVC, Audio: LPCM stereo)

Image size (pixels)	<ul style="list-style-type: none"> <li>• 16M (High) <b>4608×3456★</b></li> <li>• 16M <b>4608×3456</b></li> <li>• 8M <b>3264×2448</b></li> <li>• 4M <b>2272×1704</b></li> <li>• 2M <b>1600×1200</b></li> <li>• VGA <b>640×480</b></li> <li>• 16:9 12M <b>4608×2592</b></li> <li>• 1:1 <b>3456×3456</b></li> </ul>
ISO sensitivity (Standard output sensitivity)	<ul style="list-style-type: none"> <li>• ISO 125 - 1600</li> <li>• ISO 3200, 6400 (available when using Auto mode)</li> </ul>
Exposure	
Metering mode	Matrix, center-weighted, spot (digital zoom 2× or more)
Exposure control	Programmed auto exposure and exposure compensation (−2.0 - +2.0 EV in steps of 1/3 EV)
Shutter	Mechanical and CMOS electronic shutter
Speed	<ul style="list-style-type: none"> <li>• 1/1500 - 1 s</li> <li>• 1/4000 s (maximum speed during high-speed continuous shooting)</li> <li>• 4 s (<b>Fireworks show</b> scene mode)</li> </ul>
Aperture	Electronically-controlled ND filter (−2 AV) selection
Range	2 steps (f/3.4 and f/6.8 [W])
Self-timer	Can be selected from 10 s and 2 s
Flash	
Range (approx.) (ISO sensitivity: Auto)	[W]: 0.5 - 5.7 m (1 ft 8 in. - 18 ft) [T]: 1.5 - 3.2 m (5 - 10 ft)
Flash control	TTL auto flash with monitor preflashes
Interface	Hi-Speed USB equivalent
Data transfer protocol	MTP, PTP
HDMI output	Can be selected from Auto, 480p, 720p, and 1080i
I/O terminal	<ul style="list-style-type: none"> <li>• Micro-USB connector</li> <li>• HDMI micro connector (Type D) (HDMI output)</li> </ul>

<b>Wi-Fi (Wireless LAN)</b>	
<b>Standards</b>	IEEE 802.11b/g/n (standard wireless LAN protocol) ARIB STD-T66 (standard for low power data communication systems)
<b>Communications protocols</b>	IEEE 802.11b: DBPSK/DQPSK/CCK IEEE 802.11g: OFDM IEEE 802.11n: OFDM
<b>Range (line of sight)</b>	Approx. 30 m (32 yd)
<b>Operating frequency</b>	2412 - 2462 MHz (1 - 11 channels)
<b>Data rates (actual measured values)</b>	IEEE 802.11b: 5 Mbps IEEE 802.11g: 15 Mbps IEEE 802.11n: 15 Mbps
<b>Security</b>	OPEN/WPA2
<b>Access protocols</b>	CSMA/CA
<b>Supported languages</b>	Arabic, Bengali, Bulgarian, Chinese (Simplified and Traditional), Czech, Danish, Dutch, English, Finnish, French, German, Greek, Hindi, Hungarian, Indonesian, Italian, Japanese, Korean, Marathi, Norwegian, Persian, Polish, Portuguese (European and Brazilian), Romanian, Russian, Serbian, Spanish, Swedish, Tamil, Telugu, Thai, Turkish, Ukrainian, Vietnamese
<b>Power sources</b>	One Rechargeable Li-ion Battery EN-EL12 (included) AC Adapter EH-62F (available separately)
<b>Charging time</b>	Approx. 2 h 20 min (when using Charging AC Adapter EH-71P and when no charge remains)
<b>Battery life<sup>1</sup></b>	
Still pictures	Approx. 290 shots when using EN-EL12
Movies (actual battery life for recording) <sup>2</sup>	Approx. 1 h 5 min when using EN-EL12
<b>Tripod socket</b>	1/4 (ISO 1222)
<b>Dimensions (W × H × D)</b>	Approx. 108.6 × 61.0 × 31.6 mm (4.3 × 2.5 × 1.3 in.) (excluding projections)
<b>Weight</b>	Approx. 206 g (7.3 oz) (including battery and SD memory card)
<b>Operating environment</b>	
Temperature	0°C - 40°C (32°F - 104°F)
Humidity	85% or less (no condensation)

- Unless otherwise stated, all figures assume a fully-charged battery and an ambient temperature of  $23 \pm 3^{\circ}\text{C}$  ( $73.4 \pm 5.4^{\circ}\text{F}$ ) as specified by the Camera and Imaging Products Association (CIPA).
- 1 Battery life may vary depending on conditions of use, such as the interval between shots or the length of time that menus and images are displayed.
  - 2 Individual movie files cannot exceed 4 GB in size or 29 minutes in length. Recording may end before this limit is reached if camera temperature becomes elevated.

## Rechargeable Li-ion Battery EN-EL12

Type	Rechargeable lithium-ion battery
Rated capacity	DC 3.7 V, 1050 mAh
Operating temperature	0°C - 40°C (32°F - 104°F)
Dimensions (W × H × D)	Approx. 32 × 43.8 × 7.9 mm (1.3 × 1.7 × 0.3 in.)
Weight	Approx. 22.5 g (0.8 oz)

## Charging AC Adapter EH-71P

Rated input	AC 100 - 240 V, 50/60 Hz, MAX 0.2 A
Rated output	DC 5.0 V, 1.0 A
Operating temperature	0°C - 40°C (32°F - 104°F)
Dimensions (W × H × D)	Approx. 55 × 22 × 54 mm (2.2 × 0.9 × 2.2 in.) (excluding plug adapter) For Argentina: Approx. 55 × 63 × 59 mm (2.2 × 2.5 × 2.4 in.)
Weight	Approx. 48 g (1.7 oz) (excluding plug adapter) For Argentina: Approx. 73 g (2.6 oz)



### Specifications

- Nikon will not be held liable for any errors this manual may contain.
- The appearance of this product and its specifications are subject to change without notice.

## Approved Memory Cards

The following Secure Digital (SD) memory cards have been tested and approved for use in this camera.

- Memory cards with an SD Speed Class rating of 6 or faster are recommended for recording movies. When using a memory card with a lower Speed Class rating, movie recording may stop unexpectedly.

	SD memory card	SDHC memory card <sup>2</sup>	SDXC memory card <sup>3</sup>
SanDisk	2 GB <sup>1</sup>	4 GB, 8 GB, 16 GB, 32 GB	64 GB, 128 GB
TOSHIBA	–	4 GB, 8 GB, 16 GB, 32 GB	64 GB
Panasonic	2 GB <sup>1</sup>	4 GB, 8 GB, 16 GB, 32 GB	64 GB
Lexar	–	4 GB, 8 GB, 16 GB, 32 GB	64 GB, 128 GB

<sup>1</sup> If the memory card will be used with a card reader or similar device, make sure that the device supports 2 GB cards.

<sup>2</sup> SDHC compliant.

If the memory card will be used with a card reader or similar device, make sure that the device supports SDHC.



<sup>3</sup> SDXC compliant.

If the memory card will be used with a card reader or similar device, make sure that the device supports SDXC.



- Contact the manufacturer for details on the above cards. We cannot guarantee camera performance when using memory cards made by other manufacturers.

## AVC Patent Portfolio License

This product is licensed under the AVC Patent Portfolio License for the personal and non-commercial use of a consumer to (i) encode video in compliance with the AVC standard ("AVC video") and/or (ii) decode AVC video that was encoded by a consumer engaged in a personal and non-commercial activity and/or was obtained from a video provider licensed to provide AVC video. No license is granted or shall be implied for any other use. Additional information may be obtained from MPEG LA, L.L.C.

See <http://www.mpegla.com>.

## FreeType License (FreeType2)

Portions of this software are copyright © 2012 The FreeType Project (<http://www.freetype.org>). All rights reserved.

## MIT License (HarfBuzz)

Portions of this software are copyright © 2014 The HarfBuzz Project (<http://www.freedesktop.org/wiki/Software/HarfBuzz>). All rights reserved.

## Trademark Information

- Microsoft, Windows and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Mac, OS X, the iFrame logo and the iFrame symbol are trademarks or registered trademarks of Apple Inc., in the U.S. and other countries.
- Adobe and Acrobat are registered trademarks of Adobe Systems Inc.
- SDXC, SDHC and SD Logos are trademarks of SD-3C, LLC.
- PictBridge is a trademark.
- HDMI, HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

### **HDMI**

- Wi-Fi and the Wi-Fi logo are trademarks or registered trademarks of the Wi-Fi Alliance.
- Android and Google Play are trademarks or registered trademarks of Google, Inc.
- All other trade names mentioned in this manual or the other documentation provided with your Nikon product are trademarks or registered trademarks of their respective holders.

# Index

## Symbols

	Auto mode.....	22, 31
	Auto sort mode.....	9
	Backlighting.....	36
	Delete button.....	29, 77,  51
	Exposure compensation.....	51, 53
	Favorite pictures mode.....	5
	Flash mode.....	45
	Help.....	34
	List by date mode.....	10
	Macro mode.....	49
<b>MENU</b>	Menu button.....	4, 56, 69, 75, 78
	() movie-record) button.....	2, 71
	Night landscape.....	35
	Night portrait.....	35
	Playback button.....	2, 28
	Playback mode.....	28
	Playback zoom.....	67
	Scene auto selector.....	34
<b>SCENE</b>	Scene mode.....	33
	Self-timer.....	48
	Setup menu.....	78,  62
	Smart portrait mode.....	40
<b>EFFECTS</b>	Special effects mode.....	42
<b>T</b> (Telephoto)	.....	25
	Thumbnail playback.....	68
<b>W</b> (Wide-angle)	.....	25
JPG.....		84
.MOV.....		84
.WAV.....		84

## A

AC adapter.....	83,  85
AF area mode.....	57, 75,  38,  58
AF assist.....	78,  69
AF-assist illuminator.....	1
Album.....	5
Aperture value.....	27
Auto flash.....	47
Auto mode.....	22, 31
Auto off.....	21, 78,  71
Auto sort mode.....	9
Auto with red-eye reduction.....	47
Autofocus.....	57, 75,  41,  59

## B

Backlighting.....	33, 36
Battery.....	10, 12, 18
Battery charger.....	13,  85
Battery latch.....	10
Battery level indicator.....	20
Battery-chamber/memory card slot cover.....	2, 10, 14
Beach	33
Best Shot Selector.....	37,  35
Black and white copy	33, 37
Blink proof.....	58,  44
Blink warning.....	79,  75
Brightness.....	78,  65
Brightness (exposure compensation).....	50
BSS.....	37,  35
Button sound.....	71

Refer to the *Reference Manual* for pages indicated with .

## C

- Calendar display ..... 68
- Charge by computer .... 79, 74
- Charge lamp..... 2, 13
- Charger..... 13, 85
- Charging AC adapter..... 12
- Choose key picture  
..... 70, 11, 53
- Close-up ..... 33, 37
- Compression ratio ..... 29
- Computer..... 84, 86
- Continuous ..... 57, 34
- Copying images..... 69, 52
- Crop..... 19
- Cross process ..... 43

## D

- Date and time ..... 16, 78, 63
- Date format..... 17, 63
- Daylight saving time  
..... 17, 18, 63
- Delete..... 29, 77, 12, 51
- Digital zoom..... 25, 78, 70
- Direct print..... 84, 21
- D-Lighting ..... 69, 15
- DPOF print..... 26
- DSCN..... 84
- Dusk/dawn ..... 33

## E

- Easy panorama .... 33, 38, 2
- Easy panorama playback  
..... 38, 4
- Exposure compensation..... 51, 53
- Extension..... 84
- Eye-Fi upload..... 79, 76
- Eyeflet for camera strap..... 2

## F

- Face detection ..... 64
- Face priority  
..... 64, 75, 38, 58
- Favorite pictures ..... 70, 5
- Favorite pictures mode..... 5
- File name ..... 84
- Fill flash ..... 47
- Fireworks show ..... 33, 37
- Firmware version..... 79, 77
- Fixed range auto..... 37
- Flash..... 1, 45
- Flash lamp..... 2, 45
- Flash mode..... 45, 47
- Flash off ..... 47
- Focus  
..... 26, 57, 75, 38, 58
- Focus area ..... 26
- Focus indicator ..... 7
- Focus lock ..... 66
- Food ..... 33, 37
- Format internal memory  
..... 79, 72
- Format memory cards  
..... 14, 79, 72
- Formatting..... 14, 79, 72
- Frame rate ..... 75, 61
- FSCN..... 84
- Full-frame playback..... 67
- Full-time AF ..... 75, 41, 59

## G

- Glamour retouch..... 69, 17
- ## H
- HDMI ..... 73
  - HDMI cable..... 84, 20
  - HDMI connector cover..... 2

HDMI device control.....	73	Micro-USB connector	
HDMI micro connector.....	2		83, 86, 22
HDR.....	36	Monitor.....	2, 6, 6
Help.....	34	Monitor settings.....	78, 65
High key	42	Motion detection.....	78, 69
High-contrast monochrome		Movie editing.....	77, 27
	42	Movie length.....	71, 72
High-speed continuous.....	34	Movie menu.....	75, 54
Histogram.....	51	Movie options.....	75, 54
HS movie.....	75, 55, 56	Movie playback.....	76
Hue.....	52	Movie recording.....	71
<b>I</b>		Movie VR.....	75, 60
Identifier.....	84	Multi selector.....	2, 4, 28, 44
Image copy.....	69, 52	Multi-shot 16.....	35
Image mode.....	57, 29	Museum	33, 37
Image review.....	78, 65	<b>N</b>	
Image size.....	57, 29	Night landscape.....	33, 35
Imprinting date and time		Night portrait.....	33, 35
	18, 78, 67	Nikon Transfer 2.....	86
Internal memory.....	15, 20	Nostalgic sepia <b>SEPIA</b> .....	42
Internal memory indicator.....	7, 9	Number of exposures remaining	
ISO sensitivity.....	57, 37		20, 30
<b>L</b>		<b>O</b>	
Landscape	33	Open with HS footage	
Language.....	79, 73		75, 56, 58
Lens.....	1, 6, 17	Optical zoom.....	25
Lens cover.....	1	Optional accessories.....	85
List by date mode.....	10	<b>P</b>	
Low key	42	Paper size.....	24, 25
<b>M</b>		Party/indoor	33, 36
Macro mode.....	49	Pet portrait auto release.....	39
Memory capacity.....	20	Pet portrait	33, 39
Memory card.....	14	Photo info.....	78, 65
Memory card slot.....	14	Photo VR.....	78, 68
Microphone.....	1	PictBridge.....	84, 21

Playback..... 28, 67, 76, 51  
 Playback menu ..... 69, 45  
 Playback mode ..... 28  
 Playback zoom..... 67  
 Pop **POP** ..... 42  
 Portrait ..... 33  
 Power..... 20  
 Power switch ..... 1, 20  
 Power-on lamp..... 1  
 Preset manual ..... 32  
 Pre-shooting cache  
 ..... 34, 36  
 Pressing halfway ..... 27  
 Print  
 ... 69, 84, 23, 25, 45  
 Print date..... 18, 78, 67  
 Print order..... 69, 45  
 Print order date option  
 ..... 18, 46, 67  
 Printer..... 84, 21  
 Protect..... 69, 49

## Q

Quick effects  
 ... 26, 28, 32, 57, 14, 41  
 Quick retouch..... 69, 15

## R

Recording movies..... 71  
 Recording slow motion movies  
 ..... 75, 55, 56  
 Red-eye correction..... 69, 16  
 Remove from favorites ... 70, 7  
 Reset all ..... 79, 77  
 Rotary multi selector  
 ..... 2, 4, 28, 44  
 Rotate image ..... 69, 50  
 RSCN..... 84

## S

Scene mode..... 33, 34  
 Selective color ..... 42  
 Self-timer ..... 48  
 Self-timer lamp ..... 1, 48  
 Sequence display options  
 ..... 70, 11, 53  
 Setup menu ..... 78, 62  
 Shooting ..... 22, 24, 26  
 Shooting menu..... 56, 29  
 Shooting mode ..... 22  
 Shutter sound..... 71  
 Shutter speed ..... 27  
 Shutter-release button..... 1, 26  
 Single ..... 57, 34  
 Single AF ..... 75, 41, 59  
 Skin softening..... 58, 65, 42  
 Slide show ..... 69, 48  
 Slow sync..... 47  
 Small picture..... 69, 18  
 Smart portrait menu..... 56, 42  
 Smart portrait mode..... 40  
 Smile timer ..... 58, 43  
 Snow ..... 33  
 Soft **SOFT** ..... 42  
 Sound settings ..... 78, 71  
 Speaker ..... 1  
 Special effects mode ..... 42  
 Sports ..... 33, 36  
 SSCN ..... 84  
 Strap..... 3  
 Subject tracking ..... 39, 40  
 Sunset ..... 33  
 Super vivid **VI**..... 42

## T

Target finding AF... 57, 63, 39

Thumbnail playback.....	68
Time difference .....	64
Time zone .....	18,  63
Time zone and date .....	16, 78,  63
Toy camera effect 1  1.....	43
Toy camera effect 2  2.....	43
Tripod socket.....	2,  19
TV .....	84,  20
TV settings .....	79,  73

## U

USB cable .....	83, 86,  22
USB connector cover .....	2

## V

Vibration reduction .....	75, 78,  60,  68
ViewNX 2 .....	85
Vividness.....	52
Voice memo .....	69,  51
Volume .....	76,  51

## W

Welcome screen.....	78,  62
White balance .....	57,  31
Wi-Fi options.....	80,  78
Wind noise reduction.....	75,  61
Wireless LAN.....	80,  78

## Z

Zoom .....	25
Zoom control .....	1, 25
Zoom in.....	25
Zoom out.....	25



A series of horizontal dashed lines for handwriting practice, spanning the width of the page.

No reproduction in any form of this manual, in whole or in part (except for brief quotation in critical articles or reviews), may be made without written authorization from NIKON CORPORATION.

