



DIGITAL CAMERA

D5200

User's Manual







Product Documentation

The documentation for this product consists of a *User's Manual* (this booklet) and a *Reference Manual* (pdf). To get the most from your camera, please be sure to read all instructions thoroughly and keep them where they will be read by all who use the product.

For information on basic camera operations, see the *User's Manual* (this booklet).



For complete product information, see the Reference Manual (available on the supplied reference CD).



The *Reference Manual* can be viewed using Adobe Reader or Adobe Acrobat Reader 5.0 or later, available for free download from the Adobe website.

- 1 Start the computer and insert the reference CD.
- 2 Double-click the CD (**Nikon D5200**) icon in Computer or My Computer (Windows) or on the desktop (Macintosh).
- 3 Double-click the **INDEX.pdf** icon to display a language selection screen and click a language to display the *Reference Manual*.

Camera Settings

The explanations in this manual assume that default settings are used.

Digitutor

"Digitutor", a series of "watch and learn" manuals in movie form, is available from the following website: http://www.nikondigitutor.com/index_eng.html

Nikon Manual Viewer 2




Install the Nikon Manual Viewer 2 app on your smartphone or tablet to view Nikon digital camera manuals, anytime, anywhere. Nikon Manual Viewer 2 can be downloaded free of charge from the App Store and Google Play. Download of the app and any product manuals requires an Internet connection, for which fees may be levied by your phone or Internet service provider.

⚠ For Your Safety

Before using the camera for the first time, read the safety instructions in "For Your Safety" (Div-viii).

Package Contents


Confirm that the package contains the following items:



Purchasers of the lens kit option should confirm that the package also includes a lens. *Memory cards are sold separately* (\square 77). Cameras purchased in Japan display menus and messages in English and Japanese only; other languages are not supported. We apologize for any inconvenience this may cause.

Symbols and Conventions

To make it easier to find the information you need, the following symbols and conventions are used:



Menu items, options, and messages displayed in the camera monitor are shown in **bold**.

This icon marks references to other pages in this manual.

Table of Contents

Package Contents	i
For Your Safety	iv
Notices	V
Introduction	1
Getting to Know the Camera	1
The Camera Body	1
The Mode Dial	3
The Viewfinder	4
The Monitor	
The Information Display	
First Steps	7
Basic Photography	14
Battery Level and Card Capacity	 14
"Point-and-Shoot" Photography (🖀 and 🥸 Modes)	15
Creative Photography (Scene Modes)	19
The Mode Dial	
Other Scenes	21
Playback and Deletion	24
Viewing Photographs	24
Display pictures	
Deleting Pictures	25
More on Photography (All Modes)	26
Single-Frame, Continuous, Self-timer, Remote, and Quiet Release Mode	es 26
Self-Timer and Remote Control Modes	28
Focus	30
Focus Mode	30
AF-Area Mode	32
Focus Point Selection	
Image Quality and Size	
lmage Quality	
Image Size	
Using the Built-in Flash	
Flash Mode	
ISO Sensitivity	
Interval Timer Photography	40

P, S, A, and M Modes	42
Mode P (Programmed Auto)	43
Mode S (Shutter-Priority Auto)	43
Mode A (Aperture-Priority Auto)	
Mode M (Manual)	
Exposure Compensation (Mode P, S, A, and 🗹 Only)	44
Live View	45
Framing Photographs in the Monitor	45
Focusing in Live View	46
The Live View Display	49
Recording and Viewing Movies	53
Recording Movies	53
Movie Settings	55
Viewing Movies	
Special Effects	58
Shooting with Special Effects	58
Options Available in Live View	
Camera Menus	65
Menu Options	
Using Camera Menus	68
ViewNX 2	70
Installing ViewNX 2	70
Using ViewNX 2	72
Copy Pictures to the Computer	
View Pictures	
Technical Notes	74
Compatible Lenses	74
Compatible CPU Lenses	
Other Accessories	76
Approved Memory Cards	77
Caring for the Camera	78
Storage	78
Cleaning	78
Caring for the Camera and Battery: Cautions	79
Caring for the Camera	79
Caring for the Battery	80
Error Messages	82
Specifications	84
Warranty Terms - Nikon Europe Service Warranty	92

For Your Safety

To prevent damage to your Nikon product or injury to yourself or to others, read the following safety precautions in their entirety before using this equipment. Keep these safety instructions where all those who use the product will read them.

The consequences that could result from failure to observe the precautions listed in this section are indicated by the following symbol:



This icon marks warnings. To prevent possible injury, read all warnings before using this Nikon product.

WARNINGS

!\text{Keep the sun out of the frame}

Keep the sun well out of the frame when shooting backlit subjects. Sunlight focused into the camera when the sun is in or close to the frame could cause a fire.

⚠ Do not look at the sun through the viewfinder

Viewing the sun or other strong light source through the viewfinder could cause permanent visual impairment.

Using the viewfinder diopter adjustment control

When operating the viewfinder diopter adjustment control with your eye to the viewfinder, care should be taken not to put your finger in your eye accidentally.

⚠ Turn off immediately in the event of malfunction

Should you notice smoke or an unusual smell coming from the equipment or AC adapter (available separately), unplug the AC adapter and remove the battery immediately, taking care to avoid burns. Continued operation could result in injury. After removing the battery, take the equipment to a Nikonauthorized service center for inspection.

⚠ Do not use in the presence of flammable gas

Do not use electronic equipment in the presence of flammable gas, as this could result in explosion or fire.

!\ Keep out of reach of children

Failure to observe this precaution could result in injury. In addition, note that small parts constitute a choking hazard. Should a child swallow any part of this equipment, consult a physician immediately.

↑ Do not disassemble

Touching the product's internal parts could result in injury. In the event of malfunction, the product should be repaired only by a qualified technician. Should the product break open as the result of a fall or other action, remove the battery and/or AC adapter and then take the product to a Nikon-authorized service center for inspection.

⚠ Do not place the strap around the neck of an infant or child Placing the camera strap around the neck of an infant or child could result in strangulation.

⚠ Do not remain in contact with the camera, battery, or charger for extended periods while the devices are on or in use

Parts of the device become hot. Leaving the device in direct contact with the skin for extended periods may result in low-temperature burns.

Do not aim a flash at the operator of a motor vehicle

Failure to observe this precaution could result in accidents.

⚠ Observe caution when using the flash

- Using the camera with the flash in close contact with the skin or other objects could cause burns.
- Using the flash close to the subject's eyes could cause temporary visual impairment. Particular care should be observed when photographing infants, when the flash should be no less than one meter (39 in.) from the subject.

Avoid contact with liquid crystal

Should the monitor break, care should be taken to avoid injury due to broken glass and to prevent the liquid crystal from the monitor touching the skin or entering the eyes or mouth.

⚠ Observe proper precautions when handling batteries

Batteries may leak or explode if improperly handled. Observe the following precautions when handling batteries for use in this product:

- Use only batteries approved for use in this equipment.
- Do not short or disassemble the battery.
- Be sure the product is off before replacing the battery. If you are using an AC adapter, be sure it is unplugged.
- Do not attempt to insert the battery upside down or backwards.
- Do not expose the battery to flame or to excessive heat.
- Do not immerse in or expose to water.
- Replace the terminal cover when transporting the battery. Do not transport or store the battery with metal objects such as necklaces or hairpins.
- Batteries are prone to leakage when fully discharged.
 To avoid damage to the product, be sure to remove the battery when no charge remains.
- When the battery is not in use, attach the terminal cover and store in a cool, dry place.
- The battery may be hot immediately after use or when the product has been used on battery power for an extended period. Before removing the battery turn the camera off and allow the battery to cool.
- Discontinue use immediately should you notice any changes in the battery, such as discoloration or deformation.

⚠ Observe proper precautions when handling the charger

- Keep dry. Failure to observe this precaution could result in fire or electric shock.
- Do not short the charger terminals. Failure to observe this precaution could result in overheating and damage to the charger.
- Dust on or near the metal parts of the plug should be removed with a dry cloth. Continued use could result in fire.
- Do not go near the charger during thunderstorms.
 Failure to observe this precaution could result in electric shock
- Do not handle the plug or charger with wet hands.
 Failure to observe this precaution could result in electric shock

 Do not use with travel converters or adapters designed to convert from one voltage to another or with DC-to-AC inverters. Failure to observe this precaution could damage the product or cause overheating or fire.

⚠ Use appropriate cables

When connecting cables to the input and output jacks, use only the cables provided or sold by Nikon for the purpose to maintain compliance with product regulations.

↑ CD-ROMs

CD-ROMs containing software or manuals should not be played back on audio CD equipment. Playing CD-ROMs on an audio CD player could cause hearing loss or damage the equipment.

Notices

- No part of the manuals included with this product may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form, by any means, without Nikon's prior written permission.
- Nikon reserves the right to change the specifications of the hardware and software described in these manuals at any time and without prior notice.
- Nikon will not be held liable for any damages resulting from the use of this product.
- While every effort has been made to ensure that the information in these manuals is accurate and complete, we would appreciate it were you to bring any errors or omissions to the attention of the Nikon representative in your area (address provided separately).

Notice for Customers in Canada

CAN ICES-3 B / NMB-3 B

Notices for Customers in Europe

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

electronic equipment is to be collected separately.


The following apply only to users in European

This symbol indicates that electrical and



- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- Separate collection and recycling helps conserve natural resources and prevent negative consequences for human health and the environment that might result from incorrect disposal.
- For more information, contact the retailer or the local authorities in charge of waste management.

This symbol on the battery indicates that the battery is to be collected separately.





- All batteries, whether marked with this symbol or not, are designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- For more information, contact the retailer or the local authorities in charge of waste management.

The Battery Charger

IMPORTANT SAFETY INSTRUCTIONS—SAVE THESE INSTRUCTIONS DANGER—TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS

For connection to a supply not in the U.S.A., use an attachment plug adapter of the proper configuration for the power outlet if needed. This power unit is intended to be correctly oriented in a vertical or floor mount position.

Federal Communications Commission (FCC) Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.



Nikon

D5200

CAUTIONS

Modifications

The FCC requires the user be notified that any changes or modifications made to this device that are not expressly approved by Nikon Corporation may void the user's authority to operate the equipment.

Interface Cables

Use the interface cables sold or provided by Nikon for your equipment. Using other interface cables may exceed the limits of Class B Part 15 of the FCC rules.

Notice for Customers in the State of California

WARNING: Handling the cord on this product may expose you to lead, a chemical known to the State of California to cause birth defects or other reproductive harm. *Wash hands after handling*.

Nikon Inc., 1300 Walt Whitman Road, Melville, New York 11747-3064, U.S.A.

Tel.: 631-547-4200

Notice Concerning Prohibition of Copying or Reproduction

Note that simply being in possession of material that has been digitally copied or reproduced by means of a scanner, digital camera, or other device may be punishable by law.

· Items prohibited by law from being copied or reproduced

Do not copy or reproduce paper money, coins, securities, government bonds, or local government bonds, even if such copies or reproductions are stamped "Sample."

The copying or reproduction of paper money, coins, or securities which are circulated in a foreign country is prohibited.

Unless the prior permission of the government has been obtained, the copying or reproduction of unused postage stamps or post cards issued by the government is prohibited.

The copying or reproduction of stamps issued by the government and of certified documents stipulated by law is prohibited.

• Cautions on certain copies and reproductions

The government has issued cautions on copies or reproductions of securities issued by private companies (shares, bills, checks, gift certificates, etc.), commuter passes, or coupon tickets, except when a minimum of necessary copies are to be provided for business use by a company. Also, do not copy or reproduce passports issued by the government, licenses issued by public agencies and private groups, ID cards, and tickets, such as passes and meal coupons.

• Comply with copyright notices

The copying or reproduction of copyrighted creative works such as books, music, paintings, woodcuts, prints, maps, drawings, movies, and photographs is governed by national and international copyright laws. Do not use this product for the purpose of making illegal copies or to infringe copyright laws.

Disposing of Data Storage Devices

Please note that deleting images or formatting memory cards or other data storage devices does not completely erase the original image data. Deleted files can sometimes be recovered from discarded storage devices using commercially available software, potentially resulting in the malicious use of personal image data. Ensuring the privacy of such data is the user's responsibility.

Before discarding a data storage device or transferring ownership to another person, erase all data using commercial deletion software, or format the device and then completely refill it with images containing no private information (for example, pictures of empty sky). Be sure to also replace any pictures selected for preset manual. Care should be taken to avoid injury when physically destroying data storage devices.

AVC Patent Portfolio License

THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER TO (I) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (II) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE http://www.mpegla.com

Use Only Nikon Brand Electronic Accessories

Nikon cameras are designed to the highest standards and include complex electronic circuitry. Only Nikon brand electronic accessories (including chargers, batteries, AC adapters, and flash accessories) certified by Nikon specifically for use with this Nikon digital camera are engineered and proven to operate within the operational and safety requirements of this electronic circuitry.

The use of non-Nikon electronic accessories could damage the camera and may void your Nikon warranty. The use of third-party rechargeable Li-ion batteries not bearing the Nikon holographic seal shown at right could interfere with normal operation of the camera or result in the batteries overheating, igniting, rupturing, or leaking.



For more information about Nikon brand accessories, contact a local authorized Nikon dealer.

Use Only Nikon Brand Accessories

Only Nikon brand accessories certified by Nikon specifically for use with your Nikon digital camera are engineered and proven to operate within its operational and safety requirements. The USE OF NON-NIKON ACCESSORIES COULD DAMAGE YOUR CAMERA AND MAY VOID YOUR NIKON WARRANTY.

Servicing the Camera and Accessories

The camera is a precision device and requires regular servicing. Nikon recommends that the camera be inspected by the original retailer or a Nikon-authorized service representative once every one to two years, and that it be serviced once every three to five years (note that fees apply to these services). Frequent inspection and servicing are particularly recommended if the camera is used professionally. Any accessories regularly used with the camera, such as lenses or optional flash units, should be included when the camera is inspected or serviced.

Before Taking Important Pictures

Before taking pictures on important occasions (such as at weddings or before taking the camera on a trip), take a test shot to ensure that the camera is functioning normally. Nikon will not be held liable for damages or lost profits that may result from product malfunction.

Life-Long Learning

As part of Nikon's "Life-Long Learning" commitment to ongoing product support and education, continually-updated information is available on-line at the following sites:

- For users in the U.S.A.: http://www.nikonusa.com/
- For users in Europe and Africa: http://www.europe-nikon.com/support/
- For users in Asia, Oceania, and the Middle East: http://www.nikon-asia.com/


Visit these sites to keep up-to-date with the latest product information, tips, answers to frequently-asked questions (FAQs), and general advice on digital imaging and photography. Additional information may be available from the Nikon representative in your area. See the following URL for contact information: https://imaging.nikon.com/

Introduction

Getting to Know the Camera

Take a few moments to familiarize yourself with camera controls and displays. You may find it helpful to bookmark this section and refer to it as you read through the rest of the manual.

The Camera Body




2	Live view switch
	Live view45
	Movie53
3	📠 (information) button50
4	및/항/🕯 button
	Release mode26
	Self-timer28
	Remote control28
5	Eyelets for camera strap7
6	☑/֎ button
	Exposure compensation44
	Adjusting aperture43
	Flash compensation
7	Shutter-release button 16, 18
8	Power switch2
9	Movie-record button53

1 Mode dial.....

- 1	10	Infrared receiver for ML-L3
ı		remote control (front)28
	11	AF-assist illuminator
ı		Self-timer lamp 28
ı		Red-eye reduction lamp 38
	12	Body cap
	13	CPU contacts
	14	Built-in flash 36
	15	Speaker2
	16	Focal plane mark (- o-)
	17	፟ 4/∰ button
ı		Flash mode37, 38
ı		Flash compensation
	18	Connector cover
	19	Fn button
ı		Using the Fn button
	20	Mounting mark8

21	Lens release button13
22	Mirror
23	Lens mount 8
24	Accessory shoe cover
25	Accessory shoe (for optional
	flash units)
26	Stereo microphone2, 55
27	Connector for external
	microphone
28	USB and A/V connector
	Connecting to a
	computer72
29	HDMI mini-pin connector
30	Accessory terminal77



1	Viewfinder eyepiece 4, 29
2	Rubber eyecup29
3	MENU button
	Menus 65
4	Infrared receiver for ML-L3
	remote control (rear)28
5	Monitor
	Viewing settings6
	Live view45
	Full-frame playback 24
6	Tripod socket
7	Diopter adjustment
	control 10
8	(information edit) button
	6

9	AF-L/ ○→ button
	Using the 駐 (ㅇㅠ) button
	Protecting photographs
	from deletion
10	Command dial
11	▶ button
	Playback24
12	
13	Memory card slot cover
	8, 12
14	Multi selector68
15	Memory card access lamp
	17, 45
16	亩 button


Deleting pictures......25

The Microphone and Speaker


Do not place the microphone or speaker in close proximity to magnetic devices. Failure to observe this precaution could affect the data recorded on the magnetic devices.

The Power Switch

Rotate the power switch as shown to turn the camera on.



Rotate the power switch as shown to turn the camera off.



The Mode Dial

The camera offers a choice of the following shooting modes:

P, S, A, and M Modes

Select these modes for full control over camera settings.

- P—Programmed auto (\$\square\$ 42, 43)
- S—Shutter-priority auto (\$\square\$ 42, 43)
- A Aperture-priority auto (\$\square\$ 42, 43)
- M Manual (\$\square\$ 42, 43)

Special Effects Modes


Use special effects during shooting.

- **☑** Night vision (□ 59)
- **▼ Color sketch** (□ 59, 61)
- **Miniature effect** (\$\square\$ 59, 62)
- **Selective color** (\$\square\$ 60, 63)
- **≦** Silhouette (□ 60)
- III High key (\$\square\$ 60)
- **Low key** (40)

Auto Modes

Select these modes for simple, point-and-shoot photography.

- Auto (□ 15)
- **3** Auto (flash off) (15)



Scene Modes

The camera automatically optimizes settings to suit the scene selected with the mode dial. Match your selection to the scene being photographed.


- **₹ Portrait** (□ 19)
- **Landscape** (□ 19)
- **4** Child (11 20)

- **❖ Sports** (□ 20)
- **Close up** (🕮 20)
- SCENE Other scenes (\$\square\$ 21)


Scene Auto Selector (Live View)

Selecting live view in \square or \square mode enables automatic scene selection ("scene auto selector"; \square 50) when autofocus is used.

The Viewfinder



7



- Framing grid (displayed when On is selected for Custom Setting d2) 2 Focus points 33 3 AF area brackets10, 15 4 Low battery warning...... 14 5 Monochrome indicator (displayed when the Monochrome Picture Control or a Picture Control based on Monochrome is selected) 6 "No memory card" indicator.....8 7 Focus indicator 16 8 Autoexposure (AE) lock indicator 9 Shutter speed42, 43
- 10 Aperture (f-number)......42, 43 11 Low battery warning......14 12 **Bracketing indicator** 13 Number of exposures remaining14 Number of shots remaining before memory buffer fills27 White balance recording indicator Exposure compensation value......44 Flash compensation value ISO sensitivity......39 14 "K" (appears when memory remains for over 1000 exposures) 14 15 Flash-ready indicator...... 18


Note: Display shown with all indicators lit for illustrative purposes.

The Viewfinder

The response time and brightness of the viewfinder display may vary with temperature.

The Monitor

The monitor can be angled and rotated as shown below.




Normal use

Fold the monitor against the camera face out. This position is recommended for normal photography.



Low-angle shots

Frame live view shots with the camera close to the ground.





High-angle shots

Frame live view shots while holding the camera over your head.





Self-portraits

Use for self-portraits in live view. The monitor shows a mirror image of what will appear in the final picture.





Using the Monitor


Rotate the monitor gently within the limits shown. *Do not use force.* Failure to observe these precautions could damage the connection between the monitor and the camera body. To protect the monitor when the camera is not in use, fold it back face down against the camera body.


See Also


See "Framing Photographs in the Monitor" for information on framing photographs in the monitor (\square 45).

The Information Display

Camera settings can be viewed and adjusted in the information display. Press the \P button once to view settings, and again to make changes to settings. Highlight items using the multi selector and press @ to view options for the highlighted item.







20 19
Shooting mode
auto/
3 auto (flash off) 15
Scene modes19
P, S, A , and M modes 42
Special effects mode 58
Aperture (f-number)42, 43
Aperture display42, 43
Shutter speed42, 43
Shutter-speed display42, 43
Bracketing indicator
Auto-area AF indicator 32
3D-tracking indicator 32
Focus point 33
Eye-Fi connection indicator
GPS connection indicator
Exposure delay mode
Multiple exposure indicator
Print date indicator
Flash control indicator
Flash compensation indicator

for optional flash units

	34
12	Release mode26
13	"Beep" indicator
14	Battery indicator 14
15	ISO sensitivity39
	ISO sensitivity display39
	Auto ISO sensitivity indicator
16	ADL bracketing amount
17	Number of exposures
	remaining14
	White balance recording
	indicator
18	"K" (appears when memory
	remains for over 1000
	exposures)14
19	Exposure indicator43
	Exposure compensation
	indicator44
	Bracketing progress
	indicator44

21 Image quality34

22 Image size35

ď	-A			₹	132 U.	
		mage	qualit	у	1	Ba:k
3	3	32	31	30	29	28
	23	Brack	eting	increr	nent	
ĺ	24	HDR	(High	Dynar	nic Ra	ange)
ĺ	25	Active D-Lighting				
ĺ	26	White balance				
ĺ	27	ISO sensitivity39				
ĺ	28	Exposure compensation 44				
ĺ	29	Flash compensation				
ĺ	30	Flash mode37				
ĺ	31	1 Metering				
ĺ	32	AF-area mode 32, 47				
ĺ	33	3 Focus mode 30, 46				30, 46
ĺ	34	Picture Control				

Note: Display shown with all indicators lit for illustrative purposes.

20 Help icon


7.5


First Steps

Always turn the camera off before inserting or removing batteries or memory cards.

1 Attach the strap.

Attach the strap securely to the two eyelets on the camera body as shown below.











2 Charge the battery.

If a plug adapter is supplied, raise the wall plug and connect the plug adapter as shown below at left, making sure the plug is fully inserted. Insert the battery and plug the charger in. An exhausted battery will fully charge in about 1 hour and 30 minutes.









3 Insert the battery.

Insert the battery in the orientation shown, using the battery to keep the orange battery latch pressed to one side. The latch locks the battery in place when the battery is fully inserted.










Battery latch

4 Insert a memory card (available separately).

Check to be sure the card is in the correct orientation and then slide the card until it clicks into place.










5 Attach a lens.

Be careful to prevent dust from entering the camera when the lens or body cap is removed.






Mounting mark (lens; indicated by white dot)



Mounting mark (camera)



Keeping marks (white dots) aligned, position lens on camera, then rotate until lens clicks into place.

. Mounting mark (lens)

Autofocus is available with AF-S lenses. When using autofocus with a lens equipped with an **A-M** mode switch, slide the switch to **A** (if the lens has an **M/A-M** switch, select **M/A** for autofocus with manual override). For information on other lenses that can be used with the D5200, see page 74.







If the lens has a vibration reduction (VR) switch, select **0N** to reduce the effects of vibration.




6 Open the monitor.

Open the monitor as shown. Do not use force.








7 Turn the camera on.

A language-selection dialog will be displayed.



Lenses with Retractable Lens Barrel Buttons

Before using the camera, unlock and extend the zoom ring. Keeping the retractable lens barrel button pressed (1), rotate the zoom ring as shown (2).






Retractable lens barrel button

Pictures can not be taken when the lens is retracted; if an error message is displayed as a result of the camera having been turned on with the lens retracted, rotate the zoom ring until the message is no longer displayed.



8 Choose a language and set the camera clock.

Use the multi selector and @ button to select a language and set the camera clock.







(2)



Select language

Select time zone Time zone and date

Select date format





time option


Date and time Y M D H M S 2012. 04. 15 10:00:00

Set time and date (note that the camera uses a 24-hour clock)

Note: The language and date/time can be changed at any time using the Lanauaae and Time zone and date options in the setup menu (\square 66).

9 Focus the viewfinder.

After removing the lens cap, rotate the diopter adjustment control until the AF area brackets are in sharp focus. When operating the control with your eye to the viewfinder, be careful not to put your fingers or fingernails in your eye.



AF area brackets

Adjusting Viewfinder Focus

If you are unable to focus the viewfinder as described above, select single-servo autofocus (AF-S; \square 30), single-point AF ([12]; \square 32), and the center focus point, and then frame a highcontrast subject in the center focus point and press the shutter-release button halfway to focus the camera. With the camera in focus, use the diopter adjustment control to bring the subject into clear focus in the viewfinder. If necessary, viewfinder focus can be further adjusted using optional corrective lenses.

During Charging

Do not move the charger or touch the battery during charging. Failure to observe this precaution could in very rare instances result in the charger showing that charging is complete when the battery is only partially charged. Remove and reinsert the battery to begin charging again.

Charging the Battery

Read and follow the warnings and cautions on pages iv–v and 79–81 of this manual. Charge the battery indoors at ambient temperatures of 5 °C–35 °C (41°F–95 °F). Do not use the battery at ambient temperatures below 0 °C/32 °F or above 40 °C/104 °F; failure to observe this precaution could damage the battery or impair its performance. Capacity may be reduced and charging times may increase at battery temperatures from 0 °C/32 °F to 15 °C/59 °F and from 45 °C/113 °F to 60 °C/140 °F. The battery will not charge if its temperature is below 0 °C (32 °F) or above 60 °C (140 °F). If the **CHARGE** lamp flashes quickly (about eight times a second) during charging, confirm that the temperature is in the correct range and then unplug the charger and remove and reinsert the battery. If the problem persists, cease use immediately and take battery and charger to your retailer or a Nikon-authorized service representative.

Do not attempt to charge a fully-charged battery. Failure to observe this precaution will result in reduced battery performance.

Use the charger with compatible batteries only. Unplug when not in use.

Removing the Battery

To remove the battery, turn the camera off and open the battery-chamber cover. Press the battery latch in the direction shown by the arrow to release the battery and then remove the battery by hand.



Formatting Memory Cards

If this is the first time the memory card will be used in the camera or if the card has been formatted in another device, select **Format memory card** in the setup menu and follow the on-screen instructions to format the card (\square 66). *Note that this permanently deletes any data the card may contain*. Be sure to copy any photographs and other data you wish to keep to a computer before proceeding.




7.3

Memory Cards

- Memory cards may be hot after use. Observe due caution when removing memory cards from the camera.
- Turn the power off before inserting or removing memory cards. Do not remove memory
 cards from the camera, turn the camera off, or remove or disconnect the power source
 during formatting or while data are being recorded, deleted, or copied to a computer.
 Failure to observe these precautions could result in loss of data or in damage to the
 camera or card.
- Do not touch the card terminals with your fingers or metal objects.
- Do not bend, drop, or subject to strong physical shocks.
- Do not apply force to the card casing. Failure to observe this precaution could damage the card.
- Do not expose to water, heat, high levels of humidity, or direct sunlight.
- Do not format memory cards in a computer.


Removing Memory Cards

After confirming that the memory card access lamp is off, turn the camera off, open the memory card slot cover, and press the card in to eject it (1). The card can then be removed by hand (2).



The Write Protect Switch

SD memory cards are equipped with a write protect switch to prevent accidental loss of data. When this switch is in the "lock" position, the memory card can not be formatted and photos can not be deleted or recorded (a beep will sound if you attempt to release the shutter). To unlock the memory card, slide the switch to the "write" position.



Write-protect switch

CPU Lenses with Aperture Rings

In the case of CPU lenses equipped with an aperture ring (\square 75), lock aperture at the minimum setting (highest f-number).

Detaching the Lens

Be sure the camera is off when removing or exchanging lenses. To remove the lens, press and hold the lens release button (1) while turning the lens clockwise (2). After removing the lens, replace the lens caps and camera body cap.



Retracting Lenses with Retractable Lens Barrel Buttons

To retract the lens when the camera is not in use, hold the retractable lens barrel button (1) and rotate the zoom ring to the "L" (lock) position as shown (2). Retract the lens before removing it from the camera, and be careful not to press the retractable lens barrel button when attaching or removing the lens.



The Camera Clock

The camera clock is less accurate than most watches and household clocks. Check the clock regularly against more accurate time pieces and reset as necessary.

The Clock Battery

The camera clock is powered by an independent, rechargeable power source, which is charged as necessary when the main battery is installed or the camera is powered by an optional EP-5A power connector and EH-5b AC adapter (\square 76). Three days of charging will power the clock for about a month. If a message warning that the clock is not set is displayed when the camera is turned on, the clock battery is exhausted and the clock has been reset. Set the clock to the correct time and date.

Basic Photography

Battery Level and Card Capacity

Before shooting, check the battery level and number of exposures remaining.

1 Turn the camera on.

7

2 Check the battery level.


Check the battery level in the information display (if the battery is low, a warning will also be displayed in the viewfinder). If the monitor is off, press the 4b button to view the information display; if the monitor does not turn on, the battery is exhausted and must be recharged.



Information display	Viewfinder	Description
(111	_	Battery fully charged.
	_	Battery partially discharged.
	-	Low battery. Ready fully-charged spare battery or prepare to charge battery.
(flashes)	(flashes)	Battery exhausted; shutter release disabled. Charge or exchange battery.

3 Check the number of exposures remaining.

The information display and viewfinder show the number of photographs that can be taken at current settings (values over 1000 are rounded down to the nearest hundred; e.g., values between 1200 and 1299 are shown as 1.2 K). If a warning is displayed stating that there is not enough memory for additional photographs, insert another memory card (\$\square\$ 8) or delete some photos (\$\square\$ 25).



"Point-and-Shoot" Photography (♣ and ♠ Modes)

This section describes how to take photographs in * and * modes, automatic "point-and-shoot" modes in which the majority of settings are controlled by the camera in response to shooting conditions.



1 Turn the camera on.

Remove the lens cap and turn the camera on. The information display will appear in the monitor.

2 Select or 3 mode.

To shoot where use of a flash is prohibited, photograph infants, or capture natural lighting under low light, select auto (flash off) mode by rotating the mode dial to ③. Otherwise, rotate the dial to 🌇 (auto).





3 Ready the camera.

When framing photographs in the viewfinder, hold the handgrip in your right hand and cradle the camera body or lens with your left. Keep your elbows propped lightly against your torso for support and place one foot





half a pace ahead of the other to keep your upper body stable. When framing photographs in portrait (tall) orientation, hold the camera as shown at right.



In ③ mode, shutter speeds slow when lighting is poor; use of a tripod is recommended.

4 Frame the photograph.

Frame a photograph in the viewfinder with the main subject in the AF area brackets.



AF area brackets

5 Press the shutter-release button halfway.

Press the shutter-release button halfway to focus. The active focus point will be displayed. If the subject is poorly lit, the flash may pop up and the AF-assist illuminator may light.




6 Check the indicators in the viewfinder.

When the focus operation is complete, a beep will sound (a beep may not sound if the subject is moving) and the in-focus indicator () will appear in the viewfinder.

In-focus indicator	Description
•	Subject in focus.
• (flashes)	Camera unable to focus using
(Hasiles)	autofocus. See page 31.

While the shutter-release button is pressed halfway, the number of exposures that can be stored in the memory buffer ("¬"; □ 27) will be displayed in the viewfinder.




In-focus Buffer indicator capacity

Using a Zoom Lens

Use the zoom ring to zoom in on the subject so that it fills a larger area of the frame, or zoom out to increase the area visible in the final photograph (select longer focal lengths on the lens focal length scale to zoom in, shorter focal lengths to zoom out).

If the lens is equipped with a retractable lens barrel button $(\square 9)$, press and hold the button while rotating the zoom ring until the lens is released and the message shown at right is no longer displayed, and then adjust zoom using the zoom ring.





7 Shoot.

Smoothly press the shutter-release button the rest of the way down to release the shutter and record the photograph. The memory card access lamp will light and the photograph will be displayed in the monitor for a few seconds (the photo will automatically clear from the display when the shutter-release button is pressed halfway). Do not eject the memory card or remove or disconnect the power source until the lamp has aone out and recording is complete.






Image Sensor Cleaning

The camera vibrates the low-pass filter covering the image sensor to remove dust when the camera is turned on or off.

The Shutter-Release Button

The camera has a two-stage shutter-release button. The camera focuses when the shutter-release button is pressed halfway. To take the photograph, press the shutter-release button the rest of the way down.









Focus: press halfway

Shoot: press all the way down

The Standby Timer

The viewfinder and information display will turn off if no operations are performed for about eight seconds, reducing the drain on the battery. Press the shutter-release button halfway to reactivate the display. The length of time before the standby timer expires automatically can be selected using Custom Setting c2 (**Auto off timers**; \square 66).



The Built-in Flash

If additional lighting is required for correct exposure in mode, the built-in flash will pop up automatically when the shutter-release button is pressed halfway (\$\sigma\$ 36). If the flash is raised, photographs can only be taken when the flash-ready indicator (\$\frac{1}{2}\$) is displayed. If the flash-ready indicator is not displayed, the flash is charging; remove your finger briefly from the shutter-release button and try again.

To save battery power when the flash is not in use, return it to its closed position by pressing it gently downward till the latch clicks into place.






Creative Photography (Scene Modes)

The camera offers a choice of "scene" modes. Choosing a scene mode automatically optimizes settings to suit the selected scene, making creative photography as simple as selecting a mode, framing a picture, and shooting as described on pages 15–16.



The Mode Dial

The following scenes can be selected with the mode dial:







Use for portraits with soft, natural-looking skin tones. If the subject is far from the background or a telephoto lens is used, background details will be softened to lend the composition a sense of depth.





Use for vivid landscape shots in daylight. The built-in flash and AF-assist illuminator turn off; use of a tripod is recommended to prevent blur when lighting is poor.





Use for snapshots of children. Clothing and background details are vividly rendered, while skin tones remain soft and natural.

💐 Sports



Fast shutter speeds freeze motion for dynamic sports shots in which the main subject stands out clearly. The built-in flash and AF-assist illuminator turn off.


Close up



Use for close-up shots of flowers, insects, and other small objects (a macro lens can be used to focus at very close ranges). Use of a tripod is recommended to prevent blur.

Other Scenes

The following scenes can be selected by rotating the mode dial to **SCENE** and rotating the command dial until the desired scene appears in the monitor.







Use for a natural balance between the main subject and the background in portraits taken under low light. Use of a tripod is recommended to prevent blur.

M Night Landscape



Reduce noise and unnatural colors when photographing night landscapes, including street lighting and neon signs. The built-in flash and AF-assist illuminator turn off; use of a tripod is recommended to prevent blur.

X Party/Indoor



Capture the effects of indoor background lighting. Use for parties and other indoor scenes.

Beach/Snow



Capture the brightness of sunlit expanses of water, snow, or sand. The built-in flash and AF-assist illuminator turn off.




🚔 Sunset



Preserves the deep hues seen in sunsets and sunrises. The built-in flash and AFassist illuminator turn off; use of a tripod is recommended to prevent blur when lighting is poor.



📤 Dusk/Dawn



Preserves the colors seen in the weak natural light before dawn or after sunset. The built-in flash and AF-assist illuminator turn off; use of a tripod is recommended to prevent blur when lighting is poor.





Use for portraits of active pets. The AFassist illuminator turns off.

2 Candlelight



For photographs taken by candlelight. The built-in flash turns off; use of a tripod is recommended to prevent blur when lighting is poor.





Use for fields of flowers, orchards in bloom, and other landscapes featuring expanses of blossoms. The built-in flash turns off; use of a tripod is recommended to prevent blur when lighting is poor.

Autumn Colors



Captures the brilliant reds and yellows in autumn leaves. The built-in flash turns off; use of a tripod is recommended to prevent blur when lighting is poor.

Food



Use for vivid photographs of food. Use of a tripod is recommended to prevent blur; the built-in flash can also be used $(\square 36)$.

Playback and Deletion

Photographs are automatically displayed for a few seconds after shooting. If no photograph is displayed in the monitor, the most recent picture can be viewed by pressing the \blacksquare button.

Viewing Photographs

1 Press the **▶** button.

▶

A photograph will be displayed in the monitor.



▶ button



2 View additional pictures.


Additional pictures can be displayed by pressing ◀ or ▶ or rotating the command dial.





Display pictures

To display images in "contact sheets" of four, nine, or 72 images (thumbnail playback), press the ९☎ (?) button. To view images taken on a selected date (calendar playback), press the ९☎ (?) button when 72 images are displayed.



24

II Thumbnail Playback

Use the multi selector or command dial to highlight images and press ® to display the highlighted image full frame. Press ® to reduce the number of images displayed.





■■ Calendar Playback

Press the \mathbb{Q} (?) button to toggle between the date list and the list of thumbnails for the selected date. Use the multi selector to highlight dates in the date list or to highlight pictures in the thumbnail list. Press \mathbb{Q} when the cursor is in the date list to return to 72-frame playback.

Thumbnail list



Date list

Deleting Pictures

1 Display a picture and press the find button.

Display the picture you wish to delete and press the find button. A confirmation dialog will be displayed; to exit without deleting the picture, press .




└──| ш́ button



2 Press the $\tilde{\mathbf{m}}$ button again.

Press the fi button again to delete the picture.



More on Photography (All Modes)

Single-Frame, Continuous, Self-timer, **Remote, and Quiet Release Modes**

Choose from the following release modes:

Mode	Description
S	Single frame : Camera takes one photograph each time shutter-release button is pressed.
밀니	Continuous L (continuous low speed): The camera takes photographs at about 3 frames per
	second (fps) while the shutter-release button is pressed.
멜비	Continuous H (continuous high speed): The camera takes photographs at about 5 fps while
	the shutter-release button is pressed.
છ	Self-timer : Use self-timer for self-portraits or to reduce blurring caused by camera shake
	(CD 28).
a 2s	Delayed remote (ML-L3) : Shutter is released 2 s after shutter-release button on optional
	ML-L3 (\$\superscript{\Pi}\$ 77) remote control is pressed (\$\superscript{\Pi}\$ 28).
ê	Quick-response remote (ML-L3) : Shutter is released when shutter-release button on optional
	ML-L3 (\square 77) remote control is pressed (\square 28).
Q	Quiet shutter release : As for single frame, except that mirror does not click back into place
	while shutter-release button is fully pressed, allowing user to control timing of click
	made by mirror, which is also quieter than in single frame mode. Also, beep does not
	sound when camera focuses, keeping noise to a minimum in quiet surroundings.

Press 및 (᠔/a).

A list of release mode options will be displayed.





2 Choose a release mode.

Highlight a release mode and press ® to return to the information display. Photographs can be taken immediately.







The Memory Buffer

The camera is equipped with a memory buffer for temporary storage, allowing shooting to continue while photographs are being saved to the memory card. Up to 100 photographs can be taken in succession; note, however, that frame rate will drop when the buffer is full.

While photographs are being recorded to the memory card, the memory card access lamp will light (\$\sup\$ 17). Depending on the battery level and the number of the images in the buffer, recording may take from a few seconds to a few minutes. Do not remove the memory card or remove or disconnect the power source until the access lamp has gone out. If the camera is switched off while data remain in the buffer, the power will not turn off until all images in the buffer have been recorded. If the battery is exhausted while images remain in the buffer. the shutter release will be disabled and the images transferred to the memory card.

Continuous Release Modes

Continuous release modes can not be used with the built-in flash; rotate the mode dial to 3 $(\square 15)$ or turn the flash off $(\square 36-38)$.

Buffer Size

The approximate number of images that can be stored in the memory buffer at current settings is shown in the viewfinder exposure-count display while the shutter-release button is pressed. The illustration shows the display when space remains in the buffer for about 17 pictures.



The self-timer and optional ML-L3 remote control (\square 77) allow the photographer to be at a distance from the camera when a photo is taken.

- 1 Mount the camera on a tripod.

 Mount the camera on a tripod or place the camera on a stable, level surface.
- 2 Select a release mode.

 Select ॐ (Self-timer), ˚ 2s (Delayed remote (ML-L3)), or ˚ (Quick-response remote (ML-L3)) mode (□ 26; note that if no operations are performed for about a minute after a remote control mode is selected, the camera will automatically





□ (ⓒ/๑) buttor

return to single frame, continuous, or quiet shutter-release mode).

3 Frame the photograph.

Remote control mode: Check focus by pressing the shutter-release button halfway. No photograph will be taken even if the button is pressed all the way down.

4 Take the photograph.


Self-timer mode: Press the shutter-release button halfway to focus, and then press the button the rest of the way down. The self-timer lamp will start to flash and a beep will begin to sound. Two seconds before the photo is taken, the lamp will





stop flashing and the beeping will become more rapid. The shutter will be released ten seconds after the timer starts.

Remote control mode: From a distance of 5 m (16 ft) or less, aim the transmitter on the ML-L3 at either of the infrared receivers on the camera (\$\subseteq\$ 1, 2) and press the ML-L3 shutter-release button. In delayed remote mode, the self-timer lamp will light for about two seconds before the shutter is released. In quick-response remote mode, the self-timer lamp will flash after the shutter has been released.



Note that the timer may not start or a photograph may not be taken if the camera is unable to focus or in other situations in which the shutter can not be released. Turning the camera off cancels self-timer and remote control release modes and restores single frame, continuous, or quiet shutter-release mode.

LL Using Optional WR-R10 and WR-T10 Wireless Remote Controllers (\$\square\$ 77)

When a WR-T10 is used in combination with a WR-R10, the shutter-release button on the WR-T10 performs the same functions as the camera shutter-release button, allowing wireless remote control continuous and self-timer photography. For more information, see the manual provided with the WR-R10/WR-T10





WR-R10

WR-T10

☑ Before Using the ML-L3 Remote Control

Before using the ML-L3 for the first time, remove the clear plastic battery-insulator sheet.

Remote Control Photography

In quick-response (ML-L3) or delayed remote (ML-L3) release mode, the camera responds only to the shutter-release button on the ML-L3 remote control. Choose a different release mode when using WR-R10/WR-T10 wireless remote controllers.

Cover the Viewfinder

When taking photos without your eye to the viewfinder, remove the DK-20 rubber eyecup (①) and insert the supplied DK-5 eyepiece cap as shown (②). This prevents light entering via the viewfinder interfering with exposure. Hold the camera firmly when removing the rubber eyecup.



DK-5 eyepiece cap





✓ Using the Built-in Flash

Before taking a photograph with the flash in P, S, A, M, or ¶ mode, press the ¼ (日至) button to raise the flash and wait for the ¼ indicator to be displayed in the viewfinder (□ 18). Shooting will be interrupted if the flash is raised while a remote control mode is in effect or after the self-timer has started. If the flash is required, the camera will only respond to the ML-L3 shutter-release button once the flash has charged. In auto, scene, and special effects modes in which the flash pops up automatically, the flash will begin charging when a remote control mode is selected; once the flash is charged, it will automatically pop up and fire when required.

In flash modes that support red-eye reduction, the red-eye reduction lamp will light for about one second before the shutter is released in quick-response remote mode. In delayed remote mode, the self-timer lamp will light for two seconds, followed by the red-eye reduction lamp which lights for one second before the shutter is released.

See Also

For information on choosing the duration of the self-timer and the number of shots taken, see Custom Setting c3 (**Self-timer**; \square 66). For information on choosing how long the camera will wait for a signal from the remote, see Custom Setting c4 (**Remote on duration** (**ML-L3**); \square 66). For information on controlling the beeps that sound when the self-timer and remote control are used, see Custom Setting d1 (**Beep**; \square 66).

This section describes the focus options available when photographs are framed in the viewfinder. Focus can be adjusted automatically or manually (see "Focus Mode," below), and the focus point for automatic or manual focus can be selected using the multi selector.

Focus Mode

Choose from the following focus modes. Note that AF-S and AF-C are available only in modes P, S, A, and M.

	Option	Description
AF-A	Auto-servo AF	Camera automatically selects single-servo autofocus if subject is stationary, continuous-servo autofocus if subject is moving. Shutter can only be released if camera is able to focus.
AF-S	Single-servo AF	For stationary subjects. Focus locks when shutter-release button is pressed halfway. Shutter can only be released if camera is able to focus.
AF-C	Continuous- servo AF	For moving subjects. Camera focuses continuously while shutter-release button is pressed halfway. If subject moves, camera will engage predictive focus tracking to predict final distance to subject and adjust focus as necessary (\$\square\$ 31). At default settings, shutter can only be released if camera is able to focus.
MF	Manual focus	Focus using the lens focus ring.

1 Place the cursor in the information display.

If shooting information is not displayed in the monitor, press the 🕩 button. Press the 🕩 button again to place the cursor in the information display.





⊕ button Information display

2 Display focus-mode options. Highlight the current focus mode in the information display and press **⊗**.





3 Choose a focus mode.

Highlight a focus mode and press 8. To return to shooting mode, press the shutter-release button halfway.







Predictive Focus Tracking

In AF-C mode or when continuous-servo autofocus is selected in AF-A mode, the camera will initiate predictive focus tracking if the subject moves toward the camera while the shutter-release button is pressed halfway. This allows the camera to track focus while attempting to predict where the subject will be when the shutter is released.

Continuous-servo Autofocus

When **Focus** is selected for Custom Setting a1 (**AF-C priority selection**; \square 66) and the camera is in **AF-C** mode or continuous-servo autofocus is selected in **AF-A** mode, the camera gives higher priority to focus response (has a wider focus range) than in **AF-S** mode, and the shutter may be released before the in-focus indicator is displayed.

Getting Good Results with Autofocus

Autofocus does not perform well under the conditions listed below. The shutter release may be disabled if the camera is unable to focus under these conditions, or the in-focus indicator () may be displayed and the camera may sound a beep, allowing the shutter to be released even when the subject is not in focus. In these cases, focus manually or use focus lock to focus on another subject at the same distance and then recompose the photograph.



There is little or no contrast between the subject and the background.

Example: Subject is the same color as the background.

The focus point contains objects at different distances from the camera.

Example: Subject is inside a cage.



The subject is dominated by regular geometric patterns.

Example: Blinds or a row of windows in a skyscraper.



The focus point contains areas of sharply contrasting brightness.

Example: Subject is half in the shade.



Background objects appear larger than the subject.

Example: A building is in the frame behind the subject.



The subject contains many fine details.

Example: A field of flowers or other subjects that are small or lack variation in brightness.

See Also

For information on the focus modes available in live view, see page 46. For information on using release priority in continuous-servo AF, see Custom Setting a1 (**AF-C priority selection**, \square 66). Custom Setting d1 (**Beep**; \square 66) can be used to turn the beep speaker on or off.

AF-Area Mode

Choose how the focus point for autofocus is selected. Note that [4] (dynamic-area) and [3D] (3D-tracking) AF-area modes are not available when AF-S is selected for focus mode.

Option		Description
[11]	Single-point AF	User selects focus point using multi selector (\$\square\$ 33); camera focuses on subject in selected focus point only. Use with stationary subjects.
::39	Dynamic-area AF (9 points)	In AF-A and AF-C focus modes, user selects focus point using multi selector (\$\square\$ 33), but camera will focus based on information from surrounding focus points if subject briefly leaves selected point. The number of focus points varies with the mode selected:
⊡21	Dynamic-area AF (21 points)	 9-point dynamic-area AF: Choose when there is time to compose the photograph or when photographing subjects that are moving predictably (e.g., runners or race cars on a track). 21-point dynamic-area AF: Choose when photographing subjects that
ۥ 339	Dynamic-area AF (39 points)	 are moving unpredictably (e.g., players at a football game). 39-point dynamic-area AF: Choose when photographing subjects that are moving quickly and can not be easily framed in the viewfinder (e.g., birds).
[3D]	3D-tracking	In AF-A and AF-C focus modes, user selects focus point using multi selector (33). If subject moves after camera has focused, camera uses 3D-tracking to select new focus point and keep focus locked on original subject while shutter-release button is pressed halfway. Use to quickly compose pictures with subjects that are moving erratically from side to side (e.g., tennis players). If subject leaves viewfinder, remove your finger from shutter-release button and recompose photograph with subject in selected focus point.
	Auto-area AF	Camera automatically detects subject and selects focus point.

1 Place the cursor in the information display.

If shooting information is not displayed in the monitor, press the 🕩 button. Press the 🕩 button again to place the cursor in the information display.





⊕ button Information display

2 Display AF-area mode options. Highlight the current AF-area mode in the information display and press ®.





3 Choose an AF-area mode.

Highlight an option and press ®. To return to shooting mode, press the shutter-release button halfway.





Focus Point Selection

In manual focus mode or when autofocus is combined with AF-area modes other than (Auto-area AF), you can choose from 39 focus points, making it possible to compose photographs with the main subject almost anywhere in the frame.

1 Choose an AF-area mode other than (Auto-area AF; \(\omega\) 32).



2 Select the focus point.

Use the multi selector to select the focus point in the viewfinder or information display while the exposure meters are on. Press ® to select the center focus point.











For information on the AF-area modes available in live view, see page 47. For information on using the **Fn** button and the command dial to select an AF-area mode, see Custom Setting f1 (**Assign Fn button**, \square 66).

Together, image quality and size determine how much space each photograph occupies on the memory card. Larger, higher quality images can be printed at larger sizes but also require more memory, meaning that fewer such images can be stored on the memory card.

Image Quality

Choose a file format and compression ratio (image quality).

File type	Description
	Two images are recorded: one NEF (RAW) image and one fine-quality JPEG
	image.
NEF/	Two images are recorded: one NEF (RAW) image and one normal-quality
JPEG	JPEG image.
	Two images are recorded: one NEF (RAW) image and one basic-quality
	JPEG image.
NEE	Raw 14-bit data from the image sensor are saved directly to the memory card. Settings such as white balance and contrast can be adjusted after
INEF	shooting.
	Record JPEG images at a compression ratio of roughly 1:4 (fine quality).
JPEG	Record JPEG images at a compression ratio of roughly 1:8 (normal quality).
	Record JPEG images at a compression ratio of roughly 1:16 (basic quality).
	NEF/ JPEG

1 Place the cursor in the information display.

If shooting information is not displayed in the monitor, press the 🕩 button. Press the 🕩 button again to place the cursor in the information display.





Information display

2 Display image quality options. Highlight the current image quality in the information display and press **®**.





3 Choose a file type.

Highlight an option and press ®. To return to shooting mode, press the shutter-release button halfway.







Image Size

Choose a size for JPEG images (this option is not available for RAW-quality images; \square 34).

lmage size	Size (pixels)	Print size (cm/in.)*
■ Large	6000 × 4000	50.8 × 33.9/20 × 13.3
M Medium	4496 × 3000	38.1 × 25.4/15.0 × 10
S Small	2992 × 2000	25.3 × 16.9/10 × 6.7

^{*} Approximate size when printed at 300 dpi. Print size in inches equals image size in pixels divided by printer resolution in dots per inch (dpi; 1 inch=approximately 2.54 cm).

1 Place the cursor in the information display.

If shooting information is not displayed in the monitor, press the 🕩 button. Press the 🕩 button again to place the cursor in the information display.





♠ button

Information display

2 Display image size options. Highlight the current image size in the information display and press (®).





3 Choose an image size.

Highlight an option and press ®. To return to shooting mode, press the shutter-release button halfway.





File Names

Photographs are stored as image files with names of the form "DSC_nnnn.xxx," where nnnn is a four-digit number between 0001 and 9999 assigned automatically in ascending order by the camera, and xxx is one of the following three-letter extensions: "NEF" for NEF images, "JPG" for JPEG images, or "MOV" for movies. The NEF and JPEG files recorded at a setting of NEF (RAW)+JPEG have the same file names but different extensions.

Image quality and size can also be adjusted by rotating the command dial while keeping the **Fn** button pressed. See Custom Setting f1 (**Assign Fn button**, \square 66).

The camera supports a variety of flash modes for photographing poorly lit or backlit subjects.

■■ Using the Built-in Flash: 👸, 🏖, 🤹, 📞, 🖼, 💥, 🖼, and 🦁 Modes

- 1 Choose a flash mode (37).
- **2** Take pictures.

 The flash will pop up as required when the shutter-release button is pressed halfway, and fire when a photograph is taken. If the flash does not pop up automatically, DO NOT attempt to raise it by hand. Failure to observe this precaution could damage the flash.





■■ Using the Built-in Flash: P, S, A, M, and ¶¶ Modes

- 1 Raise the flash.

 Press the 4 (22) button to raise the flash.
- 2 Choose a flash mode (P, S, A, and M modes only; \square 37).
- **3** Take pictures.

 The flash will fire whenever a picture is taken.



🗲 (日達) button

Lowering the Built-in Flash

To save power when the flash is not in use, press it gently downward until the latch clicks into place.



Ô

Flash Mode

The flash modes available vary with shooting mode:

AUTO €	, ≥, ₩, ¾, જ	⊠		T1	
\$ AUTO	Auto	4@AUTO	Auto slow sync+ red-eye reduction	4	Fill flash
‡⊚ AUTO	Auto+red-eye reduction	≠ SLOW	red-eye reduction		
3	Flash off	4 AUTO SLOW	Auto slow sync		
		•	Flash off		

P, A		S, M	
4	Fill flash	4	Fill flash
4©	Red-eye reduction	40	Red-eye reduction
SLOW	Slow sync+red-eye reduction	\$ REAR	Rear-curtain sync
\$slow	Slow sync		
4SLOW FREΔR	Rear-curtain + slow sync	-	

1 Place the cursor in the information display.

If shooting information is not displayed in the monitor, press the 🕩 button. Press the 🕩 button again to place the cursor in the information display.





∙B∙ button

Information display

2 Display flash mode options. Highlight the current flash mode in the information display and press **®**.





3 Choose a flash mode.

Highlight a mode and press @. To return to shooting mode, press the shutter-release button halfway.





Flash Modes

The flash modes listed on the previous page may combine one or more of the following settings, as shown by the flash mode icon:

- AUTO (auto flash): When lighting is poor or subject is backlit, flash pops up automatically when shutter-release button is pressed halfway and fires as required.
- • (red-eye reduction): Use for portraits. Red-eye reduction lamp lights before flash fires, reducing "red-eye."
- (off): Flash does not fire even when lighting is poor or subject is backlit.
- **SLOW** (**slow sync**): Shutter speed slows automatically to capture background lighting at night or under low light. Use to include background lighting in portraits.
- REAR (rear-curtain sync): Flash fires just before shutter closes, creating a stream of light behind
 moving light sources (below at right). If this icon is not displayed, flash will fire as the
 shutter opens (front-curtain sync; the effect this produces with moving light sources is
 shown below at left).



Front-curtain sync



Rear-curtain sync

Choosing a Flash Mode

The flash mode can also be selected by rotating the command dial while keeping the \$ (102) button pressed (in P, S, A, M, and 11 modes, raise the flash before using the \$ (102) button to choose the flash mode).



4 (፭물) button



Command dial



Information display

The Built-in Flash

For information on the lenses that can be used with the built-in flash, see the *Reference Manual*. Remove lens hoods to prevent shadows. The flash has a minimum range of 0.6 m (2 ft) and can not be used in the macro range of zoom lenses with a macro function.

The shutter release may be briefly disabled to protect the flash after it has been used for several consecutive shots. The flash can be used again after a short pause.

Shutter Speeds Available with the Built-in Flash

Shutter speed is restricted to the following ranges when the built-in flash is used:

Mode	Shutter speed	Mode	Shutter speed
ato, £ , ⊈ , ※, ₩, ♥, P, A	¹ /200 ^{–1} /60 S	S	¹ / ₂₀₀ –30 s
₩, †1	¹ / ₂₀₀ – ¹ / ₁₂₅ S	M	¹ / ₂₀₀ –30 s, Bulb
D.	¹ /200–1 s		

Shutter speeds as slow as 30 s are available in slow sync, rear curtain + slow sync, and slow sync + red-eye reduction modes.

ISO Sensitivity

"ISO sensitivity" is the digital equivalent of film speed. The higher the ISO sensitivity, the less light needed to make an exposure, allowing higher shutter speeds or smaller apertures, but the more likely the image is to be affected by noise (randomly-spaced bright pixels, fog, or lines; noise is particularly likely at settings between Hi 0.3 (equivalent to ISO 8000) and Hi 2 (equivalent to ISO 25600)). Choosing **Auto** allows the camera to set ISO sensitivity automatically in response to lighting conditions.

Mode	ISO sensitivity
auto, ③, 🛂	Auto
P, S, A, M	100–6400 in steps of ¹ / ₃ EV; Hi 0.3, Hi 0.7, Hi 1, Hi 2
Other shooting modes	Auto; 100–6400 in steps of ¹ / ₃ EV; Hi 0.3, Hi 0.7, Hi 1, Hi 2

1 Place the cursor in the information display.

If shooting information is not displayed in the monitor, press the 🕩 button. Press the 🕩 button again to place the cursor in the information display.





⊕ button

Information display

2 Display ISO sensitivity options. Highlight the current ISO sensitivity in the information display and press **®**.





3 Choose an ISO sensitivity.
Highlight an option and press . To return to shooting mode, press the shutter-release button halfway.





See Also

Auto ISO sensitivity control can be enabled in modes P, S, A, and M using the **Auto ISO** sensitivity control option in the **ISO** sensitivity settings menu (\square 66). For information on using the **High ISO NR** option in the shooting menu to reduce noise at high ISO sensitivities, see page 66. For information on using the **Fn** button and the command dial to select ISO sensitivity, see Custom Setting f1 (**Assign Fn button**, \square 66).

Interval Timer Photography

The camera is equipped to take photographs automatically at preset intervals.

☑ Before Shooting


Before beginning interval timer photography, take a test shot at current settings and view the results in the monitor. To ensure that shooting starts at the desired time, select **Time zone and date** in the setup menu and check that the camera clock is set correctly (\square 66).

Use of a tripod is recommended. Mount the camera on a tripod before shooting begins. To ensure that shooting is not interrupted, be sure the battery is fully charged or use an optional EH-5b AC adapter and EP-5A power connector.

1 Select Interval timer shooting.

Press the MENU button to display the menus.

Highlight Interval timer shooting in the shooting menu and press ▶.




2 Choose a starting time.

Choose from the following starting triggers.

- To start shooting immediately, highlight Now and press ▶. Shooting begins about three seconds after settings are completed; proceed to Step 3.









3 Choose the interval.

Press \blacktriangleleft or \blacktriangleright to highlight hours, minutes, or seconds and press \blacktriangle or \blacktriangledown to choose an interval longer than the slowest anticipated shutter speed. Press \blacktriangleright to continue.







4 Choose the number of intervals.

Press ◀ or ▶ to highlight number of intervals (i.e., the number of times the camera shoots); press ▲ or ▼ to change. Press ▶ to continue.





5 Start shooting.

Highlight **On** and press (to return to the shooting menu without starting the interval timer, highlight **Off** and press (shots will be taken at the specified starting time, or after about 3 s if **Now** was





selected for **Choose start time** in Step 2. Shooting will continue at the selected interval until all shots have been taken. Note that because shutter speed and the time needed to record the image to the memory card may vary from shot to shot, intervals may be skipped if the camera is still in the process of recording the previous interval. If shooting can not proceed at current settings (for example, if a shutter speed of "Bulb" is currently selected in shooting mode **M** or the start time is in less than a minute), a warning will be displayed in the monitor

Cover the Viewfinder

To prevent light entering via the viewfinder interfering with exposure, remove the rubber eyecup and cover the viewfinder with the supplied DK-5 eyepiece cap (\square 29).

Other Settings

Settings can not be adjusted during interval timer photography. Regardless of the release mode selected, the camera takes one photograph at each interval; in mode , camera noise will be reduced. Bracketing, multiple exposure, and high dynamic range (HDR) can not be used.

Interrupting Interval Timer Photography

To interrupt interval timer shooting, turn the camera off or rotate the mode dial to a new setting. Returning the monitor to the storage position does not interrupt interval timer shooting.

P, S, A, and M Modes


P, S, A, and **M** modes offer different degrees of control over shutter speed and aperture:



	Mode	Description
P	Programmed auto (\$\square\$ 43)	Camera sets shutter speed and aperture for optimal exposure. Recommended for snapshots and in other situations in which there is little time to adjust camera settings.
S	Shutter-priority auto (□ 43)	User chooses shutter speed; camera selects aperture for best results. Use to freeze or blur motion.
A	Aperture-priority auto (\$\sime\$ 43)	User chooses aperture; camera selects shutter speed for best results. Use to blur background or bring both foreground and background into focus.
М	Manual (🕮 43)	User controls both shutter speed and aperture. Shutter speeds of "Bulb" and "Time" are available for long time-exposures of fireworks or the night sky.

Shutter Speed and Aperture

The same exposure can be achieved with different combinations of shutter speed and aperture. Fast shutter speeds and large apertures freeze moving objects and soften background details, while slow shutter speeds and small apertures blur moving objects and bring out background details.



Mode P (Programmed Auto)

In this mode, the camera automatically adjusts shutter speed and aperture for optimal exposure in most situations.

User can rotate command dial to choose from different combinations of shutter speed and aperture that will produce optimal exposure.



Command dial

Mode S (Shutter-Priority Auto)

In shutter-priority auto, you choose the shutter speed while the camera automatically selects the aperture that will produce the optimal exposure.

To choose a shutter speed, rotate the command dial.





Mode A (Aperture-Priority Auto)

In aperture-priority auto, you choose the aperture while the camera automatically selects the shutter speed that will produce the optimal exposure.

To choose an aperture, rotate the command dial (the maximum and minimum values for aperture vary with the lens used).



Command dial



Mode M (Manual)

In manual mode, you control both shutter speed and aperture.

Shutter speed is set by rotating the command dial, aperture by rotating the command dial while keeping the (2) button pressed (the maximum and minimum values for aperture vary with the lens used). Check exposure using the exposure indicator.







Command dial

The Exposure Indicator		
Optimal exposure	Underexposed by 1/3 EV	Overexposed by over 2 EV
- . 0 . +	₁ . +	0 + · · Inini∍

Exposure compensation is used to alter exposure from the value suggested by the camera, making pictures brighter or darker. Choose from values between -5 EV (underexposure) and +5 EV (overexposure) in increments of $^{1}/_{3}$ EV. In general, positive values make the subject brighter while negative values make it darker.

1 Place the cursor in the information display. If shooting information is not displayed in the monitor, press the 4 button. Press the 4 button again to place the cursor in the information display.





🚯 button 💎 Information display

ΔŤ

2 Display exposure compensation options. Highlight exposure compensation in the information display and press **®**.





3 Choose a value.

Highlight a value and press . To return to shooting mode, press the shutter-release button halfway.





Normal exposure can be restored by setting exposure compensation to ± 0 . Exposure compensation is not reset when the camera is turned off, but is reset if you select another mode after choosing \square .

✓ The
✓ (②) Button

Exposure compensation can also be set by rotating the command dial while keeping the **☑** (②) button pressed.







☑ (ᢀ) button Command dial


Live View

Framing Photographs in the Monitor

Follow the steps below to take photographs in live view.

1 Rotate the live view switch.

The mirror will be raised and the view through the lens will be displayed in the camera monitor. The subject will no longer be visible in the viewfinder.



Live view switch

2 Position the focus point.

Position the focus point over your subject as described on page 48.




Focus point

3 Focus.

Press the shutter-release button halfway. The focus point will flash green while the camera focuses. If the camera is able to focus, the focus point will be displayed in green; if the camera is unable to focus, the focus point will flash red (note that pictures can be taken even when the focus point flashes red; check focus in the monitor before shooting). Except in and and modes, exposure can be locked by pressing the

4 Take the picture.

Press the shutter-release button the rest of the way down. The monitor turns off and the memory card access lamp lights during recording. Do not remove the battery or memory card or unplug the optional AC adapter until recording is complete. When shooting is



Memory card access lamp

complete, the photograph will be displayed in the monitor for a few seconds or until the shutter-release button is pressed halfway. The camera will then return to live view mode. To exit, rotate the live view switch.

Focusing in Live View


Follow the steps below to choose focus and AF-area modes and position the focus point.

■ Choosing a Focus Mode

Option	Description
AF-S Single-servo AF	For stationary subjects. Focus locks when shutter-release button is pressed halfway.
AF-F Full-time-servo AF	For moving subjects. Camera focuses continuously until shutter- release button is pressed. Focus locks when shutter-release button is pressed halfway.
MF Manual focus	Focus using the lens focus ring.

1 Place the cursor in the information display.

Press the button to place the cursor in the information display.



2 Display focus options.

Highlight the current focus mode in the information display and press ®.





3 Choose a focus option.

Highlight an option and press

Highlight an option and press 8. To return to live view, press 1.





■■ Choosing an AF-Area Mode

	Option	Description
(<u>@</u>)	Face-priority AF	The camera automatically detects and focuses on portrait
_		subjects. Use for portraits.
	Wide-area AF	Use for hand-held shots of landscapes and other non-portrait
WIDE		subjects. Use the multi selector to select the focus point.
[c:]	Normal-area AF	Use for pin-point focus on a selected spot in the frame. A tripod is
NORM	NOTITIAI-atea Ar	recommended.
(Subject-tracking AF	Track a selected subject as it moves through the frame.
		I .

1 Place the cursor in the information display.

Press the \P button to place the cursor in the information display.



⊕ button

2 Display AF-area modes.

Highlight the current AF-area mode in the information display and press ®.





3 Choose an AF-area mode.

Highlight an option and press ${}^{\circledR}$. To return to live view, press ${}^{\blacktriangleleft}$.





II Choosing the Focus Point

The method for selecting the focus point for autofocus varies with the option selected for AF-area mode $(\square 47)$.

(face-priority AF): A double yellow border will be displayed when the camera detects a portrait subject (if multiple faces, up to a maximum of 35, are detected, the camera will focus on the closest subject; to choose a different subject, use the multi selector). If the camera can no longer detect the subject (because, for example, the subject has turned to face away from the camera), the border will no longer be displayed.

₩ (wide- and normal-area AF): Use the multi selector to move the focus point anywhere in the frame, or press to position the focus point in the center of the frame.





Focus point





Focus point

(subject-tracking AF): Position the focus point over your subject and press (solution). The focus point will track the selected subject as it moves through the frame. To end focus tracking, press (solution) a second time.






Focus point

Subject Tracking

The camera may be unable to track subjects if they move quickly, leave the frame or are obscured by other objects, change visibly in size, color, or brightness, or are too small, too large, too bright, too dark, or similar in color or brightness to the background.

The Live View Display




ltem		Description	
1	Shooting mode	The mode currently selected with the mode dial.	15, 19, 42, 58
2	"No movie" icon	Indicates that movies can not be recorded.	
3	Time remaining The amount of time remaining before live view ends automatically. Displayed if shooting will end in 30 s or		51, 56
4	Microphone sensitivity for movie recording.		55
5	Sound level Sound level for audio recording. Displayed in red if level is high; adjust microphone sensitivity accordingly.		55
6	Focus mode	The current focus mode.	
7	AF-area mode	The current AF-area mode.	
8	Time remaining (movie mode)	I he recording time remaining in movie mode	
9	Movie frame size	The trame size of movies recorded in movie mode	
10	Manual movie settings indicator	Displayed when On is selected for Manual movie settings in mode M	
1	Focus point	The current focus point. The display varies with the option selected for AF-area mode (\square 47).	48
12	Exposure indicator	Indicates whether the photograph would be under- or over- exposed at current settings (mode M only).	43

Note: Display shown with all indicators lit for illustrative purposes.

Live View/Movie Recording Display Options

Press the button to cycle through display options as shown below.

Circled areas indicate edges of movie frame crop



* A crop showing the area recorded is displayed during movie recording when frame sizes other than 640 × 424 are selected for **Movie settings** > **Frame size/frame rate** in the shooting menu (\$\Pi\$ 55; the area outside the movie frame crop is grayed out when movie indicators are displayed).

Automatic Scene Selection (Scene Auto Selector)

If live view is selected in * or * or * mode, the camera will automatically analyze the subject and select the appropriate shooting mode when autofocus is enabled. The selected mode is shown in the monitor (\square 49).

Ž *	Portrait	Human portrait subjects
~	Landscape	Landscapes and cityscapes
\$	Close up Subjects close to the camera	
<u>*</u>	Night portrait	Portrait subjects framed against a dark background
AUTO♥	Auto	Subjects suited to 🗳 or 3 mode or that do not fall into the categories
③ *	Auto (flash off)	listed above

Exposure

Depending on the scene, exposure may differ from that which would be obtained when live view is not used. Metering in live view is adjusted to suit the live view display, producing photographs with exposure close to what is seen in the monitor. In **P, S, A**, and modes, exposure can be adjusted by ±5 EV in increments of 1/3 EV by rotating the command dial while keeping the modes, exposure can be previewed in the monitor.

Shooting in Live View Mode

To prevent light entering via the viewfinder from interfering with exposure, remove the rubber eyecup and cover the viewfinder with the supplied DK-5 eyepiece cap before shooting (\square 29).

Although they will not appear in the final picture, distortion may be visible in the monitor if the camera is panned horizontally or an object moves at high speed through frame. Bright light sources may leave after-images in the monitor when the camera is panned. Bright spots may also appear. Flicker and banding visible in the monitor under fluorescent, mercury vapor, or sodium lamps can be reduced using **Flicker reduction** (\square 66), although they may still be visible in the final photograph at some shutter speeds. When shooting in live view mode, avoid pointing the camera at the sun or other strong light sources. Failure to observe this precaution could result in damage to the camera's internal circuitry.

Live view ends automatically if the lens is removed or when the monitor is closed (closing the monitor does not end live view on televisions or other external displays).

Live view may end automatically to prevent damage to the camera's internal circuits; exit live view when the camera is not in use. Note that the temperature of the camera's internal circuits may rise and noise (bright spots, randomly-spaced bright pixels, or fog) may be displayed in the following instances (the camera may also become noticeably warm, but this does not indicate a malfunction):

- The ambient temperature is high
- The camera has been used for extended periods in live view or to record movies
- The camera has been used in continuous release mode for extended periods

If live view does not start when you attempt to start live view, wait for the internal circuits to cool and then try again.

The Count Down Display

A count down will be displayed 30 s before live view ends automatically $\ \square$ 49; the timer turns red 5 s before the auto off timer expires or if live view is about to end to protect the internal circuits). Depending on shooting conditions, the timer may appear immediately when live view is selected. Note that although the count down does not appear in the information display or during playback, live view will still end automatically when the timer expires.

✓ Using Autofocus in Live View

Autofocus is slower in live view and the monitor may brighten or darken while the camera focuses. The camera may be unable to focus in the following situations:

- The subject contains lines parallel to the long edge of the frame
- The subject lacks contrast
- The subject in the focus point contains areas of sharply contrasting brightness, or the subject is lit by spot lighting or by a neon sign or other light source that changes in brightness
- Flicker or banding appears under fluorescent, mercury-vapor, sodium-vapor, or similar lighting
- A cross (star) filter or other special filter is used
- The subject appears smaller than the focus point
- The subject is dominated by regular geometric patterns (e.g., blinds or a row of windows in a skyscraper)
- · The subject is moving

Note that the focus point may sometimes be displayed in green when the camera is unable to focus.

県

Recording and Viewing Movies

Recording Movies

Movies can be recorded in live view mode.

1 Rotate the live view switch.


The mirror is raised and the view through the lens is displayed in the monitor instead of the viewfinder.

The 🔯 Icon

A 🔯 icon (🗆 49) indicates that movies can not be recorded.

Before Recording

Set aperture before recording in mode A or M.



Live view switch

2 Focus.

Frame the opening shot and focus as described in Steps 2 and 3 of "Framing Photographs in the Monitor" (\square 45; see also "Focusing in Live View" on pages \square 46–48). Note that the number of subjects that can be detected in face-priority AF drops during movie recording.



3 Start recording.

Press the movie-record button to start recording. A recording indicator and the time available are displayed in the monitor. Except in and $\mathfrak D$ modes, exposure can be locked by pressing the $\mathfrak E$ ($\mathfrak D$ - $\mathfrak D$) button or (in modes $\mathfrak P$, $\mathfrak S$, $\mathfrak A$, and $\mathfrak D$) altered by up to ± 3 EV in steps of $^{1}/_{3}$ EV by pressing the $\mathfrak D$ ($\mathfrak D$) button and rotating the command dial (note that depending on the brightness of the subject, changes to exposure may have no visible effect).



Movie-record button

Recording indicator



Time remaining

4 End recording.

Press the movie-record button again to end recording. Recording will end automatically when the maximum length is reached, the memory card is full, another mode is selected, the lens is removed, or the monitor is closed (closing the monitor does not end recording on televisions or other external displays).

Taking Photographs During Movie Recording

To end movie recording, take a photograph, and exit to live view, press the shutter-release button all the way down and hold it in this position until the shutter is released.

Maximum Length

The maximum length for individual movie files is 4 GB (for maximum recording times, see page 55); note that depending on memory card write speed, shooting may end before this length is reached (\square 77).

Recording Movies

Flicker, banding, or distortion may be visible in the monitor and in the final movie under fluorescent, mercury vapor, or sodium lamps or if the camera is panned horizontally or an object moves at high speed through frame (flicker and banding can be reduced using **Flicker reduction**; \square 66). Bright light sources may leave after-images when the camera is panned. Jagged edges, color fringing, moiré, and bright spots may also appear. Bright bands may appear in some areas of the frame if the subject is briefly illuminated by a flash or other bright, momentary light source. When recording movies, avoid pointing the camera at the sun or other strong light sources. Failure to observe this precaution could result in damage to the camera's internal circuitry.

The camera can record both video and sound; do not cover the microphone during recording. Note that the built-in microphone may record lens noise during autofocus and vibration reduction

Flash lighting can not be used during movie recording.

Live view may end automatically to prevent damage to the camera's internal circuits; exit live view when the camera is not in use. Note that the temperature of the camera's internal circuits may rise and noise (bright spots, randomly-spaced bright pixels, or fog) may be displayed in the following instances (the camera may also become noticeably warm, but this does not indicate a malfunction):

- The ambient temperature is high
- The camera has been used for extended periods in live view or to record movies
- The camera has been used in continuous release mode for extended periods

If live view does not start when you attempt to start live view or movie recording, wait for the internal circuits to cool and then try again.

Matrix metering is used regardless of the metering method selected. Shutter speed and ISO sensitivity are adjusted automatically unless **On** is selected for **Manual movie settings** (\$\Pi\$ 56) and the camera is in mode **M**.

Movie Settings

Use the **Movie settings** option in the shooting menu to adjust the following settings.

• Frame size/frame rate, Movie quality: Choose from the following options. The frame rate depends on the option currently selected for **Video mode** in the setup menu (\$\square\$ 66):

	Frame size	frame rate	Movie quality	Maximum length
	Frame size (pixels)	Frame rate ¹	Maximum bit rate (Mbps) (★ high quality/Normal)	(★ high quality/Normal) 4
1080 i * / 1080 i	1920 × 1080	60i ²		
1080 i * 1080 i		50i ³		
1080 P* / 1080 P		30p ²	24/12	20 min./29 min. 59 s
1080 1080		25p ³		
1080 24 / 1080 24		24p		
720 px / 720 p	↓ 1280 × 720 ∣	60p ²		
720 % / 720 %		50p ³		
424 PA / 424 PD	↓ 640 × 424 ↓	30p ²	8/5	29 min. 59 s/
424 pt / 424 pt		25p ³	0/3	29 min. 59 s

- 1 Listed value. Actual frame rates for 60p, 50p, 30p, 25p, and 24p are 59.94, 50, 29.97, 25, and 23.976 fps respectively.
- 2 Available when NTSC is selected for Video mode.
- 3 Available when **PAL** is selected for **Video mode**.
- 4 Movies recorded in miniature effect mode are up to three minutes long when played back.

The Movie Crop

The movie crop can be viewed during live view by pressing the \blacksquare button to select the "show movie indicators", "hide indicators", or "framing grid" display (\square 50). A smaller crop (shown by the illustration below at left) is used for movies with a **Frame size/frame rate** of $1920 \times 1080 60i$ or 50i; during shooting, this crop is enlarged to fill the monitor as shown below at right.



1920 × 1080 60i/50i crop



Recording in progress


• Manual movie settings: Choose On to allow manual adjustments to shutter speed and ISO sensitivity when the camera is in mode M. Shutter speed can be set to values as fast as ¹/₄₀₀₀ s; the slowest speed available varies with the frame rate: ¹/₃₀ s for frame rates of 24p, 25p, and 30p, ¹/₅₀ s for 50i or 50p, and ¹/₆₀ s for 60i or 60p. ISO sensitivity can be set



to values between ISO 100 and Hi 2 (\square 39). If shutter speed and ISO sensitivity are not in these ranges when live view starts, they will automatically be set to supported values, and remain at these values when live view ends. Note that ISO sensitivity is fixed at the value selected; the camera does not adjust ISO sensitivity automatically when **On** is selected for **ISO sensitivity settings** > **Auto ISO sensitivity control** in the shooting menu (\square 66).

1 Select Movie settings.

Press the MENU button to display the menus. Highlight **Movie settings** in the shooting menu and press ▶.



2 Choose movie options.

Highlight the desired item and press ▶, then highlight an option and press ⋈.





Using an External Microphone

The optional ME-1 stereo microphone can be used to reduce noise caused by lens vibration being recorded during autofocus.

▼ The Count-Down Display

A count down will be displayed 30 s before live view ends automatically (\square 49). Depending on shooting conditions, the timer may appear immediately when movie recording begins. Note that regardless of the amount of recording time available, live view will still end automatically when the timer expires. Wait for the internal circuits to cool before resuming movie recording.


See Also

For information on the indicators displayed in live view, see page 49. For information on choosing focus and AF-area modes, see page 46. See page 52 for information on focusing in live view.



Viewing Movies

Movies are indicated by a \P icon in full-frame playback (\square 24). Press 8 to start playback.



The following operations can be performed:

То	Use	Description				
Pause	(OK)	Pause playback.				
Play	(OK)	Resume playback when movie is paused or during rewind/advance.				
Advance/ rewind		Speed increases with each press, from $2\times$ to $4\times$ to $8\times$ to $16\times$; keep pressed to skip to beginning or end of movie (first frame is indicated by \blacksquare in top right corner of monitor, last frame by \blacksquare). If playback is paused, movie rewinds or advances one frame at a time; hold for continuous rewind or advance.				
Skip 10 s		Rotate the command dial to skip ahead or back 10 s.				
Adjust volume	୩/୧≊ (?)	Press [®] to increase volume, [©] (?) to decrease.				
Edit movie	AF-L (O-n)	To edit movie, press AFL (O-n) while movie is paused.				
Return to full- frame playback	(K) / [N]	Press ▲ or ▶ to exit to full-frame playback.				
Exit to shooting mode	▼	Press shutter-release button halfway. Monitor will turn off; photographs can be taken immediately.				

The ⋈ Icon

図 is displayed in full-frame and movie playback if the movie was recorded without sound.




Special Effects

Special effects can be used when recording images.



Shooting with Special Effects

The following effects can be selected by rotating the mode dial to EFFECTS and rotating the command dial until the desired option appears in the monitor.





NEF (RAW)

If NEF (RAW)+JPEG is selected for image quality in \square , \triangleleft , or \nearrow mode, only the JPEG images will be recorded (\square 34). If NEF (RAW) is selected, fine-quality JPEG photographs will be recorded instead of NEF (RAW) images.

Continuous Release Modes

When 🐯 or ₲ is selected, the frame rate for continuous release will drop. If the memory buffer fills, the camera will display a message indicating that recording is in progress and shooting will be suspended until the message clears from the display.

The Retouch Menu

The **Color sketch** (\square 67), **Miniature effect** (\square 67), and **Selective color** (\square 67) options in the retouch menu can be used to apply these effects to existing pictures.

Night Vision



Use under conditions of darkness to record monochrome images at high ISO sensitivities (with some noise in the form of randomly-spaced bright pixels, fog, or lines). Autofocus is available in live view only; manual focus can be used if the camera is unable to focus. The built-in flash and AF-assist illuminator turn off; use of a tripod is recommended to reduce blur.

S Color Sketch



The camera detects and colors outlines for a color sketch effect. Movies shot in this mode play back like a slide show made up of a series of stills. The effect can be chosen during live view (\square 61); note that the display refresh rate drops when live view is in effect and that the frame rate drops in continuous release modes. Autofocus is not available during movie recording.

Miniature Effect



Distant subjects appear as miniatures. Miniature effect movies play back at high speed, compressing 30 to 45 minutes of footage shot at 1920 × 1080/30p into a movie that plays back in about three minutes. The effect can be chosen during live view (\$\subseteq\$ 62); note that the display refresh rate drops when live view is in effect and that the frame rate drops in continuous release modes. Sound is not recorded with movies; autofocus is not available during movie recording. The built-in flash and AF-assist illuminator turn off; use of a tripod is recommended when lighting is poor.

Selective Color



All colors other than the selected colors are recorded in black and white. The effect can be chosen during live view (\$\square\$ 63). The built-in flash turns off; use of a tripod is recommended when lighting is poor.

🛋 Silhouette



Silhouette subjects against bright backgrounds. The built-in flash turns off; use of a tripod is recommended when lighting is poor.

High Key



Use with bright scenes to create bright images that seem filled with light. The built-in flash turns off.

Low Key



Use with dark scenes to create dark, somber images with prominent highlights. The built-in flash turns off; use of a tripod is recommended when lighting is poor.




Options Available in Live View

■ S Color Sketch

1 Select live view.

Rotate the live view switch to raise the mirror and display the view through the lens in the monitor.



Live view switch

2 Adjust options.

Press m to display the options shown at right (note that the options temporarily clear from the display during autofocus). Press \blacktriangle or \blacktriangledown to highlight **Vividness** or **Outlines** and press \blacktriangleleft or






▶ to change. Vividness can be increased to make colors more saturated, or decreased for a washed-out, monochromatic effect, while outlines can be made thicker or thinner. Increasing the thickness of the lines also makes colors more saturated. Press ⊛ to exit when settings are complete. To exit live view, rotate the live view switch. The selected settings will continue in effect and will apply to photographs taken using the viewfinder.

1 Select live view.

Rotate the live view switch to raise the mirror and display the view through the lens in the monitor.



Live view switch

2 Position the focus point.

Use the multi selector to position the focus point in the area that will be in focus and then press the shutter-release button halfway to focus (note that the options temporarily clear from the display during autofocus). To temporarily clear





miniature effect options from the display and enlarge the view in the monitor for precise focus, press \P . Press \P to restore the miniature effect display.

3 Display options.

Press ® to display miniature effect options.





4 Adjust options.

Press ◀ or ▶ to choose the orientation of the area that will be in focus and press ▲ or ▼ to adjust its width






5 Return to the live view display.

Press ® to return to live view. To exit live view, rotate the live view switch. The selected settings will continue in effect and will apply to photographs taken using the viewfinder.



1 Select live view.

Rotate the live view switch to raise the mirror and display the view through the lens in the monitor.



Live view switch

2 Display options.

Press ® to display selective color options.





3 Select a color.

Frame an object in the white square in the center of the display and press \blacktriangle to choose the color of the object as one that will remain in the final image (the camera may have difficulty detecting unsaturated colors; choose a saturated color). To zoom in on the center of the display for more precise color selection, press \P . Press \P to zoom out.





4 Choose the color range.

Press ▲ or ▼ to increase or decrease the range of similar hues that will be included in the final image. Choose from values between 1 and 7; note that higher values may include hues from other colors.







5 Select additional colors.

To select additional colors, rotate the command dial to highlight another of the three color boxes at the top of the display and repeat Steps 3 and 4 to select another color. Repeat for a third color if desired. To deselect the highlighted color, press





 $\tilde{\mathbf{m}}$ (To remove all colors, press and hold $\tilde{\mathbf{m}}$. A confirmation dialog will be displayed; select **Yes**).


••.

6 Return to the live view display.

Press ® to return to live view. During shooting, only objects of the selected hues will be recorded in color; all others will be recorded in black-and-white. To exit live view, rotate the live view switch. The selected settings will continue in effect and will apply to photographs taken using the viewfinder.

Camera Menus

Most shooting, playback, and setup options can be accessed from the camera menus. To view the menus, press the MENU button.




Tabs

Choose from the following menus:

- ▶: Playback
- Shooting
- Custom Settings
- Y: Setup

- 🕩: Retouch
- **1**/**2**: **Recent settings** or **My Menu** (defaults to **Recent settings**)



Slider shows position in current menu.

Current settings are shown by icons.

Menu options ___

Options in current menu.



If a ② icon appears at the bottom left corner of the monitor, a description of the currently selected option or menu can be displayed by pressing the $^{\triangleleft}$ E (?) button. Press \triangle or ∇ to scroll through the display. Press $^{\triangleleft}$ E (?) again to return to the menus.



Format memory card
Format the memory card.
All images and other data on the card will be deleted.

65



Menu Options

■ Playback Menu: Managing Images

Delete	Image review	DPOF print order
Playback folder	Rotate tall	
Playback display options	Slide show	

■ Shooting Menu: Shooting Options

Reset shooting menu	Manage Picture Control	High ISO NR
Storage folder	Auto distortion control	ISO sensitivity settings
Image quality	Color space	Release mode
Image size	Active D-Lighting	Multiple exposure
White balance	HDR (high dynamic range)	Interval timer shooting
Set Picture Control	Long exposure NR	Movie settings

■ Custom Settings: Fine-Tuning Camera Settings

Reset custom settings	c2 Auto off timers	e Bracketing/flash
a Autofocus	c3 Self-timer	e1 Flash cntrl for built-in flash
a1 AF-C priority selection	c4 Remote on duration(ML-L3)	e2 Auto bracketing set
a2 Number of focus points	d Shooting/display	f Controls
a3 Built-in AF-assist illuminator	d1 Beep	f1 Assign Fn button
a4 Rangefinder	d2 Viewfinder grid display	f2 Assign AE-L/AF-L button
b Exposure	d3 ISO display	f3 Reverse dial rotation
b1 EV steps for exposure cntrl	d4 File number sequence	f4 Slot empty release lock
c Timers/AE lock	d5 Exposure delay mode	f5 Reverse indicators
c1 Shutter-release button AE-L	d6 Print date	_



■ Y Setup Menu: Camera Setup

Format memory card	Video mode	Accessory terminal
Monitor brightness	HDMI	Eye-Fi upload *
Info display format	Flicker reduction	Wireless mobile adapter
Auto info display	Time zone and date	Firmware version
Clean image sensor	Language	
Lock mirror up for cleaning	Image comment	
Image Dust Off ref photo	Auto image rotation	

^{*} Only available when compatible Eye-Fi memory card is inserted.

■■ G Retouch Menu: Creating Retouched Copies

D-Lighting	NEF (RAW) processing	Color sketch		
Red-eye correction	Resize	Perspective control		
Trim	Quick retouch	Miniature effect		
Monochrome	Straighten	Selective color		
Filter effects	Distortion control	Edit movie		
Color balance	Fisheye			
lmage overlay	Color outline			


The recent settings menu lists the twenty most recently used settings.

For More Information

Information on individual menu options is available using the camera's on-board help (\square 65).


Using Camera Menus

The multi selector and ® button are used to navigate the camera menus.



Follow the steps below to navigate the menus.

1 Display the menus.
Press the MENU button to display the menus.



2 Highlight the icon for the current menu.

Press ◀ to highlight the icon for the current menu.





3 Select a menu.

Press ▲ or ▼ to select the desired menu.









Press to position the cursor in the selected menu.





5 Highlight a menu item.

Press ▲ or ▼ to highlight a menu item.





6 Display options.

Press ▶ to display options for the selected menu item.





7 Highlight an option.

Press ▲ or ▼ to highlight an option.





8 Select the highlighted item.

Press ® to select the highlighted item. To exit without making a selection, press the MENU button.





Note the following:

- Menu items that are displayed in gray are not currently available.
- While pressing ▶ generally has the same effect as pressing ®, there are some cases in which selection can only be made by pressing ®.
- To exit the menus and return to shooting mode, press the shutter-release button halfway (III 18).




ViewNX 2

Installing ViewNX 2

Install the supplied software to display and edit photographs and movies that have been copied to your computer. Before installing ViewNX 2, confirm that your computer meets the system requirements on page 71. The latest version of ViewNX 2 is available for download from the websites listed on page viii.




1 Start the computer and insert the installer CD.



2 Select a language.

If the desired language is not available, click **Region Selection** to choose a different region and then choose the desired language (region selection is not available in the European release).



3 Start the installer.

Click Install and follow the on-screen instructions.

Installation Guide

For help installing ViewNX 2, click **Installation Guide** in Step 3.



Click Install



4 Exit the installer.



The following software is installed:

ViewNX 2

- Apple QuickTime (Windows only)
- ${\bf 5} \ \ {\bf Remove\ the\ installer\ CD\ from\ the\ CD-ROM\ drive}.$

	Windows	Mac OS		
	Photos/JPEG movies: Intel Celeron, Pentium 4, or	Photos/JPEG movies: Intel Core or Xeon		
	Core series, 1.6 GHz or better	series		
	• H.264 movies (playback): 3.0 GHz or better	• H.264 movies (playback): Core Duo 2 GHz o		
	Pentium D; Intel Core i5 or better	better; Intel Core i5 or better		
CPU	recommended when viewing movies with a	recommended when viewing movies		
CPU	frame size of 1280×720 or more at a frame rate	with a frame size of 1280×720 or more a		
	of 30 fps or above or movies with a frame size	a frame rate of 30 fps or above or movie		
	of 1920×1080 or more	with a frame size of 1920×1080 or more		
	• H.264 movies (editing): 2.6 GHz or better	• H.264 movies (editing): 2.6 GHz or better		
	Core 2 Duo	Core 2 Duo		
	Pre-installed versions of Windows 7 Home Basic/			
	Home Premium/Professional/Enterprise/			
	Ultimate (64- and 32-bit editions; Service Pack 1),			
OS	Windows Vista Home Basic/Home Premium/	Mac OS X version 10.6.8, 10.7.5, or 10.8.2		
	Business/Enterprise/Ultimate (64- and 32-bit editions;			
	Service Pack 2), or Windows XP Home Edition/			
	Professional (32-bit editions only; Service Pack 3).			
	• Windows 7/Windows Vista: 1 GB or more (2 GB or more			
RAM	recommended)	512 MB or more (2 GB or more recommended)		
IVAIVI	Windows XP: 512 MB or more (2 GB or more	312 MB Of Thore (2 db of more recommended)		
	recommended)			
lard-disk	A minimum of 500 MB available on the startup d	isk (1 GR or more recommended)		
space	A minimum of 300 MB available on the startup a	isk (1 db of more recommended)		
	Resolution: 1024×768 pixels (XGA) or more	Resolution: 1024×768 pixels (XGA) or more		
Monitor	(1280×1024 pixels (SXGA) or more recommended)	(1280×1024 pixels (SXGA) or more recommended)		
	Color: 24-bit color (True Color) or more	Color : 24-bit color (millions of colors) or more		


Using ViewNX 2

Copy Pictures to the Computer

1 Choose how pictures will be copied to the computer.

Choose one of the following methods:

• **Direct USB connection**: Turn the camera off and ensure that the memory card is inserted in the camera. Connect the camera to the computer using the supplied UC-E17 USB cable and then turn the camera on.



- **SD** card slot: If your computer is equipped with an SD card slot, the card can be inserted directly in the slot.
- **SD card reader**: Connect a card reader (available separately from third-party suppliers) to the computer and insert the memory card.
- 2 Start Nikon Transfer 2 component of ViewNX 2.

 If a message is displayed prompting you to choose a program, select Nikon Transfer 2.
 - Windows 7

If the following dialog is displayed, select Nikon Transfer 2 as described below.

1 Under Import pictures and videos, click Change program. A program selection dialog will be displayed; select Import File using Nikon Transfer 2 and click OK.



2 Double-click Import File.

3 Click Start Transfer.

At default settings, all the pictures on the memory card will be copied to the computer.



Start Transfer



If the camera is connected to the computer, turn the camera off and disconnect the USB cable. If you are using a card reader or card slot, choose the appropriate option in the computer operating system to eject the removable disk corresponding to the memory card and then remove the card from the card reader or card slot.

View Pictures

Pictures are displayed in ViewNX 2 when transfer is complete.

Starting ViewNX 2 Manually

- Windows: Double-click the ViewNX 2 shortcut on the desktop.
- Mac OS: Click the ViewNX 2 icon in the Dock.



II Retouching Photographs

To crop pictures and perform such tasks as adjusting sharpness and tone levels, click the **Edit** button in the ViewNX 2 toolbar.



II Editing Movies

To perform such tasks as trimming unwanted footage from movies shot with the camera, click the **Movie Editor** button in the ViewNX 2 toolbar.



II Printing Pictures

Click the **Print** button in the ViewNX 2 toolbar. A dialog will be displayed, allowing you to print pictures on a printer connected to the computer.





For More Information

Consult online help for more information on using ViewNX 2.



Technical Notes

Read this chapter for information on compatible accessories, cleaning and storing the camera, and what to do if an error message is displayed or you encounter problems using the camera.

Compatible Lenses

Compatible CPU Lenses

This camera supports autofocus with AF-S and AF-I CPU lenses only. AF-S lenses have names beginning with **AF-S**, AF-I lenses names beginning with **AF-I**. Autofocus is not supported with other autofocus (AF) lenses. The following table lists the features available with compatible lenses in viewfinder photography:

Camera setting		Focus			Mode		Meterin	ıg
		MF (with electronic					0	0
Lens/accessory	AF	rangefinder)	MF	M	Other modes	3D	Color	⊡
AF-S, AF-I NIKKOR ¹	~	V	~	~	~	~		1 2
Other type G or D AF NIKKOR ¹	—	V	~	~	'	~	-	✓ 2
PC-E NIKKOR series	_	✓ 3	~	✓ 3	✓ 3	✓ 3	_	✓ 2,3
PC Micro 85mm f/2.8D ⁴	_	✓ 3	~	~	_	~	_	√ 2,3
AF-S/AF-I teleconverter ⁵	✓ 6	✓ 6	~	~	/	~	_	1 2
Other AF NIKKOR (except lenses for F3AF)	_	✓ 7	~	~	'	_	~	✓ 2
AI-P NIKKOR	_	✓8	~	1	~	_	~	1 2

- 1 Use AF-S or AF-I lenses to get the most from your camera. Vibration Reduction (VR) supported with VR lenses.
- 2 Spot metering meters selected focus point.
- 3 Can not be used with shifting or tilting.
- 4 The camera's exposure metering and flash control systems may not function as expected when the lens is shifted and/or tilted or an aperture other than the maximum aperture is used.
- 5 AF-S or AF-I lens required.
- 6 With maximum effective aperture of f/5.6 or faster.
- 7 When AF 80–200mm f/2.8, AF 35–70mm f/2.8, AF 28–85mm f/3.5–4.5 (New), or AF 28–85mm f/3.5–4.5 lenses are zoomed all the way in at the minimum focus distance, the in-focus indicator may be displayed when the image on the matte screen in the viewfinder is not in focus. Focus manually until image in viewfinder is in focus.
- 8 With maximum aperture of f/5.6 or faster.

IX NIKKOR Lenses

IX NIKKOR lenses can not be used.

Lens f-number


The f-number given in lens names is the maximum aperture of the lens.




Identifying CPU and Type G and D Lenses

CPU lenses can be identified by the presence of CPU contacts, type G and D lenses by a letter on the lens barrel. Type G lenses are not equipped with a lens aperture ring.





5.6 G



CPU lens

Type G lens

Type D lens

Other Accessories

At the time of writing, the following accessories were available for the D5200.

	• Rechargeable Li-ion Battery EN-EL14 (CC) 7): Additional EN-EL14 batteries are
	available from local retailers and Nikon-authorized service representatives.
	EN-EL14a batteries can also be used.
Power	• Battery Charger MH-24 (\$\sup\$ 7): Recharge EN-EL14a and EN-EL14 batteries.
sources	Power Connector EP-5A, AC Adapter EH-5b: These accessories can be used to power
Jources	the camera for extended periods (EH-5a and EH-5 AC adapters can also be
	used). A power connector EP-5A is required to connect the camera to the
	EH-5b, EH-5a, or EH-5.
	Filters intended for special-effects photography may interfere with autofocus
	or the electronic rangefinder.
	• The D5200 can not be used with linear polarizing filters. Use C-PL or C-PL II
	circular polarizing filters instead.
	NC filters are recommended for protecting the lens.
Filters	To prevent ghosting, use of a filter is not recommended when the subject is
	framed against a bright light, or when a bright light source is in the frame.
	 Center-weighted metering is recommended with filters with exposure factors
	(filter factors) over 1 × (Y44, Y48, Y52, O56, R60, X0, X1, C-PL, ND2S, ND4, ND4S,
	ND8, ND8S, ND400, A2, A12, B2, B8, B12). See the filter manual for details.
	• DK-20C Eyepiece Correction Lenses : Lenses are available with diopters of –5, –4, –3,
	-2, 0, $+0.5$, $+1$, $+2$, and $+3$ m ^{-1} when the camera diopter adjustment control is
	in the neutral position (-1 m^{-1}). Use eyepiece correction lenses only if the
	desired focus can not be achieved with the built in diopter adjustment control
	$(-1.7 \text{ to } +0.7 \text{ m}^{-1})$. Test eyepiece correction lenses before purchase to ensure
	that the desired focus can be achieved. The rubber eyecup can not be used
Viewfinder	with eyepiece correction lenses.
eyepiece	Magnifier DG-2: The DG-2 magnifies the scene displayed in the center of the
accessories	viewfinder for greater precision during focusing. Eyepiece adapter required
accessories	
	(available separately).
	• Eyepiece Adapter DK-22: The DK-22 is used when attaching the DG-2 magnifier.
	Right-Angle Viewing Attachment DR-6: The DR-6 attaches at a right angle to the
	viewfinder eyepiece, allowing the image in the viewfinder to be viewed at
	right angles to the lens (for example, from directly above when the camera is
	horizontal).
	• Capture NX 2: A complete photo editing package offering such features as white
	balance adjustment and color control points.
	Camera Control Pro 2: Control the camera remotely from a computer to record
	movies and photographs and save photographs directly to the computer hard
	disk.
Software	uisn.
	Note : Use the latest versions of Nikon software. Most Nikon software offers an
	auto update feature when the computer is connected to the Internet. See the
	websites listed on page viii for the latest information on supported operating
	systems.
	Body Cap BF-1B/Body Cap BF-1A: The body cap keeps the mirror, viewfinder screen,
Body cap	
	and low-pass filter free of dust when a lens is not in place.

• Wireless Remote Control ML-L3 (□ 28): The ML-L3 uses a 3 V CR2025 battery.



Remote controls/ wireless remote controllers


Pressing the battery-chamber latch to the right (1), insert a fingernal into the gap and open the battery chamber (2). Ensure that the battery is inserted in the correct orientation (4).

Wireless Remote Controller WR-R10*/WR-T10: When a WR-R10 wireless remote
controller is attached, the camera can be controlled wirelessly using a WR-T10
wireless remote controller (□ 29).

Microphones Stereo Microphone ME-1 (□ 56) *

Accessory terminal accessories

The D5200 is equipped with an accessory terminal for WR-R10 wireless remote controllers, MC-DC2 remote cords and GP-1 GPS units, which connect with the ◀ mark on the connector aligned with the ▶ next to the accessory terminal (close the connector cover when the terminal is not in use).



USB and A/V connector accessories

- **USB** and A/V UC-E17 and UC-E6 USB cables (\square 72)
 - Wireless Mobile Adapter WU-1a*: Supports two-way communication between the camera and smart devices running the Wireless Mobile Adapter Utility.
- * The WR-R10 wireless remote controller can not be attached at the same time as a WU-1a wireless mobile adapter or ME-1 stereo microphone. Attempting to forcibly attach accessories can damage the camera or accessory.

Approved Memory Cards

The following SD memory cards have been tested and approved for use in the D5200. Cards with class 6 or faster write speeds are recommended for movie recording. Recording may end unexpectedly when cards with slower write speeds are used.

	SD memory cards	SDHC memory cards ²	SDXC memory cards ³		
SanDisl	k	4 GB, 8 GB, 16 GB, 32 GB	64 GB		
Toshiba	1	4 db, 6 db, 10 db, 32 db	04 GB		
Panason	2 GB ¹	4 GB, 6 GB, 8 GB, 12 GB, 16 GB, 24 GB, 32 GB	48 GB, 64 GB		
Lexar Med	dia				
Platinum I	II	4 GB, 8 GB, 16 GB, 32 GB	_		
Profession	al		64 GB, 128 GB		
Full-HD Vio	deo —	4 GB, 8 GB, 16 GB	_		

- 1 Check that any card readers or other devices with which the card will be used support 2 GB cards.
- 2 Check that any card readers or other devices with which the card will be used are SDHC-compliant. The camera supports UHS-1.
- 3 Check that any card readers or other devices with which the card will be used are SDXC-compliant. The camera supports UHS-1.



Other cards have not been tested. For more details on the above cards, please contact the manufacturer.

Caring for the Camera

Storage

When the camera will not be used for an extended period, remove the battery and store it in a cool, dry area with the terminal cover in place. To prevent mold or mildew, store the camera in a dry, well-ventilated area. Do not store your camera with naphtha or camphor moth balls or in locations that:

- are poorly ventilated or subject to humidities of over 60%
- are next to equipment that produces strong electromagnetic fields, such as televisions or radios
- are exposed to temperatures above 50 °C (122 °F) or below -10 °C (14 °F)

Cleaning

Camera body	Use a blower to remove dust and lint, then wipe gently with a soft, dry cloth. After using the camera at the beach or seaside, wipe off sand or salt with a cloth lightly dampened in distilled water and dry thoroughly. Important : Dust or other foreign matter inside the camera may cause damage not covered under warranty.
Lens, mirror, and viewfinder	These glass elements are easily damaged. Remove dust and lint with a blower. If using an aerosol blower, keep the can vertical to prevent the discharge of liquid. To remove fingerprints and other stains, apply a small amount of lens cleaner to a soft cloth and clean with care.
Monitor	Remove dust and lint with a blower. When removing fingerprints and other stains, wipe the surface lightly with a soft cloth or chamois leather. Do not apply pressure, as this could result in damage or malfunction.

Do not use alcohol, thinner, or other volatile chemicals.



Servicing the Camera and Accessories

The camera is a precision device and requires regular servicing. Nikon recommends that the camera be inspected by the original retailer or Nikon-authorized service representative once every one to two years, and that it be serviced once every three to five years (note that fees apply to these services). Frequent inspection and servicing are particularly recommended if the camera is used professionally. Any accessories regularly used with the camera, such as lenses or optional flash units, should be included when the camera is inspected or serviced.

Caring for the Camera and Battery: Cautions

Caring for the Camera

Do not drop: The product may malfunction if subjected to strong shocks or vibration.

Keep dry: This product is not waterproof, and may malfunction if immersed in water or exposed to high levels of humidity. Rusting of the internal mechanism can cause irreparable damage.

Avoid sudden changes in temperature: Sudden changes in temperature, such as those that occur when entering or leaving a heated building on a cold day, can cause condensation inside the device. To prevent condensation, place the device in a carrying case or plastic bag before exposing it to sudden changes in temperature.

Keep away from strong magnetic fields: Do not use or store this device in the vicinity of equipment that generates strong electromagnetic radiation or magnetic fields. Strong static charges or the magnetic fields produced by equipment such as radio transmitters could interfere with the monitor, damage data stored on the memory card, or affect the product's internal circuitry.

Do not leave the lens pointed at the sun: Do not leave the lens pointed at the sun or other strong light source for an extended period. Intense light may cause the image sensor to deteriorate or produce a white blur effect in photographs.

Turn the product off before removing or disconnecting the power source: Do not unplug the product or remove the battery while the product is on or while images are being recorded or deleted. Forcibly cutting power in these circumstances could result in loss of data or in damage to product memory or internal circuitry. To prevent an accidental interruption of power, avoid carrying the product from one location to another while the AC adapter is connected.

Cleaning: When cleaning the camera body, use a blower to gently remove dust and lint, then wipe gently with a soft, dry cloth. After using the camera at the beach or seaside, wipe off any sand or salt using a cloth lightly dampened in pure water and then dry the camera thoroughly.

The lens and mirror are easily damaged. Dust and lint should be gently removed with a blower. When using an aerosol blower, keep the can vertical to prevent discharge of liquid. To remove fingerprints and other stains from the lens, apply a small amount of lens cleaner to a soft cloth and wipe the lens carefully.

See the Reference Manual for information on cleaning the low-pass filter.

Do not touch the shutter curtain: The shutter curtain is extremely thin and easily damaged. Under no circumstances should you exert pressure on the curtain, poke it with cleaning tools, or subject it to powerful air currents from a blower. These actions could scratch, deform, or tear the curtain.

Ø

Storage: To prevent mold or mildew, store the camera in a dry, well-ventilated area. If you are using an AC adapter, unplug the adapter to prevent fire. If the product will not be used for an extended period, remove the battery to prevent leakage and store the camera in a plastic bag containing a desiccant. Do not, however, store the camera case in a plastic bag, as this may cause the material to deteriorate. Note that desiccant gradually loses its capacity to absorb moisture and should be replaced at regular intervals.

To prevent mold or mildew, take the camera out of storage at least once a month. Turn the camera on and release the shutter a few times before putting it away.

Store the battery in a cool, dry place. Replace the terminal cover before putting the battery away.

Notes on the monitor: The monitor is constructed with extremely high precision; at least 99.99% of pixels are effective, with no more than 0.01% being missing or defective. Hence while these displays may contain pixels that are always lit (white, red, blue, or green) or always off (black), this is not a malfunction and has no effect on images recorded with the device.

Images in the monitor may be difficult to see in a bright light.

Do not apply pressure to the monitor, as this could cause damage or malfunction. Dust or lint on the monitor can be removed with a blower. Stains can be removed by wiping lightly with a soft cloth or chamois leather. Should the monitor break, care should be taken to avoid injury from broken glass and to prevent liquid crystal from the monitor touching the skin or entering the eyes and mouth.

Moiré: Moiré is an interference pattern created by the interaction of an image containing a regular, repeating grid, such as the pattern of weave in cloth or windows in a building, with the camera image sensor grid. If you notice moiré in your photographs, try changing the distance to the subject, zooming in and out, or changing the angle between the subject and the camera.

Caring for the Battery

Batteries may leak or explode if improperly handled. Observe the following precautions when handling batteries:

- Use only batteries approved for use in this equipment.
- Do not expose the battery to flame or excessive heat.
- Keep the battery terminals clean.
- Turn the product off before replacing the battery.
- Remove the battery from the camera or charger when not in use and replace the terminal cover. These devices draw minute amounts of charge even when off and could draw the battery down to the point that it will no longer function. If the battery will not be used for some time, insert it in the camera and run it flat before removing it and storing it in a location with an ambient temperature of 15 °C to 25 °C (59 °F to 77 °F; avoid hot or extremely cold locations). Repeat this process at least once every six months.
- Turning the camera on and off repeatedly when the battery is fully discharged will shorten battery life. Batteries that have been fully discharged must be charged before use.



- The internal temperature of the battery may rise while the battery is in use. Attempting to charge the battery while the internal temperature is elevated will impair battery performance, and the battery may not charge or charge only partially. Wait for the battery to cool before charging.
- Continuing to charge the battery after it is fully charged can impair battery performance.
- A marked drop in the time a fully charged battery retains its charge when used at room temperature indicates that it requires replacement. Purchase a new EN-EL14 battery.
- Charge the battery before use. When taking photographs on important occasions, ready a spare EN-EL14 battery and keep it fully charged. Depending on your location, it may be difficult to purchase replacement batteries on short notice. Note that on cold days, the capacity of batteries tends to decrease. Be sure the battery is fully charged before taking photographs outside in cold weather. Keep a spare battery in a warm place and exchange the two as necessary. Once warmed, a cold battery may recover some of its charge.
- Used batteries are a valuable resource; recycle in accord with local regulations.

M

Error Messages

This section lists the indicators and error messages that appear in the viewfinder and monitor.

Warning Icons

A flashing ② in the monitor or ? in the viewfinder indicates that a warning or error message can be displayed in the monitor by pressing the ? button.

Indicator				
Monitor	Viewfinder	Solution		
Lock lens aperture ring at minimum aperture (largest f/-number).	FE E (flashes)	Set lens aperture ring to minimum aperture (highest f-number).		
Lens not attached	F/? (flashes)	Attach non-IX NIKKOR lens.If non-CPU lens is attached, select mode M.		
Before taking photos, rotate the zoom ring to extend the lens.	F (flashes)	A lens with a retractable lens barrel button is attached with the lens barrel retracted. Press the retractable lens barrel button and rotate the zoom ring to extend the lens		
Shutter release disabled. Recharge battery.	← /? (flashes)	Turn camera off and recharge or replace battery.		
This battery cannot be used. Choose battery designated for use in this camera.	(flashes)	Use Nikon-approved battery.		
Initialization error. Turn camera off and then on again.	(flashes)	Turn camera off, remove and replace battery, and then turn camera on again.		
Battery level is low. Complete operation and turn camera off immediately.	_	End cleaning and turn camera off and recharge or replace battery.		
Clock not set	_	Set camera clock.		
No SD card inserted	(- E -)/? (flashes)	Turn camera off and confirm that card is correctly inserted.		
Memory card is locked. Slide lock to "write" position.	្រែវ (flashes)	Memory card is locked (write protected). Slide card write-protect switch to "write" position.		
This memory card cannot be used. Card may be damaged. Insert another card.	[d/(Err) (flashes)	 Use approved card. Format card. If problem persists, card may be damaged. Contact Nikon-authorized service representative. Error creating new folder. Delete files or insert new memory card. Insert new memory card. 		
This card is not formatted. Format the card.	(Far) (flashes)	Format card or turn camera off and insert new memory card.		
Card is full	Ful/0/? (flashes)	Reduce quality or size.Delete photographs.Insert new memory card.		



Indicator				
Monitor Viewfinder		Solution		
_	•	Camera can not focus using autofocus. Change		
	(flashes)	composition or focus manually.		
		Use a lower ISO sensitivity.		
		Use commercial ND filter.		
Subject is too bright		• In mode:		
		S Increase shutter speed		
	?	A Choose a smaller aperture (higher f-number)		
	(flashes)	☑ Choose another shooting mode		
	(,	Use a higher ISO sensitivity.		
		• Use flash.		
Subject is too dark		• In mode:		
		S Lower shutter speed		
		A Choose a larger aperture (lower f-number)		
No Bulb in S mode	อนไอ (flashes)	Change shutter speed or select mode M.		
Interval timer shooting		Menus and playback are not available while interval		
interval timer shooting		timer photography is in progress. Turn camera off.		
	4	Flash has fired at full power. Check photo in monitor; if		
_	(flashes)	underexposed, adjust settings and try again.		
_	\$/? (flashes)	 Use the flash. Change distance to subject, aperture, flash range, or ISO sensitivity. Lens focal length is less than 18 mm: use a longer focal length. Optional SB-400 flash unit attached: flash is in bounce position or focus distance is very short. Continue shooting; if necessary, increase focus distance to prevent shadows from appearing in photograph. 		
Error. Press shutter release		Release shutter. If error persists or appears frequently,		
button again.		consult Nikon-authorized service representative.		
Start-up error. Contact a	Err			
Nikon-authorized service	(flashes)			
representative.	`,	Consult Nikon-authorized service representative.		
Metering error				
Unable to start live view.		With the second second		
Please wait for camera to —		Wait for the internal circuits to cool before resuming live		
cool.		view or movie recording.		
Folder contains no images.	_	Folder selected for playback contains no images. Insert another memory card or select a different folder.		
Cannot display this file.	_	File can not be played back on camera.		
Cannot select this file.	_	Images created with other devices can not be retouched.		

Specifications

■■ Nikon D5200 Digital Camera

Туре	
Туре	Single-lens reflex digital camera
Lens mount	Nikon F mount (with AF contacts)
Effective angle of view	Nikon DX format; focal length equivalent to approx. 1.5× that of lenses
	with FX format angle of view
Effective pixels	
Effective pixels	24.1 million
Image sensor	
Image sensor	$23.5 \times 15.6 \text{ mm CMOS sensor}$
Total pixels	24.71 million
Dust-reduction System	Image sensor cleaning, Image Dust Off reference data (optional
	Capture NX 2 software required)
Storage	
Image size (pixels)	• 6000 × 4000 (Large) • 4496 × 3000 (Medium)
	• 2992 × 2000 (Small)
File format	NEF (RAW): 14 bit, compressed
	• JPEG : JPEG-Baseline compliant with fine (approx. 1 : 4), normal (approx.
	1:8), or basic (approx. 1:16) compression
	NEF (RAW)+JPEG: Single photograph recorded in both NEF (RAW) and
	JPEG formats
Picture Control System	Standard, Neutral, Vivid, Monochrome, Portrait, Landscape; selected
	Picture Control can be modified; storage for custom Picture Controls
Media	SD (Secure Digital) and UHS-I compliant SDHC and SDXC memory cards
File system	DCF (Design Rule for Camera File System) 2.0, DPOF (Digital Print Order
	Format), Exif (Exchangeable Image File Format for Digital Still Cameras)
	2.3, PictBridge
Viewfinder	
Viewfinder	Eye-level pentamirror single-lens reflex viewfinder
Frame coverage	Approx. 95% horizontal and 95% vertical
Magnification	Approx. $0.78 \times (50 \text{ mm f/}1.4 \text{ lens at infinity, } -1.0 \text{ m}^{-1})$
Eyepoint	17.9 mm (–1.0 m ⁻¹ ; from center surface of viewfinder eyepiece lens)
Diopter adjustment	-1.7-+0.7 m ⁻¹
Focusing screen	Type B BriteView Clear Matte Mark VII screen
Reflex mirror	Quick return
Lens aperture	Instant return, electronically controlled

A

Lens				
Compatible lenses	Autofocus is available with AF-S and AF-I lenses. Autofocus is not			
Companion renses	available with other type G and D lenses, AF lenses (IX NIKKOR and lenses			
	for the F3AF are not supported), and Al-P lenses. Non-CPU lenses can be			
	used in mode M, but the camera exposure meter will not function.			
	The electronic rangefinder can be used with lenses that have a			
	maximum aperture of f/5.6 or faster.			
Shutter				
Туре	Electronically-controlled vertical-travel focal-plane shutter			
Speed	1 /4000 – 30 s in steps of 1 /3 or 1 /2 EV; Bulb; Time (requires optional ML-L3 remote control)			
Flash sync speed	X=1/200 s; synchronizes with shutter at $1/200$ s or slower			
Release				
Release mode	S (single frame), □L (continuous L), □H (continuous H), ७ (self-timer),			
	🕯 2s (delayed remote; ML-L3), 🕯 (quick-response remote; ML-L3), 🔟 (quiet			
	shutter release); interval timer photography supported			
Frame advance rate	Up to 3 fps (밀L) or 5 fps (밀H) (continuous-servo AF with Release			
	selected for Custom Settings a1 [AF-C priority selection], manual or			
	shutter-priority auto exposure, a shutter speed of 1/250 s or faster, and			
	the remaining settings at default value)			
Self-timer	2 s, 5 s, 10 s, 20 s; 1–9 exposures			
Exposure				
Metering mode	TTL exposure metering using 2016-pixel RGB sensor			
Metering method	Matrix metering: 3D color matrix metering II (type G and D lenses); color			
	matrix metering II (other CPU lenses)			
	 Center-weighted metering: Weight of 75% given to 8-mm circle in center of frame 			
	 Spot metering: Meters 3.5-mm circle (about 2.5% of frame) centered on selected focus point 			
Range (ISO 100, f/1.4	Matrix or center-weighted metering: 0 – 20 EV			
lens, 20 °C/68 °F)	• Spot metering: 2–20 EV			
Exposure meter	CPU			
coupling	A			
Mode	Auto modes (auto; auto, flash off); programmed auto with flexible			
	program (P); shutter-priority auto (S); aperture-priority auto (A); manual (M); scene modes (≰ portrait; a landscape; ≰ child; ₹ sports; tolose up; ☐ night			
	portrait; 圖 night landscape; 溪 party/indoor; 鷸 beach/snow; 當 sunset; 當 dusk/dawn; 岑 pet			
	portrait; 2 candlelight; 4 blossom; 4 autumn colors; 1 food); special effects modes			
	(☑ night vision; ☜ color sketch; ☜ miniature effect; ⋈ selective color; ≦ silhouette; high			
	key; © low key)			
Exposure compensation	Can be adjusted by $-5 - +5$ EV in increments of $^{1}/_{3}$ or $^{1}/_{2}$ EV in P , S , A , and			
' '	M modes			
Bracketing	• Exposure bracketing: 3 shots in steps of 1/3 or 1/2 EV			
	White balance bracketing: 3 shots in steps of 1			
	Active D-Lighting bracketing: 2 shots			
Exposure lock	Luminosity locked at detected value with AFL (O-n) button			

Auto, incandescent, fluorescent (7 types), direct sunlight, flash, cloudy, shade, preset manual, all except preset manual with fine-tuning.



White balance

Live view			
Lens servo	Autofocus (AF): Single-servo AF (AF-S); full-time-servo AF (AF-F)		
	Manual focus (MF)		
AF-area mode	Face-priority AF, wide-area AF, normal-area AF, subject-tracking AF		
Autofocus	Contrast-detect AF anywhere in frame (camera selects focus point		
	automatically when face-priority AF or subject-tracking AF is selected)		
Automatic scene	Available in 🚾 and ③ modes		
selection			
Movie			
Metering	TTL exposure metering using main image sensor		
Metering method	Matrix		
Frame size (pixels) and	• 1920 × 1080, 60i (59.94 fields/s)/ 50i (50 fields/s)*, ★ high/normal		
frame rate	• 1920 × 1080, 30 p (progressive)/25p/24p, ★ high/normal		
	• 1280 × 720, 60p/50p, ★ high/normal		
	• 640 × 424, 30p/25p, ★ high/normal		
	Frame rates of 30p (actual frame rate 29.97 fps), 60i, and 60p (actual		
	frame rate 59.94 fps) are available when NTSC is selected for video		
	mode. 25p, 50i, and 50p are available when PAL is selected for video		
	mode. Actual frame rate when 24p is selected is 23.976 fps.		
File format	MOV		
Video compression	H.264/MPEG-4 Advanced Video Coding		
Audio recording format	Linear PCM		
Audio recording device	Built-in or external stereo microphone; sensitivity adjustable		
ISO sensitivity	ISO 100–6400; can also be set to approx. 0.3, 0.7, 1, or 2 EV (ISO 25600		
	equivalent) above ISO 6400		
* Canada a	L + CO TO f		

*	Sensor	output	is a	bout	60	or	50	fps.
---	--------	--------	------	------	----	----	----	------

Monitor

Monitor	7.5-cm (3-in.), approx. 921k-dot (VGA), vari-angle TFT monitor with 170° viewing angle, approx. 100% frame coverage, and brightness adjustment
Playback	
Playback	Full-frame and thumbnail (4, 9, or 72 images or calendar) playback with playback zoom, movie playback, photo and/or movie slide shows, histogram display, highlights, auto image rotation, and image comment (up to 36 characters)
Interface	
USB	Hi-Speed USB
Video output	NTSC, PAL
HDMI output	Type C mini-pin HDMI connector
Accessory terminal	Wireless remote controller: WR-R10 wireless remote controller (available separately) Remote cord: MC-DC2 (available separately) GPS unit: GP-1 (available separately)
Audio input	Stereo mini-pin jack (3.5mm diameter)

Supported languages			
Supported languages	languages Arabic, Chinese (Simplified and Traditional), Czech, Danish, Dutch, English, Finnish, French, German, Greek, Hindi, Hungarian, Indonesian, Italian, Japanese, Korean, Norwegian, Polish, Portuguese (Portugal and Brazil), Romanian, Russian, Spanish, Swedish, Thai, Turkish, Ukrainian		
Power source			
Battery	One rechargeable Li-ion EN-EL14 battery		
AC adapter	EH-5b AC adapter; requires EP-5A power connector (available separately)		
Tripod socket			
Tripod socket	¹ / ₄ in. (ISO 1222)		
Dimensions/weight			
Dimensions (W \times H \times D)	Approx. 129.0 × 98.0 × 78.0 mm (5.1 × 3.9 × 3.1 in.)		
Weight	Approx. 555 g (1 lb 3.6 oz) with battery and memory card but without body cap; approx. 505 g/1 lb 1.8 oz (camera body only)		
Operating environment			
Temperature	0 °C-40 °C (+32 °F-104 °F)		
Humidity	85% or less (no condensation)		
 Unless otherwise state 	ed all figures are for a camera with a fully-charged battery operating at the		

- Unless otherwise stated, all figures are for a camera with a fully-charged battery operating at the temperature specified by the Camera and Imaging Products Association (CIPA): 23 ±3 °C (73.4 ±5.4 °F).
- Nikon reserves the right to change the specifications of the hardware and software described in this
 manual at any time and without prior notice. Nikon will not be held liable for damages that may result
 from any mistakes that this manual may contain.

■■ MH-24 battery charger

	-	
Rated input	AC 100–240 V, 50/60 Hz, 0.2 A maximum	
Rated output	DC 8.4 V/0.9 A	
Supported batteries	Nikon Rechargeable Li-ion Battery EN-EL14	
Charging time	Approx. 1 hour and 30 minutes at an ambient temperature of 25 °C/77 °F	
	when no charge remains	
Operating temperature	0 °C-40 °C (+32 °F-104 °F)	
Dimensions (W \times H \times D)	Approx. $70 \times 26 \times 97$ mm (2.8 × 1.0 × 3.8 in.), excluding plug adapter	
Weight	Approx. 89 g (3.1 oz), excluding plug adapter	

■■ EN-EL14 rechargeable Li-ion battery

Туре	Rechargeable lithium-ion battery	
Rated capacity	7.4 V/1030 mAh	
Operating temperature	0 °C-40 °C (+32 °F-104 °F)	
Dimensions (W \times H \times D)	Approx. $38 \times 53 \times 14 \text{ mm } (1.5 \times 2.1 \times 0.6 \text{ in.})$	
Weight	Approx. 48 g (1.7 oz), excluding terminal cover	


■■ AF-S DX NIKKOR 18-55mm f/3.5-5.6G VR II lens

Туре	Type G AF-S DX lens with built-in CPU and F mount	
Focal length	18–55 mm	
Maximum aperture	f/3.5–5.6	
Lens construction	11 elements in 8 groups (including 1 aspherical lens element)	
Angle of view	76°-28°50′	
Focal length scale	Graduated in millimeters (18, 24, 35, 45, 55)	
Distance information	Output to camera	
Zoom	Manual zoom using independent zoom ring	
Focusing Autofocus controlled by Silent Wave Motor and separate foc		
	manual focus	
Vibration reduction	Lens shift using voice coil motors (VCMs)	
Minimum focus distance	AF: 0.28 m (0.92 ft) from focal plane at all zoom positions	
	MF: 0.25 m (0.82 ft) from focal plane at all zoom positions	
Diaphragm blades	7 (rounded diaphragm opening)	
Diaphragm	Fully automatic	
Aperture range	• 18 mm focal length: f/3.5–22	
	• 55 mm focal length : f/5.6–36	
	The minimum aperture displayed may vary depending on the size of the	
	exposure increment selected with the camera.	
Metering	Full aperture	
Filter-attachment size	52 mm (P=0.75 mm)	
Dimensions	Approx. 66 mm diameter × 59.5 mm (distance from camera lens-mount flange when	
	lens is retracted)	
Weight	Approx. 195 g (6.9 oz)	

Nikon reserves the right to change the specifications of the hardware and software described in this manual at any time and without prior notice. Nikon will not be held liable for damages that may result from any mistakes that this manual may contain.

The AF-S DX NIKKOR 18–55mm f/3.5–5.6G VR II

The lens generally used in this manual for illustrative purposes is an AF-S DX NIKKOR 18–55mm f/3.5–5.6G VR II.



The AF-S DX NIKKOR 18-55mm f/3.5-5.6G VR II features a retractable lens barrel.

Trademark Information

IOS is a trademark or registered trademark of Cisco Systems, Inc., in the United States and/or other countries and is used under license. Macintosh, Mac OS, and QuickTime are registered trademarks of Apple Inc. in the United States and/or other countries. Microsoft, Windows, and Windows Vista are either registered trademarks, or trademarks of Microsoft Corporation in the United States and/or other countries. PictBridge logo is a trademark. The SD, SDHC, and SDXC logos are trademarks of the SD-3C, LLC. HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

HDMI

All other trade names mentioned in this manual or the other documentation provided with your Nikon product are trademarks or registered trademarks of their respective holders.

FreeType License (FreeType2)

Portions of this software are copyright © 2012 The FreeType Project (http://www.freetype.org). All rights reserved.

MIT License (HarfBuzz)

Portions of this software are copyright © 2012 The HarfBuzz Project (http://www.freedesktop.org/wiki/Software/HarfBuzz). All rights reserved.



The movie footage or number of shots that can be recorded with fully-charged batteries varies with the condition of the battery, temperature, the interval between shots, and the length of time menus are displayed. Sample figures for EN-EL14 (1030 mAh) batteries are given below.

- Photographs, single-frame release mode (CIPA standard 1): Approximately 500 shots
- Photographs, continuous release mode (Nikon standard ²): Approximately 1700 shots
- Movies: Approximately 40 minutes of HD footage at 1080/60i and 1080/50i³
 - 1 Measured at 23 °C/73.4 °F (±3 °C/5.4 °F) with an AF-S DX NIKKOR 18–55mm f/3.5–5.6G VR II lens under the following test conditions: lens cycled from infinity to minimum range and one photograph taken at default settings once every 30 s; after photograph is taken, monitor is turned on for 4 s; tester waits for standby timer to expire after monitor is turned off; flash fired at full power once every other shot. Live view not used.
 - 2 Measured at 20 °C/68 °F with an AF-S DX NIKKOR 18–55mm f/3.5–5.6G VR II lens under the following test conditions: vibration reduction off, continuous high-speed release mode, focus mode set to AF-C, image quality set to JPEG basic, image size set to M (medium), white balance set to AUTO, ISO sensitivity set to ISO 100, shutter speed ¹/250 s, focus cycled from infinity to minimum range three times after shutter-release button has been pressed halfway for 3 s; six shots are then taken in succession and monitor turned on for 4 s and then turned off; cycle repeated once standby timer has expired.
 - 3 Measured at 23°C/73.4°F (±3°C/5.4°F) with the camera at default settings and an AF-S DX NIKKOR 18–55mm f/3.5–5.6G VR II lens under conditions specified by the Camera and Imaging Products Association (CIPA). Individual movies can be up to 20 minutes in length or 4 GB in size; recording may end before these limits are reached if the camera temperature rises.

The following can reduce battery life:

- · Using the monitor
- Keeping the shutter-release button pressed halfway
- Repeated autofocus operations
- Taking NEF (RAW) photographs
- Slow shutter speeds
- Using a GP-1 GPS unit
- Using a WU-1a wireless mobile adapter
- Using VR (vibration reduction) mode with VR lenses

To ensure that you get the most from rechargeable Nikon EN-EL14 batteries:

- Keep the battery contacts clean. Soiled contacts can reduce battery performance.
- Use batteries immediately after charging. Batteries will lose their charge if left unused.



Warranty Terms - Nikon Europe Service Warranty

Dear Nikon Customer,

We thank you for your purchasing this Nikon product. Should your Nikon product require warranty service, please contact the dealer from whom it was purchased or a member of our authorized service network within the sales territory of Nikon Europe BV (Europe/Africa and Russia).

In order to avoid any unnecessary inconvenience, we advise you to read the user manuals carefully before contacting the dealer or our authorized service network.

Your Nikon equipment is guaranteed against any manufacturing defects for one full year from the date of original purchase. If during this period of guarantee the product proves defective due to improper material or workmanship, our authorized service network within the sales territory of Nikon Europe BV will, without charge for labor and parts, repair the product in the terms and conditions set as below. Nikon reserves the right (at its sole discretion) to replace or repair the product.

- 1. This warranty is only provided upon presentation of the completed warranty card and original invoice or purchase receipt indicating the date of purchase, product type and dealer's name, together with the product. Nikon reserves the right to refuse free-of-charge warranty service if the above documents cannot be presented or if the information contained in it is incomplete or illegible.
- 2. This warranty will not cover:
 - necessary maintenance and repair or replacement of parts due to normal wear and tear.
 - modifications to upgrade the product from its normal purpose as described in user manuals, without the prior written consent of Nikon.
 - transport costs and all risks of transport relating directly or indirectly to the warranty of the products.
 - any damage resulting from modifications or adjustments which may be made to the product, without the prior written consent of Nikon, in order to comply with local or national technical standards in force in any other country than the ones for which the product was originally designed and/or manufactured.

- **3.** The warranty will not be applicable in the case of:
 - damage caused by misuse including but not limited to failure to use the
 product for its normal purpose or according to the user instructions on the
 proper use and maintenance, and to installation or use of the product
 inconsistent with the safety standards in force in the country where it is used.
 - damage caused by accidents including but not limited to lightning, water, fire, misuse or neglect.
 - defacing, illegibility or removal of the model or serial number on the product.
 - damage resulting from repairs or adjustments which have been conducted by unauthorized service organizations or persons.
 - defects in any system into which the product is incorporated or with which it is used.
- **4.** This service warranty does not affect the consumer's statutory rights under applicable national laws in force, nor the consumer's right against the dealer arising from their sales/purchase contract.

Notice: An overview of all authorized Nikon Service Stations can be found online by following this Link (URL = http://www.europe-nikon.com/service/).

No reproduction in any form of this manual, in whole or in part (except for brief quotation in critical articles or reviews), may be made without written authorization from NIKON CORPORATION.

Nikon User Support

Visit the site below to register your camera and keep up-to-date with the latest product information. You will find answers to frequently asked questions (FAQs) and can contact us for technical assistance.

http://www.europe-nikon.com/support

AMA15880 Printed in Europe

SB3K01(11)
6MB23511-01