

Nikon

COOLPIX

Updating Firmware for Selected Cameras with Location Data Support

– Mac –

Thank you for choosing a Nikon product. This guide describes how to update the firmware for the following cameras with location data support: the P900, W300, AW130, AW120, S9900, and S9700. *If you are not confident that you can perform the update successfully, the update can be performed by a Nikon service representative.*

See the camera manual for information on camera operations.

Important

The camera may be damaged if power is interrupted or camera controls are operated during the update. Do not turn the camera off, remove or disconnect the power source, or operate camera controls during the update. If the update is not completed successfully and the camera becomes inoperable, take the camera to a Nikon-authorized service representative for inspection.



Get ready


To upgrade the camera firmware, you will need:


- The camera
- A computer equipped with a card reader or card slot
- One of the following camera power sources:
 - An AC adapter
 - A battery or batteries with sufficient charge to complete the update
- A Nikon-approved memory card that has been formatted in the camera (note that all data on the memory card will be deleted when the card is formatted; before formatting the card, back up any data you wish to keep to a computer or other device)
- The camera *User's Manual*

2


Check the current camera firmware version

The menus displayed on your camera may differ from those shown here.

- 1 Turn the camera on.
- 2 Press the  to display the menus.
- 3 Select **Firmware version** in the setup menu.



- 4 The current firmware version will be displayed. Confirm that the firmware version is the correct version for this update.




"XXXX" is the camera name and "**" the firmware version.

- 5 Exit to the setup menu and turn the camera off.

3

Download and extract the new firmware

After reading the end-user license agreement on the download site, select **Accept** and click **Download** to download the file "F-XXXX-V**M.dmg", where "XXXX" is the camera name and "**" the firmware version. When download is complete, click the downloaded file. A disk image will appear on the desktop containing the files and folders listed below:



4


Copy the firmware to the memory card

The firmware can be copied to the camera memory card using a computer equipped with a card reader or card slot.

Important

Do not lock (write protect) the memory card before the update is complete.

- 1 Insert a formatted memory card in the card reader or card slot. If an application such as Nikon Transfer 2 starts automatically, exit the application before proceeding.
- 2 An untitled volume (“NO_NAME”) will appear on the desktop. Copy the “firmware” folder from the disk image to this untitled volume.



When copying is complete, open the “firmware” folder on the untitled volume and confirm that it contains the files “firmware.bin” and “gpsfirm.bin”.

Important

Be sure to copy the “firmware” folder to the root directory of the memory card. The camera will not recognize the new firmware if it is placed in a folder under the root directory.

- 3 Drag the untitled volume into the Trash and remove the memory card from the card reader or card slot.

5


Update the camera firmware


The menus displayed on your camera may differ from those shown here.

During the update, do not:


- Remove the memory card
- Turn the camera off
- Unplug or disconnect the AC adapter
- Remove the battery
- Subject the camera to powerful electromagnetic noise

Any of the above actions could cause the camera to become inoperable.


- 1 Insert the memory card containing the firmware into the camera memory card slot.
- 2 Turn the camera on.
- 3 Press the  to display the menus.
- 4 Select **Firmware version** in the setup menu.




- 5 A firmware update dialog will be displayed. Select **Yes** to begin the update.



The message shown at right will be displayed while the update is in progress.



The message shown at right will be displayed. **Note that the update process is not yet complete.** Proceed to Step 5-6.



6 Turn the camera off and then on again.

If further updates are required, the message shown at right will be displayed (if this message is not displayed, proceed to Step 5-7).

Updating. . .
Do not turn camera off
during update!

The message shown at right will be displayed when the update is complete. Note that the second update will take longer than the first.


Done.
Turn camera off to
complete update.

7 Confirm that the update was completed successfully.

7-1. Turn the camera off and remove the memory card.

7-2. Check the camera firmware version as described in Step 2, "Check the current camera firmware version".

7-3. If the updated version is displayed, the update was successful.



"XXXX" is the camera name and "**" the firmware version.

Important

If the updated firmware version is not displayed, repeat the update process from Step 5-1. If this does not resolve the problem, contact a Nikon-authorized service representative.

8 **Format the memory card in the camera.**

This completes the firmware update.