

割り当てられる機能		Fn1	Fn2	Fn	Fn3	AF-ON	⊗	DISP	OK	▶	⌂	AF-ON	▶	ISO	WB	BKT	WB	L.Fn	L.Fn2	Fn	Fn	M.SET	01
⌂/ISO	[フラッシュモード/調光補正]	✓	✓	✓	—	✓	✓	✓	—	✓	✓	✓	✓	✓	—	✓	✓	—	—	—	—	—	—
⌂/⊗	[リリースモード]	✓	✓	✓	—	✓	✓	✓	—	✓	✓	✓	✓	✓	—	✓	✓	—	—	—	—	—	—
AF/⊗	[フォーカスモード/AFエリアモード]	✓	✓	✓	✓	✓	✓	✓	—	✓	✓	✓	✓	✓	—	✓	✓	—	—	—	—	—	—
BKT	[オートブラケティング]	✓	✓	✓	—	✓	✓	✓	—	✓	✓	✓	✓	✓	—	✓	✓	—	—	—	—	—	—
⌂	[多重露出]	✓	✓	✓	—	✓	✓	✓	—	✓	✓	✓	✓	✓	—	✓	✓	—	—	—	—	—	—
HDR	[HDR合成]	✓	✓	✓	—	✓	✓	✓	—	✓	✓	✓	✓	✓	—	✓	✓	—	—	—	—	—	—
PIXEL	[ピクセルシフト撮影]	✓	✓	✓	—	✓	✓	✓	—	✓	✓	✓	✓	✓	—	✓	✓	—	—	—	—	—	—
⌂	[露出ディレーモード]	✓	✓	✓	—	✓	✓	✓	—	✓	✓	✓	✓	✓	—	✓	✓	—	—	—	—	—	—
LOCK	[操作のロック]	✓	✓	✓	—	✓	✓	✓	—	✓	✓	✓	✓	✓	—	✓	✓	—	—	—	—	—	—
⊗	[シャッター・絞り値1段選択]	✓	✓	✓	—	✓	✓	✓	—	✓	✓	✓	✓	✓	—	✓	✓	—	—	—	—	—	—
Man CPU	[手動設定済みレンズの選択]	✓	✓	✓	—	✓	✓	✓	—	✓	✓	✓	✓	✓	—	✓	✓	—	—	—	—	—	—
M/A	[フォーカス (M/A)]	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
⊗	[絞り]	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	✓
⊗	[絞り (最小絞り側)]	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	✓	—
⊗	[絞り (開放絞り側)]	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	✓	—	—
▶	[露出補正 (+側)]	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	✓	—
▲	[露出補正 (-側)]	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	✓	—
ISO+	[ISO感度 (高感度側)]	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	✓	—
ISO-	[ISO感度 (低感度側)]	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	✓	—
[設定しない]		✓	✓	✓	—	✓	✓	✓	✓	✓	✓	✓	✓	✓	—	✓	✓	✓	✓	✓	✓	✓	✓
コマンドダイヤルに設定できる機能		Fn1	Fn2	Fn	Fn3	AF-ON	⊗	DISP	OK	▶	⌂	AF-ON	▶	ISO	WB	BKT	WB	L.Fn	L.Fn2	Fn	Fn	M.SET	01
[露出設定]		—	—	—	—	—	—	—	—	—	—	—	—	—	—	✓	—	—	—	—	—	—	—
[フォーカスモード/AFエリアモード設定]		—	—	—	—	—	—	—	—	—	—	—	—	—	—	✓	—	—	—	—	—	—	—
[拡大表示中のサブコマンドダイヤル]		—	—	—	—	—	—	—	—	—	—	—	—	—	—	✓	—	—	—	—	—	—	—

再生時

カスタムメニュー f3 [カスタムボタンの機能 (再生)] で設定します。

■機能を割り当てられるボタン



- [Fn1 ボタン]
- [Fn2 ボタン]
- [縦位置 Fn ボタン]
- [DISP ボタン]
- [プロテクト/Fn3 ボタン]
- [再生ボタン]
- [OK ボタン]
- [サブコマンドダイヤル]



- [メインコマンドダイヤル]
- [動画撮影ボタン]
- [ISO 感度ボタン]
- [露出補正ボタン]
- [BKT ボタン]
- [WB ボタン]
- [レンズの Fn ボタン]
- [レンズの Fn2 ボタン]

■各ボタンに割り当てられる機能

割り当てられる機能		Fn1	Fn2	Fn	DISP	Fn3	再生	OK	サブコマンドダイヤル	メインコマンドダイヤル	動画撮影	ISO	露出補正	BKT	WB	L-Fn	L-Fn2
	[プロテクト]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓
	[削除]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓
	[拡大画面との切り換え]	✓	✓	✓	✓	✓	✓	✓	—	—	✓	✓	✓	✓	✓	✓	✓
	[フィルター再生]	✓	✓	✓	✓	✓	✓	✓	—	—	✓	✓	✓	✓	✓	✓	✓
	[フィルター再生 (条件設定)]	✓	✓	✓	✓	✓	✓	✓	—	—	✓	✓	✓	✓	✓	✓	✓
	[グループ内の画像送り]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓
	[音声メモ]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓
	[送信指定 (PC)]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓
	[送信指定 (FTP)]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓
	[1コマとサムネイルの切り換え]	✓	✓	✓	✓	✓	✓	✓	—	—	✓	✓	✓	✓	✓	✓	✓
	[ヒストグラム表示]	✓	✓	✓	✓	✓	✓	✓	—	—	✓	✓	✓	✓	✓	✓	✓
	[スロット/フォルダー指定]	✓	✓	✓	✓	✓	✓	✓	—	—	✓	✓	✓	✓	✓	✓	✓
	[情報表示の切り換え]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓
	[撮影に戻る]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓
	[レーティング]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	—	—
	[設定しない]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓
コマンドダイヤルに設定できる機能		Fn1	Fn2	Fn	DISP	Fn3	再生	OK	サブコマンドダイヤル	メインコマンドダイヤル	動画撮影	ISO	露出補正	BKT	WB	L-Fn	L-Fn2
	[画像送り]	—	—	—	—	—	—	—	✓	✓	—	—	—	—	—	—	—
	[動画再生]	—	—	—	—	—	—	—	✓	✓	—	—	—	—	—	—	—
	[画像送り時の拡大位置]	—	—	—	—	—	—	—	✓	✓	—	—	—	—	—	—	—
	[拡大再生中の顔送り]	—	—	—	—	—	—	—	✓	—	—	—	—	—	—	—	—