


Playback

The roles played by custom controls during playback are chosen using Custom Setting f3 [Custom controls (playback)].


Customizable Controls



- [Fn1 button]
- [Fn2 button]
- [Fn button for vertical shooting]
- [DISP button]
- [Protect/Fn3 button]



- [Playback button]
- [OK button]
- [Sub-command dial]
- [Main command dial]
- [Video record button]
- [ISO sensitivity button]



- [Exposure compensation button]
- [BKT button]
- [WB button]
- [Release mode button]
- [Lens Fn2 button]
- [Lens Fn button]

Available Roles

Role	Fn1	Fn2	Fn	DISP	Fn3	Playback button	OK	Sub-command dial	Main command dial	Video record button	ISO	Exposure compensation button	BKT	WB	Release mode button	L-Fn2	L-Fn
[Protect]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Delete]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Zoom on/off]	✓	✓	✓	✓	✓	✓	✓	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Filtered playback]	✓	✓	✓	✓	✓	✓	✓	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Filtered playback (select criteria)]	✓	✓	✓	✓	✓	✓	✓	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Start series playback]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Voice memo]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Select for upload to computer]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Select for upload (FTP)]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Thumbnail on/off]	✓	✓	✓	✓	✓	✓	✓	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[View histograms]	✓	✓	✓	✓	✓	✓	✓	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Choose slot and folder]	✓	✓	✓	✓	✓	✓	✓	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Cycle info display]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Resume shooting]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Rating]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	—	—
[Jump to the source image]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[RAW processing (current picture)]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[RAW processing (multiple pictures)]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Trim]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Resize (current picture)]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
Role	Fn1	Fn2	Fn	DISP	Fn3	Playback button	OK	Sub-command dial	Main command dial	Video record button	ISO	Exposure compensation button	BKT	WB	Release mode button	L-Fn2	L-Fn
[Resize (multiple pictures)]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[D-Lighting]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Straighten]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Distortion control]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Perspective control]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Monochrome]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Overlay (add)]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Lighten]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Darken]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[Motion blend]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
[None]	✓	✓	✓	✓	✓	✓	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓
Role with command dial	Fn1	Fn2	Fn	DISP	Fn3	Playback button	OK	Sub-command dial	Main command dial	Video record button	ISO	Exposure compensation button	BKT	WB	Release mode button	L-Fn2	L-Fn
[Frame advance]	—	—	—	—	—	—	—	✓	✓	—	—	—	—	—	—	—	—
[Video playback]	—	—	—	—	—	—	—	✓	✓	—	—	—	—	—	—	—	—
[Frame advance zoom position]	—	—	—	—	—	—	—	✓	✓	—	—	—	—	—	—	—	—
[Playback zoom face selection]	—	—	—	—	—	—	—	✓	—	—	—	—	—	—	—	—	—