


En Configuring the WT-4 for Upload to a Computer (Infrastructure Mode)

This document provides basic instructions on configuring the WT-4 wireless transmitter and a Windows XP Professional SP2 computer for transmission over an infrastructure network that includes a wireless LAN access point, or bridge.



Introduction

This section describes a simple network consisting solely of a wireless LAN access point (bridge) connected to an computer via a LAN cable or wireless, with no connections to other networks or devices. Follow the steps below to use the WT-4 in this type of network.

- 1: Get Ready..... pg. 2**
- 2: Assign the Computer an IP Address pg. 3**
- 3: Configure the Wireless LAN Access Point pg. 5**
- 4: Configure the Computer for Wireless Access..... pg. 6**
- 5: Copy the Network Profile to the Camera..... pg. 10**
- 6: Connect to the Computer..... pg. 15**

1: Get Ready

Equipment

Ready the following:

- A WT-4 wireless transmitter
- A fully-charged EN-EL3e battery for the WT-4
- A Nikon D3 or D300 digital SLR camera
- A fully-charged battery for the camera (an EN-EL4a for the D3, a EN-EL3e for the D300)
- A computer with Windows XP Professional SP2, the WT-4 Setup Utility installed
- A wireless LAN access point
- A LAN cable
- A memory card
- A USB cable
- Manuals for the above equipment

Network Settings

Note the IP addresses, encryption, and other settings that will be used in the wireless LAN. The following are intended as examples only.

- IP address for the WT-4: 192.168.1.4
- IP address for the computer: 192.168.1.3
- IP address of the wireless LAN access point: 192.168.1.2
- Subnet mask: 255.255.255.0
- Network name (SSID): WT-4
- Communication mode: Infrastructure
- Authentication: WPA-PSK
- Encryption: TKIP
- Encryption key: abcde123


2: Assign the Computer an IP Address

Choose an address for the computer. The following IP address is intended as an example only.

- **IP address:** 192.168.1.3
- **Subnet mask:** 255.255.255.0


2-1

Click **Start** and select **All Programs** > **Accessories** > **Communications** > **Network Connections**.




2-2

Right-click the network icon (**Wireless Network Connection** if the access point and computer are connected via a wireless network, **Local Area Connection** if the access point is connected by a LAN cable) and select Properties from the menu that appears.




Wireless network connection



Local area connection


2-3

Select **Internet Protocol (TCP/IP)** and click **Properties**.



2-4

Select **Use the following IP address** and enter the IP address and subnet mask for the computer. Click **OK** to exit and then click **OK** to close the properties dialog. This completes the process of assigning an IP address to the computer.



3: Configure the Wireless LAN Access Point

Configure the wireless LAN access point as described below. For more information, see the documentation provided by the manufacturer.

- **Network name (SSID):** Enter the network identifier (network name or SSID), which may be up to 36 characters long. The network in this example uses the identifier WT-4.
- **Wireless mode:** Choose 801.11g or 801.11b.
- **Channel:** Automatic.
- **Wireless security**
 - **Authentication:** Choose from open system, shared key, WPA-PSK, or WPA2-PSK. The network in this example uses **WPA-PSK**.
 - **Encryption:** If you selected open system or shared key authentication, choose 64- or 128-bit WEP. If you selected WPA-PSK or WPA2-PSK authentication, choose TKIP or AES. The network in this example uses **TKIP**.
 - **Encryption key:** If you selected 64-bit WEP encryption, enter a 5-character ASCII or 10-digit hexadecimal key. If you selected 128-bit WEP encryption, enter a 13-character ASCII or 26-digit hexadecimal key. If you selected TKIP or AES, enter an ASCII key of from 8 to 63 characters or a 64-digit hexadecimal key. The network in this example uses **abcde123**.
 - **ANY connection:** Enable this option to make the network SSID public. This makes it easier to connect to the network, but also makes the network less secure. This option may not be available on some access points. In this example, we will enable ANY connection.
- **IP address:** Turn any "obtain automatically" options off and enter the IP address manually. Be sure that the address is different from the addresses used for the computer and WT-4. The addresses for the access point, computer, and WT-4 must however belong to the same class. In this example, we will use the following address for the access point, while the computer and WT-4 are assigned 192.168.1.3 and 192.168.1.4, respectively:
- **IP address:** 192.168.1.2
- **Subnet mask:** 255.255.255.0
- **Default gateway:** ---.---.---.---
- **DNS server:** ---.---.---.---
- **MAC address:** If the network uses MAC address filtering, the filter must be supplied with the MAC address of the WT-4. After attaching the WT-4 to the camera, turn the WT-4 on, select **Wireless transmitter > Device info > MAC address** from the camera setup menu, and note the MAC address.


4: Configure the Computer for Wireless Access

This step is only required if the computer connects to the access point via a wireless LAN. If the computer is connected to the wireless access point via a LAN cable, proceed to Step 5. The settings you choose in Step 4 should conform to the network settings selected in Step 3.

- **Network name:** WT-4
- **Security type:** WPA-PSK
- **Encryption type:** TKIP
- **Security key/Passphrase:** abcde123


4-1

Click **Start** and select **All Programs** > **Accessories** > **Communications** > **Network Connections**.



4-2


Select **Wireless Network Connection** and click **Change settings of this connection**.



4 - 3


Click the **Wireless Networks** tab.

If a third-party wireless connection program is installed, the **Wireless Networks** tab will not be displayed. Choose authentication, encryption, and a security key as described in the documentation for the wireless LAN adapter. The Wireless Networks tab may also not be displayed if Wireless Network Connection is disabled, or if **Wireless Zero Configuration** is active in the **Performance and Maintenance** > **Administrative Tools** > **Services** Control Panel.




4 - 4

Select **Use Windows to configure my wireless network settings**.



4-5

Click **Add**.



4-6

After entering a network name and choosing security options to match those selected for the wireless LAN access point, remove the check from **This is a computer-to-computer (ad hoc) network; wireless access points are not used** and click **OK**.

Network name: Enter a name of up to 32 characters. The network in this example uses the identifier **WT-4**.


Security type: Choose from **Open**, **Shared**, and **WPA-PSK**. The WT-4 does not support WPA.

Encryption type: The type of encryption available depends on the options selected for **Network Authentication**:

- Open, Shared: **WEP**, **Disabled**


- WPA, WPA2: **TKIP**, **AES**

Security key/Passphrase: If **WEP** is selected for **Data encryption**, enter a 5- or 13-character ASCII key or 10- or 26-digit hexadecimal key. Entering a five-character ASCII or ten-digit hexadecimal key enables 64-bit encryption, a 13-character ASCII or 26-digit hexadecimal key 128-bit encryption. ASCII keys may contain letters, punctuation, and the numbers 0–9, hexadecimal keys the numbers 0–9 and the letters a, b, c, d, e, and f. If **TKIP** or **AES** is selected for **Data encryption**, enter an ASCII key of 8 to 63 characters or a 64-digit hexadecimal key.



4 - 7

Click **OK**. Network setup is now complete.




5: Copy the Network Profile to the Camera

Use the WT-4 setup utility to copy the network profile to the camera. Before proceeding, make sure that **MTP/PTP** is selected for the **USB** option in the camera setup menu.


5 - 1

After starting the computer, use the supplied USB cable to connect the camera and turn the camera on.




5 - 2

Double-click the **WT-4 Setup Utility** icon on the desktop.




5 - 3

The dialog shown below will be displayed; click **Next**.




5-4

Select **Add/Edit profiles** and click **Next**.



5-5


Select **Add new profile** and click **Next**.



5-6


Enter the following information and click **Next**:

- **Profile name:** Enter a name of up to 16 characters.
- **Profile type:** Choose **Computer**.
- **Interface type:** Choose **Wireless & Ethernet** for networks that include wireless, or **Ethernet only** for Ethernet-only networks.



5-7


Select **Manual setup** and click **Next**.



5-8

Enter the following information and click **Next**.

- **Network name (SSID):** WT-4
- **Communication mode:** Infrastructure
- **Authentication:** WPA-PSK
- **Encryption:** TKIP
- **Encryption key:** abcde123



5 - 9

Enter the following information and click **Next**.

- **IP address:** 192.168.1.4
- **Subnet mask:** 255.255.255.0
- **Default gateway:** Remove the check from this option.
- **DNS Server:** Remove the check from this option.

WT-4 Setup Utility

Nikon

TCP/IP settings

Obtain IP address automatically

IP address: 192.168.1.4

Subnet mask: 255.255.255.0

Default gateway

DNS Server

<Back Next> Cancel

Choosing an IP Address

Be sure that the address for the WT-4 is different from the addresses used for the computer and access point. The addresses for the access point, computer, and WT-4 must however belong to the same class. In this example, we will use 192.168.1.2 for the access point, 192.168.1.3 for the computer, and 192.168.1.4 for the WT-4.

5 - 10

Confirm that settings are correct and click **Next**.

WT-4 Setup Utility

Nikon


Profile information

Field	Value
Profile name	PC1
Profile type	Computer
Interface type	Wireless & Ethernet
	Wireless settings
Network name (SSID)	WT-4
Communication mode	Infrastructure
Channel	1
Authentication	WPA-PSK

<Back Next> Cancel

5 - 11

Select **Finish wizard** and click **Next**.



5 - 12

Turn the camera off and disconnect the USB cable. The network profile has now been copied to the camera.

6: Connect to the Computer


In this step, you will establish a wireless connection between the WT-4 and the computer. Before connecting the WT-4, select **MTP/PTP** for the **USB** option in the camera setup menu and confirm that the host computer is running and the user is logged in.

6-1

Insert a memory card in the camera, connect the WT-4, and turn the camera on.


6-2

Choose an option for the **Wireless transmitter > Mode** option in the camera setup menu.



6-3


A list of available connection profiles will be displayed. Highlight the desired profile and press **OK**.



6 - 4

Return to the wireless transmitter menu and turn the WT-4 on. The profile name will be highlighted in green when a connection is established.

This completes the process of connecting to the computer.



 **Third-Party Security Software**

Third-party security software with firewall support may block the ftp server port, preventing access to the computer. This can be avoided by setting the software to allow protocols send and receive access to TCP ports 15740 and UDP ports 5353. For more information, see the documentation for the software or firewall.